## **SILENT AUTO GLIDING ELITE BASSINET**



701405

**ASSEMBLY INSTRUCTIONS** 

#### **A** WARNING: **CHOKING HAZARD**

Adult assembly required because of small parts. Keep assembly parts out of reach of children under 3 years.

Styles and colors may vary



**REQUIRED:** Phillips Screwdriver (not included) **IMPORTANT:** Read all instructions before assembly and use of the product. Keep the

instructions for future reference.



#### **Consumer Information**



#### WARNING

**WARNING:** Do not use this bassinet if you cannot exactly follow the accompanying instructions. Failure to follow these warnings and instructions could result in serious injury or death.

• Read all instructions before assembling unit.

**KEEP INSTRUCTIONS FOR FUTURE USE.** 

#### DO NOT USE THIS UNIT IF THE INSTRUCTIONS CANNOT BE STRICTLY FOLLOWED.

Before each usage or assembly, inspect unit for damaged hardware, loose joints, missing parts or sharp edges. NEVER use this
product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and
periodically during use. Contact Simmons Customer Service Department at 1-646-435-8726 (8:00am ~ 4:30pm PST) for
replacement parts, repair or instructions.

# SUFFOCATION HAZARD Infants have suffocated:

- In gaps between an extra padding, a mattress (too small or too thick) and product sides.
- On soft bedding.
- Use only the pad provided by the manufacturer that is no thicker than 25 mm (1 In) and is of such a size that, when pushed against any side of the product, it does not leave a gap of more than 25 mm (1 in) between the mattress and sides.
- NEVER add a pillow, comforter or another mattress for padding.
- Do not leave child unattended in the bassinet when it is in the "rocking/gliding" mode. Always make sure the wheels or stands are in the locked "down" position. Remove any tools or excess parts including plastic packaging from bassinet vicinity after assembly.

**FALL HAZARD:** To help prevent falls, DO NOT use this product when the infant begins to push up on hands and knees or has reached manufacturer's recommended maximum weight of 6.8kg (15lbs), whichever comes first.

#### **STRANGULATION HAZARD:** Children have STRANGLED in cords. Keep the cord out of reach of children.

- Strings can cause strangulation! DO NOT place items with a string around a child's neck, such as hood strings or pacifier cords. DO NOT suspend strings over a product or attach strings to toys.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their backs to sleep, unless otherwise advised by your physician.
- Always attach all provided fasteners tightly according to the instructions. Check frequently. Do not use if there are any loose or missing parts or signs of damage. Do not substitute parts. Contact the manufacturer for replacement parts.
- Use bassinet with only one child at a time.
- Toys are not to be "mouthed" by the baby and should be positioned clearly out of reach of the baby's face and mouth.
- Do not place medication, small toys, small items, cords, straps or similar items that could become wound around the child's neck in or near this product and do not place product near a window, patio door, heater, or power outlet.
- If a sheet is used with the pad, use only the one provided by Delta Children or one specifically designed to fit the dimension of the bassinet mattress.



#### Please DO NOT return this product to the store.

If you experience any difficulty with assembly, missing parts or use, please DO NOT return this item to the store. Retail stores are unable to properly assist you. Contact our Customer Service Department directly for assistance 1-646-435-8726.



www.DeltaChildren.com • gcs@deltachildren.com ©2018 Delta Children's Products, Inc. New York, NY 10001



## **EXTENDED WARRANTY**

#### DON'T MISS YOUR CHANCE TO BE COVERED FOR ALL OF LIFES MISHAPS!

With Delta's Extended Warranty, you're covered for mechanical failure from normal use or if your item stops working due to normal wear and tear, plus all those unexpected surprises.


## 2 YEARS OF PROTECTION


For Additional Information:
Simply visit our Website, register your product, and add the Extended Warranty
<a href="https://www.deltachildren.com/pages/product-registration">https://www.deltachildren.com/pages/product-registration</a>

Extended Warranty only available in the following States: Arkansas, Colorado, Delaware, District of Columbia, Georgia, Idaho, Illinois, Indiana, Iowa, Kansas, Kentucky, Louisiana, Maryland, Michigan, Mississippi, Missouri, Nebraska, Nevada, New Hampshire, New York, North Carolina, North Dakota, Pennsylvania, Rhode Island, South Dakota, Tennessee, Utah, West Virginia


#### **Parts**

#### **IMPORTANT!** Please remove all parts from the package and identify them before assembly.







Mattress Support Board
Part # 50377




**Fabric Liner** 



Fabric Storage Liner
Part # 56381







**Auto-Glide Housing (X1)** 

(Needs 2 - M6 - 3.5cm - screws to attach to front base leg with wire connection)

Part # 50376







Mattress Pad Part # 50380



**Sheet** Part # 50382


#### **Parts**

**IMPORTANT!** Please remove all parts from the package and identify them before assembly.




**Locking Casters (X4)** 

Part # 50292




**Phillips Screwdriver** 

(NOT INCLUDED)




**Canopy With Plush Bears** 

Part # 50419




#### **Hardware**

\*Screws are shown in actual size - 10 total screws



M6 - 1.7cm x 8pcs

Part # 50428



M6 - 3.5cm x 2pcs

(Used for power housing assembly)
Part # 50535




**Power Cord** 


Part # 50295

### **Top Frame Assembly**

1


NOTE: You may need the help of another adult for assembly.







- Place the frame on a flat surface and extend the support legs out.
- Locate the mattress support board and align the front of frame to top of support board front.
- Align and insert the (4) support legs into the (4) support board housings until they "click" in place.

NOTE: Pull upward to make sure support legs are fully locked.









\*Completed top frame assembly

#### **Attaching Power Housing to Front Base Leg**




## Front Base Leg and Frame Assembly




- Locate the two (x2) M6 screw, a Phillips screwdriver, and the front base leg.
- Insert the two (x2) M6 screw to the assembled front base leg and use the Phillips screwdriver to tighten on both sides.

NOTE: Align the front base leg so that the power housing is facing inside of the bassinet.


## **Back Base Leg and Frame Assembly**




#### **Storage Basket Assembly**





- Locate the two (x2) support tubes, and the fabric storage liner.
- Slide the support tubes into fabric storage liner on both sides.
- Flip over the fabric storage liner with support tubes, facing upward.












- Locate the four (x4) M6 x 1.7cm screws and a Phillips screwdriver
- Insert the (x4) M6 screws on both sides of the legs and use a Phillips screwdriver to tighten both screws on both sides.

NOTE: Pull side support tube to make sure it's fully fastened.


## **Locking Casters Assembly**





- Locate the four (x4) locking casters and insert into (4) bottom leg joints.
- Insert the casters into the base legs. Push down until you hear the caster "CLICK" into place.
- Pull upward on the caster to assure it is properly attached to the bassinet.





\*Once casters are assembled, turn the assembly bassinet upright.

#### **Consumer Information**




#### Read all instructions BEFORE assembly and USE of product. KEEP INSTRUCTIONS FOR FUTURE USE.

**CAUTION** - Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


**NOTE:** This equipment has been tested and found to comply with the limits for a class B digital device. pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

## **Attaching Music Module**




• To attach Music Module, remove the screws and line up music module to screw holes on front frame.



• Position Music Module onto front of frame and screw module to frame.

#### **Music Module Operation**




- Press Auto Glide button (GLIDE) to start 15 minute cycle of auto glide.
- Press again to stop auto glide.
- Activate bassinet light by pressing LIGHT button (3) on the top of the music module.

**NOTE:** Light will stay on in 10-minute cycles, unless button is pressed before 10 minutes are up.

- Press MUSIC button (♪) on top of the music module to activate MUSIC. Press button multiple times to cycle through three (3) music melodies.
- Volume can be adjusted with UP/DOWN buttons on the top of the music module.


#### **Attaching Fabric**




Locate the fabric liner.

NOTE: Front of the frame has the music module and the front of the liner has the warning label.


- Align the fabric hole over the music module.
- Place the liner onto the frame. Make sure warning is centered at the front of the bassinet.




 Stretch the pockets on the bottom of the liner around the ends of the mattress support.



 Lift the skirt on the liner, snap all (8) of the straps around the top tube of the frame and all (4) snaps to the underside of the mattress boards.




- Place the sheet over the mattress pad.
- Place the covered mattress pad into the liner.




- Position the canopy over the top end of the bassinet opposite the warning label.
- Push aside foam to expose metal and push the canopy ratchet onto the frame on both sides of the bassinet.
- Fasten the hook and loop fasteners on the back edge of the canopy to the liner. Then fasten the hook and loop patches on each canopy flap to the side of the liner.

## **Wire Connection Assembly**



- Lift the fabric on the front of the bassinet.
- Locate the auto-glide housing plug cord 1 and insert it into the auto-glide connector 1. (Fig. 1)
- Locate the large plug cord 2 and insert into the top leg connector 2. (Fig. 2)

Make sure both wires are fully connected (Fig. 1)



Bottom Base Leg Connection Located On The Inside Of Base Leg Fig. 2A

 Locate the Power Cord. Insert underneath the fabric storage liner opening and plug into the Bottom Base Leg Connector (Fig. 2) until fully connected (Fig. 2A)

#### **Care and Maintenance**

- The frame, mattress pad, storage basket, music module may be wiped clean using a mild cleaning solution and a damp cloth. Do not use bleach. Do not use harsh or abrasive cleaners. Rinse clean with water to remove residue. Do not immerse the frame.
- The sheet is machine washable. Wash it separately in cold water on the gentle cycle. Do not use bleach. Tumble dry separately on low heat and remove promptly.
- Always store product in a clean and dry place.
- Before each usage or assembly, inspect unit for damaged hardware, loose joints, missing parts or sharp edges. NEVER use this product if there are any loose or missing fasteners, loose joints, broken parts, or torn mesh/fabric. Check before assembly and periodically during use. Contact Simmons Customer Service Department at 1-646-435-8726 (8:00am ~ 4:30pm PST) for replacement parts, repair or instructions.



Delta Childrens Products Corp. 114 West 26th Street New York, NY 10001 1-646-435-8726

www.DeltaChildren.com