



### Operation

▶▶	Play/Pause	Single Click MFS (L/R)
⬅	Volume Up+	Triple Click MFS (L)
➡	Volume Down-	Double Click MFS (L)
⏮	Previous Track	Double Click MFS (R)
⏭	Next Track	Triple Click MFS (R)
📞	Answer Call/Hang Up	Single Click MFS (L/R)
📞	Reject Call	Press the MFS for 2 seconds (L/R)
🗣️	Voice Assistant function-Siri / Google	Press the MFS for 3 seconds (R)
👂	Hearing-through	Press the MFS for 3 seconds (L)

### LED Indicator Lights

Usage Scenario	LED Indicator Status
Power On	White LED light flashes for one second
Power Off	Blue LED light flashes for one second
Pairing	Blue and White LED alternating flash
Pairing succeeds	White LED light flashes every 7 seconds
Playing music or on calling	LED lights off
Low Power	White LED light flashes twice every 8 seconds
When put earphones in the charger case	Blue LED light on
Earphones are sitted in the charger case	LED lights off
Charging	The last LED light flashes
Fully charged	All LED lights on

Single Pairing mode: Put one side back in the charging case and the other earphone will work independently.  
One side will continue working even when the other side is powered off." Pairing after being taken out of range.  
The earphones will automatically pair to the smartphone within 3 minutes if they are close to the smartphone again after being taken out of range.  
If they are not brought within range within three minutes, the headphones will automatically power off.



### Specification

Product Model	Noble FoKus Prestige
Bluetooth Version	V 5.2
Bluetooth Profile	A2DP, AVRCP, HFP, HSP
DD Diameter	Triple-driver arrangement, 1 Dynamic & 2 Balanced Armature
Resistance	30Ω±(15%)
Connection Distance	≥10m
Earphone Battery Capacity	50mAh
Charging Case Battery Capacity	500mAh
Play time	9-10 hours for earphone(50% volume) and more than 26 hours for charger case.
Charging time	~1.5 hour
Charging Port	USB Type C (5V = 1A)

### Declarations and Warnings

Disconnect previous devices before pairing a new device.

**WARNING!**  
Long-term exposure to high noise volumes may cause permanent hearing loss. Do not use the Noble FoKus Prestige earphones in locations prohibiting the use of electronic equipment.  
Consult your physician prior to using your Noble FoKus Prestige earphones if you have a pacemaker or other electrical medical devices.  
This package contains small parts, which may pose a hazard to small children. Do not disassemble the Noble FoKus Prestige as it contains lithium batteries, and disassembly could result in electric shock or fire or serious injury.  
Any disassembly of the Noble FoKus Prestige, or attempt to replace or repair the Noble FoKus Prestige by an unauthorized person, will void the Noble FoKus Prestige warranty.  
This product is not designed for use in water or wet environments. Keep product away from water and liquids.  
Failure to do so will void any warranty and may cause permanent damage to the product.

### FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
Reorient or relocate the receiving antenna.  
Increase the separation between the antenna and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.

11

12