

ROKINON **F**

14mm F2.8 AF Nikon F Mount Instruction Manual



Thank you for purchasing the Rokinon AF 14mm F2.8 lens. It is a high performance prime autofocus optic designed exclusively for Nikon F mount interchangeable lens cameras. Please note that supported functions may vary according to the camera model.

Advantages

- It will provide optimal quality still images and video with both Nikon Full Frame and APS-C image sensor cameras.
- It's ultra-wide view, performance and image quality competes with the best in its class.
- UMC anti-reflective coatings, one ED, two high precision Aspherical, and four High Refractive Index elements combine to minimize aberrations and increase sharpness and contrast.













- The AF (autofocus) function is optimized for fast and precise focus detection with the latest Full Frame high pixel count Nikon DSLR's.
- Its size, shape and grip have been ergonomically designed for enhanced stability and comfortable use.
- The refined all metal design combines a luxurious look with excellent durability and is weather sealed to help protect against dust and moisture.
- It maintains excellent distortion control and resolution from the center to the edges of the frame.

Cautions

- Do not look directly at the sun through the lens as it may seriously impair your vision.
- Do not to apply excessive force when attaching the lens to the camera as it may cause damage to the lens or your camera.
- The lens is a precision optical product, so dropping or excessive impact may cause product failure.
- Attach or detach the lens only while the camera is turned off.
- Be careful not to touch or contaminate the contacts on the mount as it can adversely affect communication with the camera.
- Protect the lens from water, high humidity and excessive heat.
- Always store the lens with the lens cap on in a dry and well ventilated location out of direct sunlight. Direct sunlight passing through the lens could become concentrated enough to cause a fire.

- Avoid subjecting the lens to drastic temperature changes such as moving from a very cold outdoors location to a warm indoors location. This can cause moisture in the air to condense inside or on the outside of the lens and lead to failure or mold production. Before taking the lens indoors from a cold outdoors location, put the lens in a plastic bag or sealed camera bag and remove it only when the lens has warmed up to room temperature.

CAUTION

 <p>When mounting the lens make sure that it clicks in place otherwise it may detach and cause damage or injury.</p> 	 <p>Do not apply excessive force on the lens when it is attached to the camera. It may damage the lens and camera mount.</p> 	 <p>Ensure that the lens is operating properly by testing it on your camera before shooting an important event.</p> 
 <p>Do not modify or try to repair the lens as this will invalidate the warranty.</p> 	 <p>Do not leave the lens in direct sunlight as this could cause a fire.</p> 	 <p>Do not look directly at the sun through a camera with a lens attached it may damage your eyesight.</p> 

Cleaning

- It is extremely important before cleaning to dust off the lens surface using a lens blower or a soft brush to remove any foreign particles or grit that could scratch the lens.
- Using a clean microfiber lens cloth, gently wipe the lens in a circular motion from the center outwards towards the edges of the glass.

- If stubborn spots remain, put only one or two small drops of ethanol or reputable lens cleaner on the microfiber cloth and repeat the circular cleaning process. **DO NOT USE AN ORGANIC SOLVENT SUCH AS PAINT THINNER, ALCOHOL, OR BENZENE.**

Included Components

- Front lens cap
- Rear lens cap
- Warranty Card
- Soft lens pouch
- Instruction manual

Attaching the lens

- Remove the rear lens cap and the camera body cap.
- Align the index mark (white dot on the lens) with the index mark (white dot) on the lens mount of the camera.
- Do not press the lens release button on the camera when mounting the lens.
- Insert the lens into the camera mount and rotate it counterclockwise until it "clicks" and locks in place. Do not insert the lens at an angle.
- Remove the front lens cap when you are ready to shoot.

Detaching the lens

- Attach the front lens cap.
- While holding down the lens release button on the camera body, rotate the lens clockwise until it stops and separate the lens from the body.
- Attach the rear lens cap.



① Built-In Hood

③ Lens mount

⑤ Contacts

② Manual focus ring

④ White index mark

⑥ AF/ Manual switch

Nikon DSLRs offer various methods of focusing. For detailed information regarding the available focus mode settings for your particular model, refer to your camera's instruction manual.



- Set the AF/MF switch to "AF" for auto focus operation.

- For manual focus operation set the switch to "MF". Manual Focus allows you instead of the camera to adjust the focus by rotating the manual focus ring on the lens.

Product specifications

Model name	IO14AF-N	
Aperture range	F2.8 ~22	
Angle of View	Full Frame	116.6°
	APS-C	92.8°
Optical construction	15 elements in 10 groups including 1 ED, 2 Aspherical and 4 HRI	
Minimum focusing distance	7.9in (0.20m)	
Maximum shooting magnification	0.15x	
Filter size	n/a	
Number of aperture blades	7	
Maximum diameter X length	3.6" x 3.7" (90.5 x 93.1mm)	
Weight	16.7 oz (474g)	
Weather Sealed	Yes	

- The minimum focus is the distance from the image sensor to the object.
- The product specifications and exterior are subject to change without notice.

Elite Brands Inc.
Rokinon Division
New York, NY 10005

Toll Free: 800.441.1100
Phone: 212.947.7100
support@rokinon.com

rokinon.com
facebook.com/rokinonlenses

ROKINON® is owned and operated solely by Elite Brands Inc.