



Air Fryer
Quick Start Guide



Welcome to the Family!

Whether it's your first iCucina appliance or you're already part of our family, we're happy you're here! Our customers are our mission, and we hope to bring you and your loved one's new memories, lots of smiles, and happy taste buds through our Air Fryer. We strive to grow alongside you on your culinary journey - if you have any questions, comments, or concerns, please reach out to our team at service@icucinakitchen.com.

We know you're hungry to get cooking, but please take a few minutes to read through this quick guide, user manual, and warranty information.

We wish you happy taste buds!

From our kitchen to yours,

iCucina Kitchen Team

Step 1



Make sure the air fryer is properly plugged in. To turn on, press the power button on the digital display. Place prepared food in the appropriate accessory.

Step 2



Insert or place the accessory into the air fryer oven. Use the rotisserie fetch tool if necessary.

Step 3



Set the time and temperature as desired or select the preset function, then press the power button to start. Press the rotation button if desired.

Step 4



After the 20 second cool-down fan has been completed, take out, and enjoy!

Control Panel Preset Function Chart

Preset Buttons	Temperature	Time
French Fries	400°F (200°C)	15 minutes
Steaks/Chops	370°F (185°C)	25 minutes
Fish	390°F (200°C)	15 minutes
Shrimp	320°F (160°C)	12 minutes
Chicken	370°F (185°C)	40 minutes
Baking	350°F (175°C)	30 minutes
Rotisserie	400°F (200°C)	30 minutes
Dehydrator	90°F (30°C)	4 hours (2-24 hours)

