

## TS1921 Occupancy Sensor

# **Installation Guide**





## **Table of Contents**

1	Welcome!	<u>3</u>
2	What is in the box?	<u>4</u>
3	Sensor Overview	<u>5</u>
4	Pairing the Sensor	<u>6</u>
5	Mounting the Sensor on a wall	<u>10</u>
6	Placing the Sensor on a flat surface	<u>11</u>
7	Ready for use	<u>12</u>
8	Occupancy Detection	<u>13</u>
9	Changing Occupancy Detection settings on the Portal	<u>14</u>
10	Connectivity	<u>19</u>
11	Specifications	<u>20</u>
12	Enviromental-Friendly Features	<u>22</u>
13	Replacing the battery	<u>23</u>
14	Troubleshooting	<u>24</u>
15	FCC Statement	<u>25</u>
16	IC Statement	<u>26</u>



#### Welcome!

Thank you for choosing the TrickleStar TS1921 Occupancy Sensor.

This Occupancy Sensor is an accessory for the TrickleStar Wi-Fi Smart Thermostat. The Sensor helps the Thermostat to maximize comfort to your room as the sensor can detect occupancy as well as measure the temperature in the room. Maximum 6 sensors can be connected to the thermostat via bluetooth.

This Installation Guide describes how to install the Sensor and pair it to a TrickleStar Wi-Fi Smart Thermostat.

If you have any inquiries about TrickleStar products or need technical support, visit our website for tutorials, videos and Frequently Asked Questions (FAQ). You can also contact us by email or phone.

Website: www.tricklestar.com Email: customer.service@tricklestar.com Toll Free: 1-888-700-1098

#### **Instruction Videos**

If you want to see the Installation Instructions as videos, visit our YouTube channel:

https://www.youtube.com/user/TrickleStarUS/





#### What is in the box?



Occupancy Sensor





Stand

Double-sided adhesive



QR code sheet



Lithium cell battery (CR2477X x 1)

Fig 4-A

4



#### **Sensor Overview**



Fig 5-B



#### Pairing the sensor

#### **Step 1: Remove Battery Insulator**

To power up the sensor, gently remove the sensor back cover by detaching the cover from the clips. You will see an insulator on the battery with the caption "REMOVE BEFORE USE". Lift the battery by pulling on the battery insulator and gently peel off the battery insulator.

Insert the battery back into the sensor's battery compartment. Reassemble the sensor back cover.



When the Sensor is powered up, it enters Pairing mode automatically. The LED starts blinking and continues blinking up to eight minutes.





If the LED does not blink after the Sensor is powered up or after battery insertion or the Sensor exits Pairing mode after eight minutes, hold the Pairing Button for 2 seconds to re-initiate pairing to the thermostat. The sensor will enter Pairing mode again and broadcast itself for 8 minutes for thermostat scanning. LED will blink briefly in the mode.



Fig 7-A

#### **Step 2: Add Occupancy Sensor to the system**

- 1. Log in to your TrickleStar Portal account at: portal.tricklestar.com You can also use the QR code here.
- 2. On the Dashboard screen, select Devices, then click on your Thermostat Name to enter the Thermostat page.
- 3. Select Sensors on the left panel, then click on "+" to add a new sensor.
- 4. Enter the name for your sensor.





- 5. Press Next once your sensor LED is blinking to complete the pairing process. This will initiate a scan function and the Thermostat will scan for sensors in range. Sensors that are detected will be listed by their MAC addresses. Users can select from the list if there is more than one sensor to be paired and add the sensors. Note: It may take up to 30 seconds to detect and pair a new sensor.
- 6. Once your sensor is successfully added, the Connection Status, Temperature, and Occupancy State will be shown as "Not Used". Wait 1-2 minutes for the Sensor Data to be auto-updated or you may click on the "Refresh Sensor Data" button to update the sensor readings.

TrickleStor.	Thermostat - S	ensors					¢÷ í	🗹 John 🗸
Control Modes Schedules Usage	Devices > PPN04 > Sensors						6 © + Search	<ul><li>○ ◊</li></ul>
Settings	Sensor Type	▲ Name 🔶	Temperature 🔶	Humidity 🖨	Sensor Enabled	Occupancy	Status	Weighting 🖨
Sensors			76°F	66%				100%
Services <	Occupancy Sensor				Yes	Occupied	Connected	100%

Fig 8-A



If pairing is successful, the Occupancy Sensor's LED will blink twice. Then, the Bluetooth indicator appears on the Thermostat display.





If pairing is unsuccessful or time-out after 8 minutes, the LED will stop blinking and the Sensor will go into standby mode. In Standby mode, the connection between the sensor and the thermostat is not set up. All the sensor circuits will be shut down to save power. Hold the Pairing Button for 2 seconds to initiate the Pairing mode again.

Note: If the sensor is previously registered, it will be added to the thermostat network automatically in Pairing mode. If disconnected, the sensor will change to Pairing mode automatically and try to reconnect with the thermostat. User can also press the pairing button to restart the sensor in Pairing mode.



#### Mounting the Sensor on a wall

Before you mount the Sensor on the wall, be sure to check that:

- The sensor is connected to the Thermostat.
- The sensor is mounted away from direct heating or cooling sources, such as a fireplace or an air ventilator.

Attach the double-sided adhesive to the Sensor. Then, mount the Sensor at a height of approximately 5 ft. (1.5 m) on the wall.



Fig 10-A



#### Placing the Sensor on a flat surface

Before you place the Sensor on a flat surface, be sure to check that:

- The sensor is connected to the Thermostat.
- The sensor is placed on an even surface and at a safe location.
- The sensor is facing the direction where you want to detect occupancy.

Attach the stand to the Sensor. Then, place the Sensor on a flat surface.



Fig 11-A



#### **Ready for use**

#### Normal mode

The Occupancy Sensor is now ready for use. In Normal mode, the connection between the sensor and the thermostat is set up. The sensor will automatically update the Connection Status, Room Temperature, Occupancy State and Sensor Battery Level in the Tricklestar Portal and Tricklestar App.

You can enable or disable the sensor detection LED operation in Normal mode through the TrickleStar Portal Sensor settings (Occupancy Detection LED Enabled). This option also disables the sensor detection LED by default, where the sensor LED will not blink when it detects a movement. If the LED is enabled it will blink once when there is movement detected within 30 second interval.







#### **Occupancy Detection**

The occupancy sensor is equipped with an occupancy detection function. It uses PIR sensor to detect the infrared signal of moving bodies. You can also enable or disable the occupancy detection function for each sensor individually through the Portal.

You can adjust the Absence Detection Sensitivity and Occupancy Detection Sensitivity, and enable or disable the Occupancy Detection feature of the thermostat. If disabled, regardless of any sensor output and individual sensor settings, the thermostat will ignore the occupancy status received and will not automatically change the Mode. However, it will not shut off the sensor detection circuit and you can still check the occupancy states for each sensor through the Portal or App.

The occupancy detection feature is enabled if:

- a) The Occupancy Detection Enabled is set to Yes at the Portal.
- b) The Sensor Enabled of each individual sensor is set to Yes at the Portal.
- c) The Sensor Status in the Portal is Connected.
- d) The active Mode is Home or Away (not Sleep).
- e) The Thermostat is on Schedule mode, not on Temporary/Permanent/Vacation Hold or when user has changed the Mode manually.



## **Changing Occupancy Detection settings on the Portal**

TrickleStar 💥		🔅 🗹 John 🗸
← Back	Thermostat - Sensors	
• PPN04 <	Devices > PPN04 > Separa	
Control		2
Modes		© (Đ) 🗇 (Đ)
Schedules		
Usage	Show 7 🕈	Search
Settings 1	_ Sensor Type ▲ Name	Enabled Occupancy Status Weighting 💠
Sensors	Built-in 76°F 66% -	100%
Services <	Occupancy Sensor 01 77°F - Yes	Occupied Connected 100%
	Showing 1 to 2 of 2 records	

Fig 13-A

TrickleStar.						
← Back	Thermostat - Sensors					
Control	Devices > PPN04 > Sensors					
	Thermostat Temperature Sensor					
	Weighting <b>0</b>	100% (default) ~				
	Occupancy Sensor General Settings					
Sensors	Occupancy Detection Enabled 0	Yes				
	Absence Detection Sensitivity 0	5 minutes ~				
	Occupancy Detection Sensitivity <b>1</b>	0 seconds (default) ~				
	Occupancy Detection Restart Time	0 minutes ~				
	Occupancy Detection LED Enabled 0	Yes				
	Occupancy Sensor 1					
		Sensor 01				
		CD-13-9B-17-F4-17				
		0941-O205-00067				
	Weighting <b>0</b>	100% (default) ~				
		Yes				
	Status	Connected				
	Temperature	77°F				
		Occupied				
	Battery Voltage	2.98V				

Fig 13-B



#### **Occupancy detection algorithm**

The thermostat changes the Mode automatically based on the received occupancy states from the sensors:

If the Mode is "Home"

You can set the Absence Detection Sensitivity as shown in Fig 13-B (Thermostat Sensor Settings). When the occupancy sensor detects no movement within the Absence Detection Sensitivity time set, the Mode will automatically change to "Away (set by sensor)" and follow your preset Away Mode setting as shown below:



TrickleStar 🐝		🔅 🎽 John 🗸
← Back	Lounge	
C Lounge	Devices > Lounae > Control	
Control		
Modes		
Schedules		
Usage		System
Settings		-X-
Sensors		
Services		
		Auto ~
	<u>о 61% 8 вч</u>	No hold (run current schedule) ~
	//+\\\`	Away (set by sensor)

Fig 16-A

ļ

<b>TrickleStar.</b>	Thermostat - Modes					¢ 🛛	John 👻
PPN04     Control     Modes							
Schedules Usage	# * Name	Set Temperature (Heat)	Set Temperature (Cool)	Set Fan (Heat)	Set Fan (Cool)	Used In	
Settings Sensors	2 G Home 2	687F ~	75°F ~	Auto	Auto		
Services <	3 🛃 Away 4 🕑 Sleep	64°F ~	Off ~ 80°F ~				

Fig 16-B



If the Mode is "Away"

You can set the Occupancy Detection Sensitivity as shown in Fig 13-B (Thermostat Sensor Settings). When the occupancy sensor detects a movement within the Occupancy Detection Sensitivity time set, the Mode will automatically change to "Home 1 (set by sensor)" or "Home 2 (set by sensor)" depending on the Home mode that is closest to the current time in the schedule, and follow the corresponding preset Home mode setting as shown below:



TrickleStar 💥							\$ ₽	John 🛨
← Back	Thermos	stat - Modes						
• PPN04 <								
Control								
Modes								
Schedules	# 🔺 Nam	e	Set Temperature (Heat)	Set Temperature (Cool)	Set Fan (Heat)	Set Fan (Cool)	Used In	
Usage	1 🖓		68°F ~	78°F ~				]
Sensors	2 🛱							
Services <	٤ <u>جُ</u>							
	4 (****							





If the Mode is "Sleep" The thermostat will not change the Mode.

To cancel the Mode change Press jog dial for 3 seconds to return to the Current Schedule.



## Connectivity

- Bluetooth Low Energy (BLE v4.2) connection with the TrickleStar Wi-Fi Smart Thermostat
- Connection range: 98 ft. (30 m)
- Data refresh rate: 30 seconds (Connection Status, Temperature, Occupancy State, Battery Voltage)



## **Specifications**

Temperature range	
Measurement	: 32°F to 104°F (0°C to 40°C)
Sensitivity	: 0.1°F (0.05°C)
Accuracy	: ±1°F (60°F to 80°F), ±2°F
	(any other range)
Operating	: 32°F to 122°F (0°C to 50°C)
Humidity range	
Operating	: 5% to 95% RH
	(non-condensing)
Storage	
Temperature	: -4°F to 140°F (-20°C to 60°C)
Humidity	: 5% to 95% RH (non-condensing)
<b>Product dimension</b> (Width/Height/Depth) (Approx.)	<ul> <li>2.4 in. x 1.9 in. x 1.1 in. (60.5 mm x 48.3 mm x 28.7 mm) (without the stand)</li> <li>2.4 in. x 2.5 in. x 1.1 in. (60.5 mm x 64.5 mm x</li> </ul>
	28.7 mm) (with the stand)
Product weight	
(Approx.)	: 1.4 oz. (40.7 gm)
Battery	
Battery voltage	: Yes
measurement	
Battery voltage measurement resolution	: 0.1 V
Battery warning level	: 2.6 V
Battery critical level	: 2.3 V
Battery life	: 2 years

20



#### **Detection Range**

Occupancy detection method Horizontal

Vertical

: Passive Infrared (PIR)

÷

- 36 ft. (11 m) (0°), 29.5 ft. (9 m) (+/- 30°), 16.4 ft. (5 m) (+/- 60°)
- : 6.6 ft. (2 m) (30° downward), 3.3 ft. (1 m) (45° downward)





## **Environmentally-friendly features**

- Recyclable packaging
- Mercury-free
- Arsenic-free
- PVC-free
- PBT-Free

Approvals

FCC, IC (REL) - Canada, UN 38.3, RoHS compliant



CA PROP 65 California Proposition Compliant



#### **Replacing the battery**

There is no low battery indication on the sensor. The Portal or App will send notification to remind you to change the sensor battery when the battery voltage drops to warning level (2.6 V) or critical level (2.3 V). When the voltage drops to Battery critical level or below, normal operation of the sensor cannot be guaranteed.

Remove the Battery Cover and replace the battery in the battery compartment. Put back the Battery Cover. The Sensor will automatically power up and reconnect to the TrickleStar Wi-Fi Smart Thermostat.





## Troubleshooting

Symptom	Solution
The Occupancy Sensor does not pair with the TrickleStar Wi-Fi Smart Thermostat	<ul> <li>Check that the battery insulator "REMOVE BEFORE USE" has been peeled off completely from the sensor battery and the sensor LED is flashing continuously.</li> <li>Check if the Sensor is within the connection range of 98 ft.</li> <li>If the sensor LED does not flash, hold the Pairing Button for 2 seconds to initiate pairing to the Thermostat.</li> </ul>
When you have added the Occupancy Sensor but the Connection Status, Temperature and Occupancy State is shown as "Not Used"	Wait 1-2 minutes for the Sensor Data to be auto-updated or you may click on the "Refresh Sensor Data" button to update the sensor readings.

If the problem persists, you can refer to the Frequently Asked Questions (FAQ) section on our website, or email or call our technical support:

Website: www.tricklestar.com Email: customer.service@tricklestar.com Toll Free: 1-888-700-1098



#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### **IC Statement**

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### 20cm 警告语:

The distance between user and device should be no less than 20cm. Ia distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.





For technical support, go to: Website: www.tricklestar.com Email: customer.service@tricklestar.com Toll Free: 1-888-700-1098

Patent Pending

© 2021 TrickleStar Inc.

TrickleStar® is a registered trademark of TrickleStar Ltd. All other trademarks are the property of their respective owners. The information in this document is subject to change without notice. TrickleStar assumes no responsibility for any errors that may appear in this document.