

HS150 eMeetLink User Manual

EMEET GeniusCall HS150

Device settings

Firstly, connect the device to the computer via USB cable.

Open the eMeetLink software and enter the setting interface.

1. Remain talk time

You can check the remaining talk time of your device.

General Settings

Firmware Ver: 1.5.2/1.2.6

SN Code:

Remaining talk time: 3 hour

2. Bluetooth name

You can change the Bluetooth name of your device to make it easier to find on the available list.

Bluetooth name

GeniusCall HS150

3. Standby time

You can decide how long the device shuts down after you stop using it.

Standby time

1H

2H

5H

8H

Always on

4. Switch


You turn on/off the Vocal voice broadcast function to decide whether it will show on the device according to your needs.

Switch

Vocal voice broadcast ⓘ

5. Restore Default Settings


After restoring default settings, all operating settings will be restored to factory mode.



Settings

In this setting interface, you can change the language according to your need.


Check your eMeetLink software version and update it.



Support

1. Feedback


Write your feedback here to get EMEET customer service support.



The screenshot shows a web application window with a dark sidebar on the left containing icons for home, settings, notifications, and user profile. The main content area has a navigation bar with links for Feedback, FAQs, User Manual, Compatible device, and Contact. The Feedback form includes a 'Question type' dropdown menu, a 'Device Name' dropdown menu, a large text area for 'Problem Description', and 'Submit' and 'Cancel' buttons. The 'Feedback' link in the navigation bar is highlighted with a red box.

2. FAQs

There are some common questions for your reference.




The screenshot shows the same web application window with the 'FAQs' link highlighted in the navigation bar. The main content area displays four common questions and their solutions:

- 1. The device is plugged into the USB port of the computer, but the device is not detected.**
Please unplug the device USB and re-plug the computer USB port.
- 2. Computer (PC) software cannot be updated.**
Please check if the software has already been the latest version. You can also uninstall the software and download the latest eMeetLink software on the official EMEET website.
- 3. After renaming the device, the updated device name is not displayed.**
Click [Save] and [Confirm] the device name.
- 4. eMeetLink is unavailable.**
Please check if your device is connected to the computer via USB.


At the bottom of the page, there is a link that says "Still have questions?".

3. User Manual

Click the device to enter EMEET official website and get the user manual.



4. Compatible device



5. Contact info

Feedback FAQs User Manual Compatible device **Contact**

Telephone

+1 888 959 5320 Mon-Fri 9:00am - 5:00pm (EST)
+81 8008051955 月-金 10:00am - 6:00pm (JST)
400 8338 051 周一-周五 9:00am - 5:00pm (BJT)

Official website

<https://www.emeet.com>

E-mail

Support: support@emeet.com
Marketing: marketing@emeet.com
Sales: sales@emeet.com