
M1A eMeetLink User Manual

EMEET OfficeCore M1A

Device settings

1. Lighting

You can turn on/off the Device light function to decide whether the device light will show on the device according to your needs.




2. Pickup gain

You can drag the slider to adjust the intensity of voice pickup.



3. Restore Default Settings


After restoring default settings, all operating settings will be restored to factory mode.



Settings

In this setting interface, you can change the language according to your need.

Check your eMeetLink software version and update it.



Support

1. Feedback

Write your feedback here to get EMEET customer service support.

The screenshot shows a web application window with a dark sidebar on the left containing icons for home, settings, notifications, and user profile. The main content area has a navigation bar with five tabs: Feedback, FAQs, User Manual, Compatible device, and Contact. The 'Feedback' tab is selected and highlighted with a red box. Below the navigation bar, there are two dropdown menus: 'Question type:' and 'Device Name:', both with 'Please select' as the current selection. A large text area labeled 'Problem Description:' contains the placeholder text 'Please enter'. At the bottom of the form are two buttons: 'Submit' and 'Cancel'.

2. FAQs

There are some common questions for your reference.


The screenshot shows the same application window as above, but with the 'FAQs' tab selected and highlighted with a red box. The main content area displays four numbered questions with their respective solutions:

- 1. The device is plugged into the USB port of the computer, but the device is not detected.**
Please unplug the device USB and re-plug the computer USB port.
- 2. Computer (PC) software cannot be updated.**
Please check if the software has already been the latest version. You can also uninstall the software and download the latest eMeetLink software on the official EMEET website.
- 3. After renaming the device, the updated device name is not displayed.**
Click [Save] and [Confirm] the device name.
- 4. eMeetLink is unavailable.**
Please check if your device is connected to the computer via USB.


At the bottom of the page, there is a link that says "Still have questions?"

3. User Manual

Click the device to enter EMEET official website and get the user manual.



4. Compatible device



5. Contact info

