

eMeetLink Guide

EMEET SmartCam S600


Device settings

Firstly, connect the device to the computer via USB cable.
Open the eMeetLink software and enter the setting interface.

1. Camera settings

1) Image Flip

The image of this device supports flip horizontal or vertical.
Check the “Flip Horizontal” button to validate the horizontal flip of the image.
Check the “Flip Vertical” button to validate the vertical flip of the image.



2. Video settings

1) Filters


There are four filters mode for your choices: Default, Customize, Black and White, or Cartoons. You can select according to your needs.

Default: In this mode, the other parameters such as brightness, contrast, sharpness, saturation, and white balance can not be adjusted.

Black and White: In this mode, the image will be black and white.

Cartoons: In this mode, you will get the image with a cartoon filter.


Customize: In this mode, you can drag the slider to adjust the image parameters like brightness, contrast, sharpness, saturation, and white balance according to your needs.



2) Anti-flicker

Most countries use 50HZ as the power grid operating frequency, and some countries such as the United States use 60HZ.

Choose a suitable power frequency to avoid the screen flashing.




3) White Balance

In the customize mode, you can click the “Auto” button to open or close the white balance auto adjustment function.


When the auto button shows blue, the white balance of the image will be adjusted automatically.

When the auto button shows grey, you can adjust the white balance according to your needs.




4) Restore Default Settings

After restoring default settings, all operating settings will be restored to the factory mode.




3. Firmware update

In the upper right corner, you can see your device's firmware version. Also, you can click the "update" button to get the latest version.



Settings


In this setting interface, you can change the language according to your need. Check your eMeetLink software version and update it.



Support

1. Feedback


Write your feedback here to get EMEET customer service support.



The screenshot shows a web application window with a dark sidebar on the left containing navigation icons. The main content area has a top navigation bar with links for Feedback, FAQs, User Manual, Compatible device, and Contact. The Feedback form includes a 'Question type' dropdown menu with 'Please select' as the current value, a 'Device Name' dropdown menu with 'Please select' as the current value, and a large text area for the 'Problem Description' with the placeholder text 'Please enter'. At the bottom of the form are 'Submit' and 'Cancel' buttons.

2. FAQs

There are some common questions for your reference.




The screenshot shows the same web application window with the 'FAQs' tab selected in the top navigation bar. The sidebar icon for 'FAQs' is highlighted with a blue circle. The main content area displays four numbered FAQ items:

- 1. The device is plugged into the USB port of the computer, but the device is not detected.**
Please unplug the device USB and re-plug the computer USB port.
- 2. Computer (PC) software cannot be updated.**
Please check if the software has already been the latest version. You can also uninstall the software and download the latest eMeetLink software on the official EMEET website.
- 3. After renaming the device, the updated device name is not displayed.**
Click [Save] and [Confirm] the device name.
- 4. eMeetLink is unavailable.**
Please check if your device is connected to the computer via USB.


At the bottom of the page, there is a link that says 'Still have questions?'.

3. User manual


Click the device to enter EMEET official website and get the user manual.



4. Compatible device



5. Contact info



Feedback **FAQs** **User Manual** **Compatible device** **Contact**

Telephone

+1 888 959 5320 Mon-Fri 9:00am - 5:00pm (EST)
+81 8008051955 月-金 10:00am - 6:00pm (JST)
400 8338 051 周一-周五 9:00am - 5:00pm (BJT)

Official website

<https://www.emeet.com>

E-mail

Support: support@emeet.com
Marketing: marketing@emeet.com
Sales: sales@emeet.com