


bodywand™


Rechargeable

POWERING UP THE MASSAGER

1. Plug the charging cable into the charging port at the side of the massager.




2. Plug the charger into wall power source. Charging light will turn blue to indicate charging. Light will turn off when charge is complete.




USING THE MASSAGER

1. Power on the massager by turning the dial at the center of the massager in a downwards direction.



2. Continue rolling the dial to increase the vibration power.
3. To decrease the vibration power or turn off the massager, roll the dial in an upward direction.
4. Press the side button 1x to change the pulsation mode. Your wand has 8 total modes.

Vibration Levels:



- By fast double clicking the side button you will move to the previous vibration mode.
- Holding down the side button for 2 seconds will return the massager to steady vibration (no pattern).

WARNING: For adult use only. For external use only. Remove all scarves, neckties, necklaces, and jewelry before using this massager.

IMPORTANT: Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increase risk of developing blood clots, or who has pins/screws/artificial joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

CARE AND MAINTENANCE: Clean the massager with a soft, damp cloth. DO NOT fully submerge or clean with an alcohol or chemical-based cleaner.

SPECIFICATIONS:

- Power - 100~240V (AC power)
- Out put - 3~4.5W
- Weight - 0.76 lb / 0.345 kgs
- Vibration: 4000~7000 rpm

DISCLAIMER:

BODYWAND AND ITS AFFILIATED COMPANIES SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE MISUSE OF THIS PRODUCT.

Generation Products™
Horsham, PA 19044
All Rights Reserved



This product is CE certified.
CE2200