


USA

bodywand™

Original Massager


POWERING UP THE MASSAGER

Plug the power plug into the power socket.



USING THE MASSAGER

1. Power on the massager by turning the dial at the center of the massager in a downwards direction.



2. Continue rolling the dial to increase the vibration power.
3. To decrease the vibration power or turn off the massager, roll the dial in an upward direction.

WARNING:

For adult use only. For external use only. Remove all scarves, neckties, necklaces, and jewelry before using this massager.