
body wand™

Midnight Massager


POWERING UP THE MASSAGER

Plug the power plug into the power socket.



USING THE MASSAGER

 Power on the massager by turning the dial at the center of the massager in a downwards direction.



- 2. Continue rolling the dial to increase the vibration power.
- 3. To decrease the vibration power or turn off the massager, roll the dial in a upward direction.

body wand

Midnight Massager

WARNING: For adult use only. For external use only. Remove all scarves, neckties, necklaces, and jewelry before using this massager.

IMPORTANT: Any individual who may be pregnant, has a pacemaker, suffers from diabetes, phlebitis and/or thrombosis, is at an increase risk of developing blood clots, or who has pins/screws/artifical joints or other medical devices implanted in his/her body should consult with a physician before using a massaging device designed for home use.

CARE AND MAINTENANCE

Clean the massager with a soft, damp cloth. DO NOT fully submerge or clean with an alcohol or chemical-based cleaner.


SPECIFICATIONS:

- Power 100~240V (AC power)
- Weight 0.662 lb / 0.3 kgs
- Vibration: Low/High 8000 rpm

DISCLAIMER:

BODYWAND SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE MISUSE OF THIS PRODUCT.

Generation Products™ Horsham, PA 19044 All Rights Reserved



This product is CE certified. CE2200