




User Manual for Key Safe


Read all instructions before using this safe.

WARNING

- Test registered pin code a few times before closing the safe door.
- Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the safe, gaining full access to the safe and its contents.
- Store emergency keys in a secure place; NOT inside of the safe.
- To maximize security and performance of the safe, test pin code every 6 months.
- Test and make sure the safe works properly before mounting. Once tested, mount the safe before use.



- A. Handle
- B. Key Access
- C. Indicator Lights
- D. Key Pad
- E. Key Drop Slot
- Located on the side of the safe



GETTING STARTED

Remove emergency keys and other included accessories from packaging.

KEY ACCESS

1. To expose the key access, gently lift off the key cover
2. Use emergency key and insert into key hole, turn key counter clockwise and turn handle clockwise.

BATTERY

Battery compartment is located on the inside of the door safe.

1. Remove battery compartment cover.
2. Insert four new AA alkaline batteries into the battery compartment and restore battery compartment cover.

Note: Do not mix new and old batteries

PIN CODE REGISTRATION

Safe retains only two 3-8 digit pin codes

1st Personal Pin Code

1. With safe open, press and release the initialization button located on the inside of the safe door. Yellow indicator light will be on.
2. On the key pad input your 3-8 digit pin code and press and release either "A" or "B" to confirm. Yellow indicator light will turn off.

2nd Personal Pin Code

1. On the keypad press "00" then press and release the initialization button located inside of the safe door. Yellow indicator light will be on.
2. On the key pad input your 3-8 digit pin code and press and release either "A" or "B" to confirm. Yellow indicator light will turn off.

TESTING REGISTERED PIN CODES

1. With safe door open, and the handle/lock knob in the lock position. Enter in 1st personal pin code on the key pad and press and release either "A" or "B" to confirm.

Successful Save

- You will hear 2 short beeps
- The green indicator light will flash
- Move handle to the right to retract bolts

Unsuccessful Save

- You will hear 3 short beeps
- Handle will not move and bolts will stay extended
- Repeat steps CREATING PERSONAL PIN CODES

2. To test 2nd personal pin code, enter in 2nd personal pin code on the key pad and press and release either "A" or "B" to confirm. See "Successful Save" and "Unsuccessful Save" above
3. Test a pin code that is not registered to make sure the safe does not open to complete testing process

OPENING & CLOSING SAFE WITH PERSONAL PIN CODES

OPEN:

1. On the key pad enter in either of your 3-8 digit pin codes and press and release either "A" or "B" to confirm.
2. Turn the handle/lock knob to the unlock position and pull the safe door open

NOTE

After entering pin, you have 5 seconds to turn the knob before the mechanism re-locks automatically

CLOSE:

To close safe, close door and turn knob to the lock position

LOCK OUT

When the wrong pin code is entered 3 consecutive times lock out mode will activate for 5 min; safe cannot be used during this time; please wait or open with emergency keys.

CHANGING PERSONAL PIN CODES

Follow steps in "PIN CODE REGISTRATION"

LOW BATTERY WARNING

After entering correct personal code and the green and red indicator lights are flashing this indicates that the batteries are low. Follow steps in "BATTERIES"

NOTE

Safe may still be opened in low battery state depending on battery voltage. If safe cannot be opened please use emergency key. All registered pin codes remain stored

MOUNTING INSTRUCTIONS

The safe may be mounted to a wall. Be aware of the load bearing. Failure to do so can result in personal injury and/or damage to property. Use appropriate tools when performing work and always use eye protection.

- Do not mount the safe without anchoring to the wall.
- Find the studs in the wall, at your desired location. Most studs are 16 inches or 24 inches apart.
- Check the wall for concealed wires or pipes.
- Measure the location of the pre-set drill holes; mark their exact position onto the wall ensuring that the studs or anything else behind will not interfere.
- Drill the appropriate size holes for the anchors you are using.
- Carefully press the anchor into the holes at this time.
- Mount the safe by running screws from inside of the safe and securing to anchors; ensure the safe is mounted securely.

CARE AND MAINTENANCE

- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock.
- Secure safe in a proper area to prevent from falling and causing damage or injury.
- DO NOT disassemble the product. For all repairs, contact BARSKA Customer Service.
- DO NOT use chemicals or cleaning agents to clean the safe.
- DO NOT over stuff the contents of the safe, it can damage the motor mechanism or the contents
- DO NOT place emergency keys inside of safe



1 YEAR LIMITED WARRANTY

SAFE

BARSKA warrants this new safe to be free of original defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is received by purchaser. This warranty does not include damage caused by improper installation or maintenance. Damage from misuse, abuse, accident (such as dropping), normal wear and tear, fire, flood, or acts of nature. Damage from service or repairs other than those performed by BARSKA. Labor, cost and shipping charges for the removal and replacement of defective parts beyond the initial twelve-month warranty period. All transportation and shipping charges. Removing or altering the seal under any circumstances will automatically void the warranty.

This warranty is limited to original purchaser and is not transferable. This warranty applies only to products purchased in the United States.

Please email info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. The RMA number must appear on the outside of the shipping package. Product must be packed carefully and sturdily in its original packaging to prevent damage in transit and returned freight pre-paid to:

BARSKA OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect.
4. A Check/Money Order to cover inspection, shipping and handling. Charges are as follows
\$70 - Large
\$40 - Standard

BARSKA will examine and test returned product and repair or replace defective part(s) or units with new part(s) or a new unit if necessary within the warranty period. Purchaser is required to remit amount above to BARSKA for return shipping and handling at time product is returned. If repair is required after warranty period expiration, purchaser will be charged for replacement parts and return shipping.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.