



WARRANTY

ONE YEAR WARRANTY

All Hayman Safe Company products carry a warranty to the original retail purchaser to be free from defects in material and workmanship. Standard models are warranted for ONE (1) year from the original date of purchase.

This warranty applies only to new safes purchased from Hayman Safe Company or its authorized dealers. Proof of purchase must be provided so as to establish date of purchase and supplying dealer.

Hayman Safe Company will, at our option, repair or replace any defective part or unit.

Authorization must be received from Hayman Safe Company prior to performance of any service which will be submitted under warranty.

Improper installation, improper use, lack of proper maintenance or accidental damage will nullify this warranty. No other warranty, expressed or implied, is offered. This warranty cannot be changed, modified, enlarged or altered without direct written consent from Hayman Safe Company.

Hayman Safe Company is not responsible for consequential damage, incidental expenses or personal injury.

This warranty gives you specific legal rights.

You may have other rights which vary from state to state.

GUARANTEE

BURGLARY PROTECTION

Hayman Safe Company will, at our option, replace or repair any BlueRidge if they are ever successfully burglarized.

To claim this guarantee, ship the burglarized safe and a copy of the police report to us. We will repair or replace the safe and return it to you.

Improper installation can nullify this guarantee.

FIRE PROTECTION

Hayman Safe Company will, at our option, replace or repair any BlueRidge if its contents are ever damaged by fire.

To claim this guarantee, ship the fire damaged safe and a copy of the fire department report to us.

We will repair or replace the safe and return it to you.

Improper installation can nullify this guarantee.



BlueRidge

SAFE OPERATION GUIDE



BlueRidge Key Features:

- UL RSC Labeled for Burglary
- ¼" Solid Steel Door with Heavy Duty Hinge
- 90 Minute Fire Protection at 1200°
- Premium Fabric Lined Interior & Mirror Back
- Auto activated LED Lighting
- 1.5" dia 3 Way Active Bolt work
- 110VAC & USB Power Ports

BlueRidge

MECHANICAL SAFE LOCK OPERATING INSTRUCTIONS:

1. Turn the dial counterclockwise (to the left) until the first number of your combination aligns with the 12 o'clock opening index 4 times, be sure to stop on the first number of your combination the fourth time.
2. Turn the dial clockwise (to the right) until the second number of your combination aligns with the 12 o'clock opening index 3 times, be sure to stop on the second number of your combination the third time.
3. Turn the dial counterclockwise (to the left) until the third number of your combination aligns with the 12 o'clock opening index 2 times, be sure to stop on the third number of your combination the second time.
4. Turn the dial clockwise (to the right) until the dial comes to a complete stop, and then turn the safe handle to gain access.
5. Locking your safe; Close the safe door and then spin the safe dial to the left at least 4 full turns.

If you do not successfully gain access repeat steps 1-4.

BlueRidge

ELECTRONIC SAFE LOCK OPERATING INSTRUCTIONS:

Note:

*SecuRAM SafeLogic Locks have two factory default codes.

A Master Code of 111111 and a user code of 123456 are programmed into each lock. Both factory default codes will open the safe and **must** be changed before using your new safe.

To open your electronic lock, enter your 6 digit master or user code. The lock will beep twice indicating a correct code and the door can be opened.

If a wrong code is entered, the lock will beep three times indicating a wrong code. If a wrong code is entered four times in a row, the lock will go into timeout mode for 5 minutes.

Wait for the timeout mode to expire and enter the correct code.

To change the Master or user code on the lock:

1. Write down your new code.
2. Open the door with the existing Master or user code and extend the bolts. Perform all lock service with the door open.
3. Enter 000000 (lock beeps twice).
4. Enter the existing Master or user code you wish to change (lock beeps twice).
5. Enter new code (lock beeps once).
6. Enter new code again to verify (lock beeps once).

Test the operation of the new code twice before closing the door.

Lastly, test the operation of the new code with the door closed.

For more detailed information on your SecuRAM SafeLogic lock visit www.securamsys.com.

Or for more information on these locks such as changing the batteries visit YouTube and go to the HAYMAN Safe Co Network.

ACCESSORY OPERATION

Be sure to place the adjustable shelves and items in the pockets of the door organizer such that they do not interfere with each other.

Note that there is an access port at the back of the safe for 110vac/USB power cord. Also you will find a jack for the LED light power supply to plug into on the lower right side of the safe.

Use only **FRESH** Duracell or Eveready 9V Alkaline Batteries in the lock keypad.

BOLT DOWN INSTRUCTIONS:

Steps:

1. Place the safe in the location desired.

Note that it is desirable to have at least 16" clearance to the wall on the back and sides.

2. Mark the floor at the two front corners of the safe.

This will help in relocating the safe after drilling the mount holes in the floor.

3. From inside the safe, mark the floor through the mount holes in the bottom of the safe.
4. Move the safe to the side and drill the floor at the marks with the masonry drill bit. Be sure to drill the holes deeper than the length of the anchors.
5. Vacuum the concrete dust out of and from around the holes in the floor.
6. Move the safe back into position using the corner marks to help align the safe.
7. Insert the anchor through the safe floor and into the concrete floor until the washer touches the safe floor, and then tighten the nuts from inside the safe.
8. Tighten first to a barely snug level on each bolt before tightening up all bolts evenly.

Tools You Will Need:

- Drill Motor
- Anchors
- Masonry Drill Bit
- Wrench to fit nuts on anchors
- Marker to mark the floor
- Vacuum