


User Guide

Steel Security Box




Models 5605, 5605B, 5605P,
5605W / 5605G, 5605GB,
5605GP, 5605GW, 815605

Package Includes


- 1 - Steel Security Box
- 1 - Operation Manual
- 2 - Override Access Keys



1 Steel Security Box



1 Operation
Manual



2 - Override
Access Keys

Please carefully check the above list to confirm all items have been received. If any items are missing, please contact Consumer Assistance. (see page 6 for contact information).

Read this manual carefully and never store inside the safe!

INDEX

WELCOME / PACKAGE CONTENTS	PAGE 1
OVERRIDE ACCESS KEY / INSTALL BATTERIES.....	PAGE 2
TESTING DIGITAL LOCK / PROGRAMMING NEW USER CODE...	PAGE 3
TESTING NEW USER CODE / SECURE LOCKOUT.....	PAGE 4
PERIOD / LOST OR FORGOTTEN USER CODES	PAGE 4
CARE AND MAINTENANCE.....	PAGE 4
ANCHORING YOUR SAFE.....	PAGE 5
CONSUMER ASSISTANCE.....	PAGE 6
ORDERING ADDITIONAL OVERRIDE ACCESS KEYS.....	PAGE 7
SAFE IDENTIFICATION RECORD / DIGITAL USER CODE	PAGE 7
RECORD.....	PAGE 7

For Your Protection

- Do not remove the Serial Number tag from the safe.
- Never Store Override Access Keys inside safe.
- Record all Safe Identification Numbers on Safe Identification Record (page 7).
- Save this manual and NEVER keep it inside the safe.

WELCOME


Your Honeywell Steel Security Safe will provide years of safe and secure protection for your valuables, important documents and other personal items. All Honeywell safes are designed and built using the highest manufacturing standards to ensure maximum user satisfaction under a variety of conditions. With proper care, your Honeywell safe will provide “Peace of Mind” for many years to come.

Thank you and enjoy!

PACKAGE CONTENTS

The following list outlines the items and quantities of each included with your new safe. Please carefully check the list to confirm all items have been received. If any item is missing, please contact Consumer Assistance (See page 6 for contact information).

Operation Manual (1 ea.)
Override Access Keys (2 ea.)
Mounting Hardware (1 set)



Attention: DO NOT RETURN SAFE TO STORE

If you are missing parts or have difficulty operating your safe, please contact our Consumer Assistance Department by telephone. Store will not accept returned products without prior authorization. You must first contact our consumer assistance department. (See page 6 for contact information)

VERRIDE ACCESS KEY

Your safe is equipped with an override access key which allows immediate access in case you forget your user codes or the batteries need to be installed or replaced.

1. Remove override key cover with small screwdriver (Figure 1).
2. Insert the override access key into the lock until it stops (Figure 2).
3. With the key inserted turn counter clockwise to the left (Figure 3).
4. Turn knob clockwise to the right and pull safe door open (Figure 4).




Figure 1



Figure 2




Figure 3




Figure 4

5. Remove override access key and store it in a safe place away from the safe. Replace the cover over the key lock and proceed to "Install Batteries".

INSTALL BATTERIES

The batteries must be installed before using your safe. The battery compartment is located inside the safe on the lock cover panel.

1. Remove battery compartment cover and insert 4 "AA" batteries. Make sure that the batteries are installed in the correct direction with regard to polarity (+ and -). (Figure 1 & Figure 2).
2. Replace the battery cover (Figure 3).
3. Proceed to the "Testing Digital Lock" section on next page.




Figure 1




Figure 2




Figure 3

Note:

If both green and red LED's are on, it is an indicator that the batteries are weak and must be changed immediately. The User Code will not be erased if power is restored by replacing the batteries within 30 minutes. After 30 minutes, the User Code will be erased and will need to be reprogrammed. Weak or dead batteries should be replaced immediately and all 4 batteries should be changed. To replace the batteries please follow STEPS 1 - 3. Remember to always remove batteries from safe if not using for an extended period of time. If your batteries are completely dead and you cannot open the safe by using the digital keypad, use the override access key to open safe and access the battery compartment. The use of Non-alkaline or rechargeable batteries is NOT RECOMMENDED.

TESTING DIGITAL LOCK

1. Push the safe door to the closed position and turn the knob counter clockwise to the left (Figure 1).
2. Enter the preset primary factory code "1 5 9" followed by "#" key into the keypad. If the correct code is entered, the green LED will light up (Figure 2).
3. The knob can then be turned clockwise to the right to open (Figure 3).
NOTE: You have approximately 5 seconds to open the safe. If you wait any longer, the safe will re-lock and you must re-enter the code to open the safe.
4. To lock, close safe door and turn knob counter clockwise to the left (Figure 4).




Figure 1




Figure 2




Figure 3




Figure 4

PROGRAMMING NEW USER CODE

1. Open door using the factory preset code of 159 followed by the "#" key (Figure 1).
2. Access the red reset button located on the inside of the door near the battery compartment. Press the red reset button and the yellow LED will light up (Figure 2).
3. Enter a new 3-8 digit Primary user code followed by the "#" key. Press "*" to clear entry if wrong digit is entered (Figure 3).
4. Safe will beep and yellow light will turn off (Figure 4).
5. You can now close and lock the safe door and your new User Code is now active.

NOTE: The factory pre-set code will not work after a new pass code is programmed.




Figure 1




Figure 2




Figure 3




Figure 4

TESTING NEW USER CODE

1. Push the safe door to the closed position and turn the knob counter clockwise to the left (Figure 1).
2. Enter the new User Code followed by “#” key into the keypad. If the correct code is entered, the green LED will light up (Figure 2).
3. The knob can then be turned clockwise to the right to open (Figure 3).
NOTE: You have approximately 5 seconds to open the safe. If you wait any longer, the safe will re-lock and you must re-enter the code to open the safe.
4. To lock, close safe door and turn knob counter clockwise to the left (Figure 4).




Figure 1




Figure 2




Figure 3




Figure 4

SECURE LOCKOUT PERIOD

If a wrong code is entered three times in a row, the digital keypad will begin a five-minute secure lockout period. During this secure lockout period the keypad will become disabled. Once the lockout period has expired, the safe can be unlocked using the correct passcode. You may use the override key to open safe, but keypad will complete the full lockout period.

LOST OR FORGOTTEN USER CODES

If the user code is lost or forgotten, you may open the safe using the Override Access key and use the red reset button to reprogram the 3-8 digit user code. The instructions for opening the safe with the override access key are located on page 2.

CARE AND MAINTENANCE

When properly maintained, your safe will continue to operate for many years. In order to ensure optimum performance of your safe, please follow these simple precautions:

CLEAN HANDS – Never attempt to operate the digital keypad if your hands have excessive dirt, debris or liquids on them.

CLEAN SAFE – To clean the surface of your safe, it is recommended that you use a mild cleaner (e.g., window cleaner) to avoid scratching or discoloring the surface. Always wipe dry and NEVER use abrasive cleansers on the safe or digital keypad.

For future reference, store this Operation and Installation Guide in a secure area away from the safe.

DO NOT DISCARD!

ANCHORING YOUR SAFE

You may bolt your safe to the wall or floor for added theft protection and resistance to tipping. Your safe has pre-drilled bolt-down holes in the back panel and in the floor.

To secure your safe to the wall and/or floor:

1. Select a suitable and convenient location for your safe.
2. Empty the safe and remove the carpet.
3. Locate the predrilled holes on the inside of safe.
4. Place your safe in the desired location.
5. Line up the predrilled holes and mark the floor or wall through the holes (Figure 1).
NOTE: It is not recommended to attempt to bolt to both floor and wall.
6. Move the safe aside to clear marked spots for drilling.
7. Drill holes appropriate for hardware being used and the mounting surface (Figure 2).
INCLUDED: (2 each – bolts, washers and masonry anchors).
8. Place the safe back over the holes and install the fasteners as required (Figure 3).
9. Once completed, replace the carpet.

NOTE: Bolting/unbolting of the unit is at the consumer's expense and discretion. LH Licensed Products is not responsible for any costs incurred if the unit is to be replaced.

If you have any questions about mounting the safe, please check with your local home center/hardware retailer or independent contractor.




Figure 1




Figure 2





Figure 3



ORDERING ADDITIONAL OVERRIDE ACCESS KEYS

The following information is required to order keys:

1. PROOF OF OWNERSHIP (1 of 2 Options Below)

A) SALES RECEIPT & IDENTIFICATION – INTERNATIONAL ORDERS ONLY!

- Copy of sales receipt showing Store, Date & Product Description.
- Copy of your picture I.D. (Drivers license, passport, regular I.D.).

B) PRODUCT OWNERSHIP VERIFICATION FORM

If sales receipt is not available, contact us by email or telephone to request a "Product Ownership Verification Form".

2. ORDER INFORMATION

CONTACT

- Name & Shipping Address
- E-mail address (If Available)
- Telephone Number
- Best Time to Contact You

PRODUCT

- Model #
- Serial #
- Lock Key #
- Quantity of Keys Ordered

3. PLACING AN ORDER

- To begin the order process, contact us by telephone, email, or mail

4. METHOD OF PAYMENT

- Visa, MasterCard, Check or Money Order

NOTE: For pricing please contact Consumer Assistance. Payment method and pricing subject to change.

SAFE IDENTIFICATION RECORD

Model Number: _____

Serial Number: _____

Override Access Key Number: _____

DIGITAL USER CODE RECORD

User Code: _____