




MINI OVAL REBOUNDER TRAMPOLINE ASSEMBLY MANUAL



For Models:
UBSF01-3856-BT
UBSF01-3856-BR

2 Mill St. Cornwall NY 12518
1-888-965-3331 • www.machrus.com

MACHRUS
LET'S GO OUT AND PLAY!

MACHRUS

LET'S GO OUT AND PLAY!

US



Call us

UK

1-888-965-3331

020-3150-0484



Email us

support@machrus.com

support@machrus.co.uk



Check out our website

www.machrus.com

THANK YOU FOR PURCHASING THIS BOUNCE GALAXY TRAMPOLINE

Simply follow the assembly and safety instructions in this manual and you will soon be starting your MACHRUS exercise program and be on your way to a happier, healthier lifestyle.

Should you have any questions, please call our Customer Service Department.

1-888-965-3331

MONDAY - THURSDAY

9:30 A.M. - 5:00 P.M.

Eastern Time.

FRIDAY

9:00 A.M. - 12:00 P.M.

Eastern Time.

WARNINGS


Please read these warnings and the information in this manual in its entirety.

Failure to comply with the following instructions may increase the risk of serious injury.

This unit is designed for jogging in place and similar bouncing exercises.

- Maximum weight limit: 220lbs. (100kgs)
- Kids should always be supervised by an adult when using this trampoline. Do not leave children unattended at any time.
- Do not place this trampoline directly underneath light fixtures or ceiling fans.
- When not assembled, this trampoline contains small parts, which are a choking hazard for children under the age of 3 years.
- Immediately discontinue use if any breakage to the frame assembly or springs are found. Failure to do this may result injury and/or further damage to the product.
- This trampoline is only designed for normal residential use. It is NOT intended for commercial applications and/or in public areas.
- When in use, this trampoline must be placed at a safe distance from any vertical or horizontal obstructions, such as stairways/stairwells, power lines, ceiling fans, pools, walls, overhead or wall light fixture, windows, furniture, appliances etc. Keep on a level surface.
- DO NOT store trampoline outdoors or where exposed to moisture or extreme temperatures.
- Ensure area under and around trampoline is clear of any toys/obstacles that may cause injury.
- DO NOT wear glasses or helmets when using the trampoline.
- DO NOT store any toys or objects underneath the trampoline mat.
- To avoid injury, DO NOT fall or bounce on your knees.
- Keep infants and animals away from this trampoline at all times.
- DO NOT use or allow use of the trampoline under the influence of any substance or medication which may impair the supervisor's or jumper's judgment and/or coordination.
- Users should stand or bounce as near to the center of the mat as possible. Bouncing or standing near the edge of the trampoline could cause the frame to tip over or damage the mat/springs.
- ALWAYS wear socks when using the trampoline
- NEVER wear footwear (e.g. shoes) when using the trampoline.
- Before each use, inspect and replace any worn, defective or missing parts. It is important to check the trampoline to ensure the frame is steady and all parts are in good condition.
- Before each use, make sure the frame padding is in place with the springs and frame fully covered.
- ALWAYS make sure to store your trampoline safely, where it will not present a tripping or obstacle hazard.
- Dispose of all packaging materials safely and per local ordinance.
- This trampoline should be assembled by a capable adult.

PRODUCT PARTS DRAWING




PART NO.	PART DESCRIPTION	QTY. (PCS)	SKU #
A	Assembled Frame		
	• Mat	1	BGRP-3856-MAT-B
	• Mat	1	BGRP-3856-MAT-R
	• Spring	40	BGRP-3856-SPRING
	• Frame	1	BGRP-3856-FRAME-B
	• Frame	1	BGRP-3856-FRAME-O
B	Lower Handle Base	2	BGRP-3856-LHB-B
			BGRP-3856-LHB-O
C	Middle Handle Bar	2	BGRP-3856-MHB-B
			BGRP-3856-MHB-O
D	Upper Handle Bar	2	BGRP-3856-UHB-B
			BGRP-3856-UHB-O
E	Legs	8	BGRP-3856-LEG-B
			BGRP-3856-LEG-O
F	Metal Plate	2	BGRP-3856-MP-B
			BGRP-3856-MP-O
G	Center Base Tube	1	BGRP-3856-CB-B
			BGRP-3856-CB-O
H	Frame Cover	1	BGRP-3856-PAD-T
			BGRP-3856-PAD-B
I	Screw Driver	1	BGRP-3856-SD
J	Long Screw + Bolt Set	4	BGRP-3856-LSBS
K	Short Screw + Bolt Set	2	BGRP-3856-SSBS
L	Triangle Screws	2	BGRP-3856-TS
M	Wrench	1	BGRP-3856-WRENCH

ASSEMBLY STEPS


STEP 1

Before you unfold the frame, please make sure the screws in the side hinges are tightly mounted. Use the enclosed screw-driver (I) to tighten, if needed.




STEP 2

Unfold one side of the oval frame first, straighten the frame hinges and smooth out the mat/springs on the open side.




STEP 3


Repeat the process when opening the other side. Turn the frame upside-down (Bounce Galaxy logos facing down), straighten the frame hinges and smooth out the mat. Use your knees and body weight to ensure the frame is completely open & flat.




Note: Ensure that all the springs are attached before continuing to assemble the trampoline. If any spring is disconnected or damaged then follow this process:



Find the open end of the **SPRING ④** and hook this end into the hole on the **RAIL (1,2,3,4)**. Refer to illustration A.




Swing the **SPRING ④** to face inside of the trampoline. Refer to illustration B.



Slide the metal loop on the **MAT ②** into the spring hook as shown in illustration C.


**STEP
4**

Remove the frame coverings, and attach the legs (E) to the trampoline frame.




**STEP
5**

Flip the trampoline to stand on its legs. Place the frame cover over the trampoline and springs. Tie the attached cords to the trampoline frame for a tight and neat fitted look.




**STEP
6**

Remove the bottom plastic caps off the 2 center legs.




**STEP
7**


Attach the 2 lower handle bases (B) to both sides of the center base tube (G).



**STEP
8**


Attach the assembled lower base to the 2 center legs simultaneously. Push both sides of the frame firmly into place.






**STEP
9**

Replace the bottom plastic caps to the 2 inner-center legs.



**STEP
10**

Attach the sides of the lower handle bases to both sides of the frame with the metal plates (F) using the screw + bolt sets (J) with the screw driver (I) and wrench (M) as shown on this diagram.





**STEP
11**

Fasten the center base tube (G) on both sides using the short screw + bolt sets (K) with the screw driver (I) and wrench (M) as shown on this diagram.

**STEP
12**

Attached the 2 middle handle bars (C) to the 2 side bars using the triangle screws (L).





**STEP
13**

Assemble the 2 upper handle bars (D) as shown on this diagram.

**STEP
14**

Use the triangle screws (L) to attach the upper handle bar to the middle handle bars on both sides.



**STEP
15**

To avoid injury, please check each screw on the trampoline to make sure they are tightly and securely assembled.