QUICK START

CHARGING

- Attach the magnetic pins on the charging cord to the magnetic charging ports located on the side of the Swami Watch. Make sure the charging cradle snaps into place and is securely attached to the unit.
- Be sure the pins are aligned, then insert the other end of the charging cord into a USB port or AC adapter



BUTTON DIAGRAM

- A. [POWER] Power On/Off Backlight On/Off
- B. Magnetic Charging Ports
- C. [UP] Scroll Up
- D. [OK] Select Options, Hold to access Main Menu, Toggle Shot Distance & Scorecard while in Golf Mode
- E. [DOWN] Scroll Down



AT GOLF COURSE






Course List
Crooked_Pines_Golf_C
Perinton_Golf_&_Count
BLUE_HERON_HILLS
Greystone_Golf_Club
Cobblestone_Creek_Co

- From Time Screen, HOLD [OK] button to access Main Menu.
- 2. PRESS [OK] button to select Play Golf.
- Device will begin searching for satellite signal (HOLD [OK] button to cancel).
- Once satellite connection is established, the nearest golf courses will be listed. Use [UP/DOWN] buttons to scroll to desired course, PRESS [OK] button to select course.

DISPLAY DIAGRAM



- A. Distance to the Center of Green
- B. Distance to the **Back** of Green
- C. Distance to the **Front** of Green
- D. Distance to front and back of **Dogleg**
- E. Distance to layup or carry Water
- F. Distance to layup or carry **Bunker**

Note: To set the correct time, select Play Golf to connect to satellites (must be outside).