


LeCavist

Instruction Manual

BEVERAGE COOLER



www.lecavist.com

MODEL: LJBC238MN

CONGRATULATIONS

Congratulations and thank you for choosing LeCavist for your beverage storage solution.

This appliance complies with all relevant safety requirements in Australia. Inappropriate use can, however, lead to personal injury and damage to property.

In order to operate the unit correctly and safely, please read this instruction manual carefully before installation and use. This user manual which provides you with all required instructions related to safety, installation, use and maintenance of the appliance.

For future reference, please store this booklet in a safe place and ensure that all users are familiar with the contents. Pass them on to any future owner of the appliance.

Record Model & Serial Number

Model:.....
Serial Number

Register your product at www.lecavist.com



IMPORTANT

Adherence to the directions for use in this manual is extremely important for health and safety. Failure to strictly adhere to the requirements in this manual may result in personal injury, property damage and affect your ability to make a claim under the LeCavist manufacturer's warranty provided with your product. Products must be used, installed and operated in accordance with this manual. You may not be able to claim on the LeCavist manufacturer's warranty in the event that your product fault is due to failure to adhere this manual.

Correct Conditions of Use

- The appliance is intended for use in the home and similar environments only. It is not intended for commercial use.
- The appliance is not suitable for outdoor use, non-stationary installation.



Installation must comply with the valid standards, regulations and laws. All safety and warning information and the operating and installation instructions must be complied with.

TABLE OF CONTENTS

1. General Information	03
1.1 Appliance information	
2. General Safety Instructions	03
2.1 General safety information	
2.2 Safety instruction - Installation	
2.3 Correction use & Operation	04
2.4 Disassembling and Disposal of the Appliance	
2.5 Accessories and Spare parts	
3.Installation instruction	05
4.Temperature regulation	06
4.1 Routine maintenance and care instructions	
5.Equipment	07
5.1 The anti-vibration system	
5.2 The anti-UV system	
5.3 Defrosting	07
5.4 Shelves	
6.Food Storage Tips	08
7.Care and maintenance	08
7.1 In case of a power cut	
7.2 Moving your beverage cooler	
8. In the event of a breakdown	08
9. Troubleshooting guide	09
Replacing the light	
10.Environmental tips	10
10.1 Disposal considerations	
10.2 Disposing your old appliance	
10.3 Caution : Risk of fire	
11.Warranty and After sales	10
11.1 Warranty	
11.2 After sales service	
11.3 Replacement of spare parts	

Additional information on products, accessories, warranty, replacement parts and services can be found at www.lecavist.com

1. GENERAL INFORMATION

1.1 Appliance Information

- A damaged appliance can be dangerous. If you find the appliance is damaged or marked, you must report it within 7 days if you wish to claim for damage/marks under the manufacturer's warranty. This does not affect your statutory rights. Do not use a damaged appliance.
- The manufacturer's warranty will be invalidated if the appliance is not repaired by a LeCavist approved service technician.
- Faulty components must only be replaced by genuine LeCavist spare parts. The manufacturer can only guarantee the safety of the appliance when LeCavist replacement parts are used.
- If the power cord is damaged, it must only be replaced by a LeCavist authorised service technician or suitably qualified electrician in order to avoid a hazard.
- LeCavist cannot be held liable for non-compliance with these instructions, resulting from incorrect or improper use or operation.

2. GENERAL SAFETY INSTRUCTIONS

 The appliance complies with the stipulated safety requirements in Australia. The user is responsible for appliance cleaning and maintenance as well as its safe use. Improper use can lead to personal injury and damage to property.

2.1 General Safety Instructions

Children and People with Special Needs

WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- The appliance is NOT suitable for use by children without supervision.
- Young children should be supervised near the appliance to ensure they do not play with this appliance.
- Children may be able to wrap themselves in packing material or pull it over their heads with the risk of suffocation. Keep children away from any packing material.

Unauthorised Modifications

Unauthorised modifications can cause the appliance to pose risks. Do not conduct any modifications to the appliance.

Cleaning & Maintenance

The device must be cleaned regularly. Dirt can lead to damage or the build up of odours.

- Always clean the appliance exactly as indicated in the operating instructions.
- Always ensure the appliance is switched off before cleaning or replacing parts.
- There is a risk of fire if cleaning is not carried out as described in these operating instructions.
- Make sure no water penetrates inside the device when cleaning. Do not use a steam cleaning appliance to clean this appliance. The steam could reach electrical components and cause a short circuit.
- In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the machine and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the machine warranty.

2.2 Safety Instructions - Installation

- In order to avoid any potential hazard, the installation instructions must be followed.
- Observe all regional regulations for the installation of ventilation systems.
- During installation, maintenance and repair work, the appliance must be disconnected from the mains electricity supply. It is only completely isolated from the electricity supply when:
 - the mains circuit breaker is switched off, or
 - it is switched off at the wall socket and the plug is withdrawn from the socket.
- Do not damage the refrigerant circuit.
- After the beverage cooler is installed in place, the plug shall be easily accessible to facilitate the removal of the cooler plug in case of any accident.

- Do not pull the mains connection cable but the mains plug to disconnect your appliance from the mains electricity supply.
- Do not connect the appliance to the mains electricity supply by a multi-socket unit or an extension lead.
- Extension leads are a fire hazard and do not guarantee the required safety of the appliance.
- Tampering with electrical connections or components and mechanical parts is highly dangerous to the user and can cause operational faults. Only open the housing as described in the instructions given in "Installation" section of this booklet. Under no circumstances should any other parts of the housing be opened.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

- THIS APPLIANCE MUST BE PROPERLY EARTHED. It is most important that this basic safety requirement is present and tested regularly and, where there is any doubt, the household wiring system should be inspected

by a qualified electrician. LeCavist cannot be held liable for noncompliance with these instructions, resulting from incorrect or improper use or operation.

2.3 Correct use and Operation

- For safety reasons, this appliance may only be used after it has been installed.
- Reliable and safe operation of this appliance can only be assured if it has been connected to the main electricity supply.
- Before using the appliance, ensure that all packaging materials are removed from the appliance and make sure that the connection data on the data plate [voltage (V) and frequency (Hz)] indicated on the appliance corresponds to the voltage and frequency of the power supply in your household. Consult a qualified electrician if in doubt.
- DO NOT store or spray flammable materials in the appliance or near this appliance while it is in operation (e.g. aerosols).
- Prevent water ingress. Never sprinkle or flush the cooler using water, place the cooler in an area exposed to moisture water sprinkling, or fill the cooler with water, so as to avoid impairment of the electric insulation of the cooler. Furthermore, failing to follow such requirements may lead to electric shock and fire, or other accidents.

- After the cooler is put into operation, never touch its inner surface, especially when your hand is wet; otherwise the skin may stick onto the inner surface to get injured.
- Regularly clean surfaces that can come in contact with food and accessible drainage systems. If the refrigerating appliance is left empty for long periods, switch off, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Cracks, fissures or fractures in the panels can damage the underlying electronics. Switch off and disconnect the appliance immediately.



WARNING

The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged.

2.4 Disassembling and Disposal of the Appliance

(see the “Environmental Tips” section for best practices on disposing of this appliance).

The device must only be disassembled by trained specialists who are familiar with and comply with the standard national regulations and supplementary regulations of the local utility companies.

Work on electrical components must only be conducted by trained electrical personnel.

2.5 Accessories and Spare parts


Incorrect components can lead to personal injury or damage to the appliance. Only use original Lecepage spare parts for repairs.

Modifications, additions or alterations to the appliance can lead to safety risks. If spare parts or accessories from other manufacturers are used, the warranty will be invalidated, and Lecepage cannot accept liability.

Please check www.lecavist.com for more information.

3. INSTALLATION INSTRUCTIONS

Product model	LJBC238MN
Voltage/ frequency	220-240VAC, 50Hz
Refrigerant/ weight	R600a/35g
Volume	237L
Net weight	44kg
Unit dimension (WxDxH)	540×560×1405mm
Packing dimension (WxDxH)	580×600×1455mm



When selecting a location for your appliance you should make sure the floor is flat and firm, and the room is well ventilated. An average ambient temperature must be observed.

Before using this appliance

- Remove the exterior and interior packing.
- Before connecting the appliance to the power source, let it stand upright for approximately 24 hours. This will reduce the possibility of a malfunction in the cooling system from handling during transportation.
- Clean the interior surface with lukewarm water using a soft cloth.
- When disposing your appliance, please choose an authorized disposal site.
- Place your beverage cooler on a floor that is strong enough to support it when it is fully loaded. To level your beverage cooler, adjust the front leveling leg at the bottom of the beverage cooler.
- Adequate ventilation is required, do not block the front air outlet.
- This beverage cooler is designed for free-standing.
- Connect the cooler to a single socket, leaving a 30-mm gap between the back of the cooler and the wall. Be careful to support it, so that your beverage cooler is perfectly level (use of a spirit level is recommended). This will prevent any movement due to instability, causing noise and vibration, and will ensure that the door seals perfectly.
- This appliance is intended to be used exclusively for the storage of beverage.
- This appliance is using flammability refrigerant. So never damage the cooling pipe work during the transportation.

CAUTION


- Store beverage in sealed bottles.
- Do not overload the cabinet.
- Do not open the door unless necessary.
- Do not cover shelves with aluminum foil or any other shelf material which may prevent air circulation.
- Should the beverage cooler be left empty for long periods it is suggested that the appliance is unplugged, and after careful cleaning, leave the door ajar to allow air to circulate inside the cabinet in order to avoid possible condensation, mold or odors forming.

Ambient room temperature limits

- This appliance is designed to operate in ambient temperatures specified by its temperature class marked on the rating plate.
- The ambient temperature affects the interior temperature and humidity of your cooler. For optimal operation, the settings of your beverage cooler are carried out for ambient temperatures of 23°C to 25°C.

CLIMATE TYPE	DRY BULB TEMPERATURE	RELATIVE AIR HUMIDITY
0	20 °C	50%
1	16 °C	80%
2	22 °C	65%
3	25 °C	60%
4	30 °C	55%
5	40 °C	40%
6	27 °C	70%
7	35 °C	75%
8	24 °C	55%

4. TEMPERATURE REGULATION



Setting the temperature control

Since the temperature is nearly the same as the ambient temperature when the appliance operates for the first time. In generally, it takes 4 hours to enable the temperature inside to reach such one. which can stop motor running automatically. After working for 4 hours with the reference of the following instructions, adjust the temperature control to a suitable position and close the door, then the appliance can come to normal work. (Thermostat controls compressor to stop and start automatically.)

The first time you put your appliance into operation, set the thermostat to intermediate position "3" and let it run empty for 4 hours before storing drinks in it so that it is sufficiently cooled.

The thermostat goes from the warmest position "1" to the coldest position "7". Adjust the temperature as needed. The intermediate position "3" seems appropriate for indoor use (ambient temperature 25°C).

Appliance thermostat has 7 settings, position "7" on the thermostat shall decrease the internal temperature to the minimum level. The appliance assures that temperature is maintained as long as it is in operation and that it is used in normal conditions of use. The temperature inside the appliance can be influenced by many factors: ambient temperature, sun exposure, number of door 's opening and amount of beverages stored. The slight changes in temperature are perfectly normal.

Setting to 1-2: the temperature range of the interior of the beverage cooler is 13~15°C.


Setting to 3-4: the temperature range of the interior of the beverage cooler is 9~12°C.

Setting to 5-6: the temperature range of the interior of the beverage cooler is 2~8°C.

Setting to 7: the temperature range of the interior of the beverage cooler is 1°C.

4.1 Routine maintenance and care instructions

1. To develop the best performance of this machine and prolong its service life, it shall be serviced frequently. Before maintenance, the power line plug shall be removed and it shall be confirmed that the power supply has been cut off.
2. It is not allowed to remove the power line plug from the socket by pulling the cable.
3. The cooler inside shall be thoroughly cleaned every year. To clean the cooler, the plug shall be removed and the cooler shall be emptied. Then the cooler inside shall be cleaned using the wet soft cloth or sponge dipped with clean water or soap liquid (or any other non-corrosive neutral cleanser). It is not allowed to clean the cooler using the organic solvent, alkaline detergent, boiled water, washing powder or acid and the like.
4. In the humid environment or in the rainy weather, the cooler surface may be dewed, especially on the external surface of the glass door. This is caused due to the contact with the moisture in the air. In such a case, the surface can be dried using the dry cloth.
5. To ensure the normal operation of the cooler in a long period of time, the user should inspect the cooler on a regular basis; if any abnormality is found, the manufacturer shall be notified of the same immediately.
6. During cleaning operation, it is not allowed to use the water to flush the compressor compartment of the cooler. After cleaning operation, the cooler shall be wiped using the dry cloth to prevent rusting.



5. EQUIPMENT

5.1 The anti-vibration system

The refrigeration compressor is equipped with special dampers (silent-blocks) and the inner space is insulated from the body by a thick layer of polyurethane foam. These characteristics prevent the transmission of vibration to your beverage.

5.2 The anti-UV system

Light accelerates the ageing of beverage. In our solid door beverage cooler, your beverage are naturally protected, on condition, of course, that the door is not opened too often. This glass-door model has been specially treated and filters out harmful ultraviolet rays, thus ensuring your beverage are perfectly shielded.

5.3 Defrosting

- > Defrost the appliance if ice has developed inside of it. Otherwise, the cooling capacity of the appliance may be impaired.
- > To defrost the appliance, switch it off and unplug it. Remove all its contents.
- > Wait until the developed ice melts. Wipe the melting water up completely with a soft dry cloth.

5.4 Shelves

- > To prevent damage to the door seal, ensure that the door is fully open before pulling out the shelves to add or remove bottles.
- > For easier access to the contents of the shelves, slide the shelf out approximately one third of the way. The shelves are, however, fitted with a stop to prevent the bottles falling out.

6. FOOD STORAGE TIPS

- > Food should not be too tight inside the refrigerator to avoid obstructing the circulation of cold air and increasing energy consumption.
- > Food should be wrapped in plastic film to prevent water evaporation, which may cause dryness, mixed flavors, and water dripping from the shelves. Food that can be cleaned must be washed and stored after drying with water.
- > Pumpkin, radish, onion, banana, etc. do not require refrigeration.
- > Do not put items that are too large or heavy into the refrigerator to prevent the shelves from being crushed.
- > Do not put too hot food in the refrigerator, let them cool naturally before putting them in the fridge.

7. CARE AND MAINTENANCE

- > Before cleaning your appliance (something that should be done regularly), disconnect it by removing the plug or by pulling the fuse on the circuit.
- > Before using your appliance for the first time and regularly after that, we recommend that you clean the inside and outside (front, side and top) with warm mixed with a gentle cleaning product. Rinse with clean water and allow drying before reconnecting. Do not use solvents or abrasives. When the appliance is switched on for the first time, there may be a residual odor. In that case, run the appliance empty for a few hours at the coldest possible temperature. The cold will kill any odors.

7.1 In case of a power cut

- > Most power cuts are resolved within a short time. A power cut of 1 or 2 hours will not affect the temperature in your cabinet. To protect your drinks a power cut, avoid opening the door as much as possible.
- > During very long power cuts, take the necessary measures to protect your drinks. If the appliance is disconnected or if there is a power cut, you must wait three to five minutes before restarting. If you try to re-start before this time, the compressor will only re-start after 3 to 5 minutes (if the temperature requires).

7.2 Moving your beverage cooler

- Remove all items.
- > Securely tape down all loose items (shelves) inside your appliance.
 - > Turn the adjustable leg up to the base to avoid damage.
 - > Tape the door shut.
 - > Be sure the appliance stays secure in the upright position during transportation. Also protect outside of appliance with a blanket, or similar item.

8. IN THE EVENT OF A BREAKDOWN

Despite the care, we take during production, a breakdown can never be totally ruled out. Before contacting your retailer's after-sales department, please check that:

- > The appliance is properly plugged in.
- > There is not a power cut in progress.
- > The breakdown is not one of those described in the table at the end of this manual.

IMPORTANT: If the power cable supplied is damaged, it must be replaced by the manufacturer, a service centre approved by the brand or the retailer. In all events, it must be replaced by qualified personnel in order to avoid any risk of injury.

WARNING: Do not use electrical appliances inside the food/ice storage compartments unless they are of the type recommended by the manufacturer.

WARNING: The maximum loading of the shelves (25kg) must not be exceeded.


9. TROUBLESHOOTING GUIDE

You can solve many common Beverage Cooler problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
The appliance does not work	Power plug not connected to electrical outlet	Check the plug connecting it others appliance, or verify that the appliance is connected to the plug
	supply cord is damaged	Have supply cord replaced by the manufacturer, its service agent or similarly qualified persons.
The appliance doesn't cool enough	The door is too often opened or was left opened for a long time	Close the door and do not open it too much frequently
	Thermostat is not set correctly	Set temperatur with thermostat as described in this manual.
	Appliance is located near heat sources.	Move appliance well away from heat sources.
	Stored beverages or other objects prevent proper closing of door.	Remove several items,remove hot beverages or reorder contents of cooling compartment to allow air circulation.
	Cooling compartment overloaded, filled with hot beverages or filled in a way that prevents proper air circulation.	Remove several items, remove hot beverages or reorder contents of contents of cooling compartement to allow air circulation.
Appliance is very noisy	Back of appliance is placed too near to the wall or to other objects.	Keep a minimum distance of 30cm to wall or other objects
	Appliance not in a stable position.	Bring appliance into a stable position by adjusting its feet. Make sure that all feet are frmly on the ground.
Condensation on outside of appliance.	Normal phenomenon in hot and humid environments.	Wipe appliance with a dry and soft cloth.

Replacing the light

This appliance consists of light-emitting diodes (LEDs). This type of diode cannot be changed by the consumer. The lifetime of these LEDs is normally sufficient for no change to be made. If however, and despite all the care taken during the manufacture of your beverage cooler, the LEDs were defective, please contact your after-sales service for any intervention.



10. ENVIRONMENTAL TIPS

Observe all safety and warning information during operation (see the "General Safety Instructions" section).

10.1 Disposal considerations

The transport and protective packaging has been selected from materials which are environmentally friendly for disposal, and can normally be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.



10.3 Caution : Risk of fire

Do not use the appliance near explosive or flammable vapours.

Do not store any explosive or flammable substances, like benzene, liquid gas or glue, in the appliance.

If gas flows out of the appliance, do not pull the power plug from the outlet as this can cause sparks and fire.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

Warning: Risk of fire / flammable materials, take care to avoid causing a fire by igniting flammable material.

Warning: Blowing insulation gas.




10.2 Disposing of your old appliance

Electrical devices marked with this label may not be disposed of in domestic waste at the end of their service life.

Electrical and electronic appliances often contain valuable materials. They also contain specific materials, compounds and components, which were essential for their correct function and safety. These could be hazardous to human health and to the environment if disposed of with your domestic waste or if handled incorrectly. Please do not, therefore, dispose of your old appliance with your household waste.

Please dispose of those materials by contacting your local authorities and ask for the correct method of disposal. Please ensure that your old appliance poses no risk to children while being stored prior to disposal.

By disposing of this product in accordance with the regulations, you protect the environment and the health of those around you from negative consequences.



11. WARRANTY & AFTER SALES SERVICE

Observe all safety and warning information during operation (see the "General Safety Instructions" section).

In the event of a fault which you cannot remedy yourself, please contact LeCavist.

11.1 Warranty

The manufacturer's warranty for this appliance is 2 years.

11.2 After sales service

The contact details for LeCavist are given at the beginning and end of these instructions.

When contacting LeCavist, please quote the model and serial number of your appliance. These can be found on the data plate at the back of the Beverage Cooler.

Record model & serial number

Model:.....

Serial Number:.....

Register your product www.lecavist.com

11.3 Replacement of spare parts

Incorrect components can lead to personal injury or damage to the appliance. Use only genuine original Lecavist spare parts.

Modifications, additions or alterations to the appliance can lead to safety risks. If spare parts or accessories from other manufacturers are used, the warranty will be invalidated, and Lecavist cannot accept liability.

Please check www.lecavist.com for more information.

LIKE TO KNOW MORE?

For further information on all LeCavist products,
or to obtain detailed dimension and installation
information, phone or email our Customer Care
team or visit our website: **www.lecavist.com**

Operating and installation instructions:

Original

√ Translation

Osass Australia Pty Ltd.
ACN 005 635 398
ABN 96 005 635 398

The distribution and duplication of this document, as well as the use and disclosure of its contents are prohibited unless expressly authorised.

These operating and installation instructions have been drawn up with the greatest of care. But it cannot be ruled out that subsequent technical modifications have not yet been incorporated or the relevant content has not yet been adapted. Please accept our apologies in this eventuality. An updated version can be requested from our team. Subject to printing errors and mistakes.

© LeCavist

All rights reserved.
