


CALLAWAY *EZ* LASER RANGEFINDER

QUICK START

HOW TO USE

1. While holding the unit horizontal & looking through the **Eye Piece**, **PRESS & RELEASE** the **Power Button**. The rangefinder is now powered on.
2. To focus/increase clarity, use the **Diopter Adjustment** by turning the **Eye Piece**.
3. Continue looking through the **Eye Piece**, aim the **Zero-In Aiming Square** at your intended target & **PRESS** the **Power Button**. The laser will fire and the **Laser Indicator Box** will appear around the **Zero-In Aiming Square**. The measurement will be displayed at the top of the LCD display.
4. **Unit of Measure** - To change the unit of measure from Yards to Meters, first power the laser on. Next, **PRESS & HOLD** the **Mode Button** on top of the laser for 5 seconds.



The unit of measure is indicated by a “Y” or “M” shown directly to the right of the distance on the internal and external LCD display.

5. **Disabling Slope Measurement** - First, **PRESS** the **Power Button** to power the laser on. Next, **HOLD** the **Mode Button** for 3 seconds. The slope reading bars in the bottom right corner of the internal LCD display will disappear along with the “S” on the bottom right corner of the external LCD display. To enable slope again, repeat this process.

RANGEFINDER DIAGRAM


- A. Eye Piece
- B. Diopter Adjustment
- C. Power Button
- D. EZ Button
- E. Mode Button
- F. LCD Display
- G. Battery Door
- H. Support Strap



To view complete user manual visit: www.CallawayDMD.com/product-support

MEASUREMENT MODES

- 1. Standard** - Standard Mode is recommended when measuring distances to larger objects. To quickly range targets, **SINGLE PRESS** the **Power Button** for a single fire from the laser **or PRESS** and **HOLD** the **Power Button** to continuously fire the laser. (Fig. A)
- 2. P.A.T. (Pin Acquisition Technology)** - P.A.T. Mode is best used when measuring the distance to a flagstick or smaller objects. To toggle between Standard and P.A.T Mode, quickly **PRESS** the **Mode Button** once while the device is powered on. When P.A.T. Mode is activated, the **Flagstick Icon** will appear on the **Right Side** of the internal and external LCD display. (Fig. B)




- 3. EZ Mode:** This mode will continuously fire the laser for 3 seconds & the laser will lock on to the closest distance during the firing period. First, **PRESS** the **Power Button** once to power the unit on.

Then **PRESS & RELEASE** the **Red EZ Button** on top of the laser to start the 3 second firing period. During this time, move the laser in a back & forth motion across the flagstick to easily lock onto the pin.

LCD DISPLAY

- Zero-In Aiming Square
- Laser Indicator Box
- P.A.T. Mode Indicator
- Distance
- Unit of Measure
- Low Battery
- Slope Adjusted Distance



EXTERNAL LCD DISPLAY

- Distance
- Unit of Measure (Y or M)
- P.A.T. Mode Indicator
- Low Battery
- Slope Mode



To view complete user manual visit: www.CallawayDMD.com/product-support