

RANGEMART

RANGE TARGET ASSEMBLY INSTRUCTIONS



RANGEMART

PARTS

The Range Target consists of the following assembly parts:

- 1) Base (1)
- 2) Top Hoop with Net (1)
- 3) Back Legs (2)
- 4) Front Leg (1)
- 5) Tee-Insert (6)

WEIGHT

Target can be secured to ground with stakes, but you must drill holes through base. Or use dry playground sand (not included) if added weight is required. Use a funnel to pour into legs. If using sand, be sure to add sand before assembling the Top Hoop.

ASSEMBLY INSTRUCTIONS

- 1) The Base is the smaller circle that does not have a net attached. Lay on the ground or solid work surface.
- 2) Insert Back Legs first. The two Back Legs are longer than Front Leg. Insert Back Legs into Tee-Inserts located inside the Base. When inserting the Back Legs, the curvature of the legs should be curved away from the front as shown below. With a rubber mallet, gently tap the top of the leg to secure into Tee-Insert.



RANGEMART

- 3) After Back Legs are secure, insert Front Leg into Tee-Insert on base. The curvature of the leg should be placed as show above. Gently tap into place with rubber mallet.
- 4) Place the Top Hoop on top of Back Legs lining up the Hoop Tee-Inserts into the top of the Legs. Gently tap with a rubber mallet to secure the Top Hoop into the leg.



RANGEMART

- 5) After Back Legs are secure, line up Front Leg with Top Hoop and secure Front Leg with rubber mallet.



RANGE MART



WWW.RANGEMART.COM • 4142 ADAMS AVE SUITE 103217 • SAN DIEGO, CALIFORNIA 92116

GOLF@RANGEMART.COM • 877.741.2678