




ComfyBumpy


COMFY BUMPY BABY BOUNCER



**IMPORTANT! READ CAREFULLY AND
KEEP FOR FUTURE REFERENCE.**

SAFETY INSTRUCTIONS

- Do not use the product if any components are broken or missing
- **Powerful sway:** Make sure that older children are not allowed to rock the baby too forcefully
- **NEVER** leave baby unattended



Bouncer (Max 20 lbs/9 kg):

- Do not use the bouncer once your child can sit unaided
- Keep the toy out of the reach of children when it is not firmly attached to the product

WARNING

FALL HAZARD: Babies have suffered skull fractures falling while in and from bouncer

- Use bouncer **ONLY** on floor, dangerous to use on an elevated surface e.g. table
- Child's activity may move the bouncer
- **NEVER** lift or carry baby in bouncer or fitted toy bar

SUFFOCATION HAZARD: Babies have suffocated when bouncers tipped over on soft surfaces

- **NEVER** use on a bed, cushion or other soft surface
- **NEVER** leave baby unattended
- Child's activity may move the bouncer

To prevent falls and suffocation:

- **ALWAYS** use restraints. Adjust to fit snugly
- **STOP** using bouncer when baby starts trying to sit up or has reached 20lbs, whichever comes first.

Chair (Max 29lbs/13kg)

- Use as chair when your child can walk and sit on her own
- Do not use restraint system

WARNING

AMPUTATION HAZARD: Chair can fold or collapse if lock is not fully engaged

Moving Parts can amputate child's fingers

Keep fingers away from moving parts. Completely unfold chair and fully engage locks before allowing child to sit in chair. Never allow child to fold or unfold chair



IMPORTANT!

Before each use, inspect this product for damaged hardware, loose joints, missing parts or sharp edges. **DO NOT** use if any parts are missing or broken. Contact ComfyBumpy™ for replacement parts and instructions if needed. Never substitute parts

Please read these instructions before use of this product

Product features and decorations may vary from photographs

The Baby Bouncer by Comfy Bumpy

This bouncer has been ergonomically designed to provide your child with the correct head and back support required for the first years of their development

Until your baby had learned to sit up and walk on their own, use this product as a bouncer (minimum 8 lbs/3.5 kg)


When your child is at least 29lbs/13kg or approximately 2 years of age, the fabric can be turned around to create a ComfyBumpy chair

Please read the rest of this manual so that you can take advantage of the many great features of this bouncer


SWITCHING FROM BOUNCER TO CHAIR

Bouncer Mode - Bouncer (Max 20 lbs/9kg)

- Use setting until your baby can sit up without help
- Make sure to always use the safety belt and that both buttons are locked when in use



- Make sure that elastic straps are attached to the bottom plastic frame at all times



Switching From Bouncer To Chair - Chair (Max 29lbs/13kg)

Use this setting when your child can walk and sit on their own. Converting the bouncer into a chair is easy, simply turn the fabric around.

Step By Step:

1. Release the elastic straps from the bottom of the plastic base
2. Remove the fabric from the metal frame
3. Turn the fabric around (the opposite side of the safety belt) and place it on the metal frame



Note: To guarantee that the rubber strips underneath the bouncer are fixed to the floor, occasionally wipe with a damp cloth.

WASHING INSTRUCTIONS

TO WASH THE FABRIC

To wash the fabric seat, loosen the two elastic loops at the bottom and pull it off the frame. Wash separately, warm/40°C. Do not tumble-dry



TECHNICAL INFORMATION

Weight:
1.9 kg

Height/Length/Width:
Highest Position: 58 x 39 x 65 cm

Transport Mode:
39 x 89 x 10 cm

Fabric :
100% Polyester


Mesh:
100% Polyester



Do not use accessories or replacement parts other than those approved by the manufacturer

TRAVEL MODE

To fold the bouncer for travel or storage the positioner must be set to position A or B.
Pull back the safety latch and set the positioner to the transport mode, D




POSITIONS

Place the bouncer in front of you and fold the seat until you hear the click. You're done!

The bouncer has four positions, as summarized below:

Position A & B	Position C	Position D
Best used when the child can hold their head and back upright while in this position	Recommended for newborns	This mode when transporting the bouncer



TRAVEL MODE

When the product is used as a bouncer, the maximum weight is 20 lbs/9 kg according to European Standard EN12790:2009. We therefore recommend the following maximum weights per position:

A	Highest Position	Play	Up to 20 lbs/9 kg
B	Medium Position	Rest	Up to 20 lbs/9 kg
C	Lowest Position	Sleep	Up to 15.5 lbs/7 kg.
D	Transportation Mode	When the product is not being used.	

When the product is being used as a chair, we recommend the following maximum weights per position:

A	Highest Position	Play	Up to 29 lbs/13 kg
B	Medium Position	Rest	Up to 22 lbs/10 kg
C	Lowest Position	Sleep	Up to 15.5 lbs/7 kg.
D	Transportation Mode	When the product is not being used.	

This product is not a substitute for a crib. If your child requires sleep, they should be moved to a suitable place



ComfyBumpy

Thank You!

Give your baby a hug from all of us at ComfyBumpy. 😊

If there's anything we can help with, we will. Whether you are just having a tough day or you need help with a product, we love to hear from our customers

And hey, if you've got a cute photo of your little one in our products, we love receiving those too.

www.ComfyBumpy.com
info@comfybumpy.com

Comfybumpy Inc,
1321 Upland Dr., Suite 9871, Houston, TX 77043, US