

Fitness Mode

► Walk, Run & Cycling

Menu ► Fitness ► Walk, Run or Cycling



Select your fitness mode and G2 will search for GPS. Once it acquires satellite signals it will automatically start tracking your walk/run/cycling.



Speed Mode

Pace Mode

Press the Up button to change between Speed and Pace.

► Stop Watch

Menu ► Fitness ► Stop Watch



To start, pause and reset the stop watch, press the Select button.

Settings

► Date / Time

Menu ► Settings ► Date / Time



Use the Up/Down buttons to adjust and press the Select button to confirm.

► Tournament Mode

Menu ► Settings ► Tournament Mode



► Unit ► Golf or Fitness

Menu ► Settings ► Unit ► Golf or Fitness

Use the Up/Down buttons to adjust and press the Select button to confirm.



Distance in Golf Unit Selection



Distance in Fitness Unit Selection

Settings

► Weight

Menu ► Settings ► Unit ► Weight



To change between Kilograms and Pounds, press and hold the Down button. Use the Up/Down buttons to adjust weight.

► Scorecard

Settings ► Unit ► Scorecard



Use Up/Down button to adjust then press the Select button to choose.

► Language

Menu ► Settings ► Language

Use Up/Down button to adjust then press the Select button to choose.

► Device Info

Menu ► Settings ► Device Info

View current software version

Settings

► Demo

Menu ► Settings ► Device info ► Demo

You can check golf rounding demo screen indoors without GPS.

► Factory Reset

Menu ► Settings ► Device info ► Factory Reset

Reset all settings and history to the factory default.

► GPS Test

Menu ► Settings ► Device info ► GPS Test

Check the status of GPS signal.

✳ Reboot



If your G2 freeze, press and hold the **Menu** **Up** **Down** buttons all at the same time. It will reboot automatically.

Golf Mode

► Distance to the Green

When entering the Golf Mode, your G2 watch will search for GPS. Once it acquires the satellite signals, it will automatically recognize the course and hole you are on and display the remaining slope compensated distance (or straight line distance) to the green.



One Green

Two Green

Back of the Green: 371 yards
Center of the Green: 358 yards
Front of the Green: 346 yards

Back of the Green: 358 yards 370 yards
Center of the Green: 346 yards 358 yards
Front of the Green: 335 yards 345 yards

*The slope compensated distance and straight line distance are done automatically. When the slope compensated distance is applied, an icon is displayed in the upper left corner. The slope compensated distance is available only on golf courses where altitude data has been updated. Data availability can be checked at www.voicecaddie.com

*Tournament Mode : The tournament on/off function makes it easy to turn on/off the slope compensated distance function. The icon is not displayed when using in Tournament Mode.

Golf Mode

► Shot Distance

To begin measuring your shot distance, press the Shot button at your standing point. G2 will continuously display the distance from the starting point to your current location. To exit, press the Menu button.



Shot Distance : 249 yards.

► Manual Hole Selection

To manually select a hole, press the Up/Down buttons simultaneously.



*Hole Selection Press the Up/Down button

► Fitness in Golf Mode

Press and hold the Select button. The data is displayed while the button is held.



* Time Played: 3 hours 35 minutes
* Walked Distance: 2.87 miles
* Calories Burned: 897 calories

► Time in Golf Mode

Press and hold the Menu button. The present time is displayed while the button is held.

► Light in the Golf Mode

Press and hold the Shot button.

Golf Mode

► Scorecard

G2 will automatically display scorecard if the "Auto-scoring" function is selected in Settings. After each hole, you may check and modify the score.



* Press and hold the Up button to manually display the scorecard. To return to the previous screen, press and hold the Select button.

► Exit Golf Mode

When exiting Golf Mode by pressing the Menu button, the score is displayed and, when the button is pressed, the screen returns to the Menu after checking the calories burned during round.



Getting Started

► History

Menu ► Scorecard

G2 displays the date, name of the golf course, score of your most recent round and calorie consumption.

*History stores up to 200 rounds.

► History Modification

Select a course you need to modify, then press the Up/Down button to adjust your score. Press the Select button to confirm. To return to the Menu screen, press the Menu button.

► History Deletion

Select a course you need to delete, then press and hold the Up button.



Getting Started

► Buttons and Main Screen



* Power On / Off: Press and hold the Power button for 5 seconds.

Getting Started

► Charging

This product can be charged only with the supplied charger.



► Update using VC Manager

1. Visit www.voicecaddie.com to download G2 VC manager.
2. Connect the device to a USB port on your computer using USB cradle.

Main Menu

Press the Menu button in Watch Mode. Use the Up/Down button to navigate between menus and press the Select button to choose.



► Golf Mode

Slope compensated distance (or straight line distance) to the front, center and back of the green, shot distance measurement, manual hole change, distance walked and calories consumed during your round, time elapsed during round, scorecard.



► Scorecard

Keeps score for current round and stores up to 200 rounds of golf played.

Main Menu



► Fitness Mode

Exercise time, speed, distance calculation, and calories burned during exercise

1. Walking/Running
2. Cycling
3. Stop Watch



► Settings

1. Date / Time
2. Unit
3. Scorecard
4. Language
5. Device information: Device info, Demo, Factory Reset, GPS test

Notes

1. The time required to capture GPS satellite signals while in golf or fitness mode may vary depending on the environment (weather, topography).
2. When the battery is fully charged, the Golf Mode is available for about 11 hours and the Watch Mode for about 30 days. The battery's usage time may be reduced during rounds in cold weather and in areas where satellite reception is poor.
3. It is recommended to turn power on once outside and ready to begin your round to increase product usage time.
4. Do not leave the product in vehicles in hot temperatures or humid places as damage may occur.
5. You can measure a more precise amount of calories burned by entering your weight correctly during exercise measurements.

Warranty Conditions

One Year Limited Warranty

Voice Caddie warrants this hardware product against defects in materials and workmanship for a period of one year from the date of original purchase. If a defect exists, at its option Voice Caddie will (1) repair the product at no charge, (2) exchange the product with a product that is new or like-new and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. Voice Caddie shall have no obligation to repair, replace or refund until the customer returns the defective product to Voice Caddie. This warranty does not apply : (1) to damage caused by accident, abuse, misuse, misapplication, or non-Voice Caddie products; (2) to damage caused by service performed by anyone who is not a Voice Caddie Authorized Service Provider; or (3) to a product or part that has been modified without the written permission of Voice Caddie. For more information on Voice Caddie's warranty and return policy, please visit www.Voicecaddie.com

Warranty Conditions

Product Name	Voice Caddie
Model Name	G2
Serial Number	
Date of Purchase	
Purchaser's Address	
Full Name	
Warranty Period	One year after the date of purchase. (Other components is 5 months)

Customer Center

Call: 1-888-939-3978
Email: Support@voicecaddie.com
Website: www.voicecaddie.com

voice caddie G2 User Manual

