


LOOPS




Quint

ULTRASONIC DIFFUSER LAMP


User Manual

Warning

- The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children being supervised not to play with the appliance.
- Appliance is only to be used with the power supply unit provided with the appliance.
- Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.
-  means: Clean the water tank every three days.
- Cleaning and user maintenance shall not be made by children without supervision.







Your Quint Diffuser Lamp

Welcome to your new Quint. Please read this manual before operating your Quint and keep it for future reference.



- Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
- Do not permit the area around the appliance to become damp or wet. If dampness occurs, turn the output of the appliance down. If the appliance output volume cannot be turned down, use the appliance intermittently.
- Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths to become damp.
- Unplug the appliance during filling and cleaning.
- Never leave water in the reservoir when the appliance is not in use.
- Empty and clean the appliance before storage.
- Clean the appliance before next use.

Getting Started


- Remove the cover. 
- Remove the inner lid. 
- Fill the water tank to or below MAX water mark level. 
 - Never fill water exceeding its maximum water mark level. Otherwise mist will not be generated properly.
 - Never add water around air vent.
- Add 5-10 drops of natural essential oil into the water tank. 
 - Be sure to use extract pure essential oils 100% from natural ingredients. To avoid damage to this device, NEVER use artificially produced synthetic perfume.
- Cover the inner lid and the glass cover. 
- Plug the head of power adaptor into the power jack at the bottom of base and plug the power adaptor into the wall socket. 

Mist and Timer Setting

Timer Setting




1st click	*
always on mist	*
2nd click	*
1 hour mist	○
3rd click	○
3 hour mist	*
4th click	○
8 hour mist	*
5th click	○
turn off mist	○

Mist Mode Setting

- To switch between 2 mist mode, please press switch for 2 seconds until indicator blinks:
-  Press for 2s
- Intermittent mist (30 sec.on/30 sec.off) ↔ Continuous mist

Note: Timer is not interrupted whenever mist mode is changed. The Mist Mode will be restored to Continuous Mode when the power of unit is disconnected.

Light Switch and Dimming

- Rotate the button clockwise to turn ON the lamp and increase brightness. Rotate the button anticlockwise to decrease brightness and turn OFF the lamp.
-  Turn ON/OFF Lamp
-  Activate Sleep Helper
- Sleep Helper mode is lamp timer function tailored to turn off lamp gently in 30 minutes.
- To activate, push down the button and rotate it either clockwise or anticlockwise. 3 indicators will flash once one by one from top to bottom.
- To deactivate, push down the button and rotate it either clockwise or anticlockwise. 3 indicators will flash once one by one from bottom to top.
-  Deactive Sleep Helper

Note: Sleep Helper function is still active when brightness is adjusted even when the function is already activated. Once activated, Sleep Helper function remains, despite any other Timer Setting.

Disable Independent Lamp Mode


By default, Quint's lamp works completely independent of "Timer" and "Auto Shutoff" functions. However, you can still set the lamp to switch off together with mist when "Timer" or "Auto Shutoff" function is activated, if needed.

Disable Independent Night Light

To disable Independent Light, push the button for 6 seconds. All 3 indicators flash together after 2 seconds and keep the button pressed until "1H" and "3H" indicators blink alternately 3 times.

Enable Independent Night Light Again


To enable, please repeat the same operation until you see "3H" and "8H" indicators blink alternately 3 times.



Note: The lamp will be restored to Independent Mode when the power of unit is disconnected.

Important Points You Must Know

- When water tank is empty, mist function will not be turned on.
- Water temperature, room temperature or humidity can affect the amount of mist resulting in shorter operating time.
- Due to water temperature or water quality, the amount of mist can be less at the beginning.
- Fragrance results may vary depending on ventilation, temperature, humidity, and the size of space.
- NEVER empty the water from air vent side!



Maintenance

- The diffuser has an ultrasonic atomizer found in the center of water tank. Please clean the atomizer carefully using a cotton swab or a soft clean damp cloth at least once every week. You can clean the unit more often depends on your usage.
- NEVER apply aggressive force or sharp object during cleaning process. Otherwise, the misting function can be damaged.
- Please make sure to unplug the adapter from the power outlet when cleaning.
- Empty and clean the water tank when not in use. If necessary, please only use kitchen detergent when cleaning.




Accidental Leakage

In the event of the diffuser being knocked over or tipped during use, some water may get into the air vent. A drain hole at the base is designed to drain the water from the diffuser. Please follow below steps when there is leakage:

- Unplug the head of adaptor from diffuser.
- Remove the rest of water from water tank (avoid air vent side).
- Lean the product towards the direction of water drain hole and drain the water from the hole.
- Leave the product at a dry location for 24 hours.

Take below steps to avoid water leakage:

- Use measuring cup to add water.
- NEVER shake diffuser with water.
- DO NOT move diffuser with water.



Safety Precautions

- When the product is not in use for any extended periods of time, turn the unit off and remove the power supply.
- Always place the unit on a firm, flat surface. It is also recommend that you choose a surface that is protected from the possibility of water spills. Never place the device on carpet or flooring that can be damaged from coming into contact with moisture and wetness.
- DO NOT touch the unit if it has fallen into water. REMOVE POWER immediately.
- DO NOT place or drop the unit into water or any other liquid.
- Use the device only as described in this manual.
- NEVER drop, clog, or insert any objects into the opening.
- DO NOT Place the unit near any heat or combustible materials.
- ALWAYS keep the cord away from high temperature.
- NEVER USE outdoors. Your unit is rated for indoor use only.
- NEVER COVER the unit while it is operating.
- STOP using the product if the power cord or any parts of the unit are damaged.
- DO NOT attempt to repair or replace any parts in the unit.
- Should you notice an unusual sound or smell discontinue use immediately.
- Keep this unit out of reach of children.
- When the product is at the end of its life, we recommend disposal at a collection point for the recycling of electrical and electronic equipment, rather than with household waste.

Troubleshooting

Problem	Possible cause	Solutions
The mist function is not working.	Power supplier is not connected.	Plug the adapter into the power socket and press the mist button.
	Insufficient water.	Refill the water tank.
Mist function is not working effectively.	Too much water.	Dump the excess water until water level is below MAX line.
	Ultrasonic atomizer is clogged.	Clean the atomizer according to the instructions in this manual.
The mist ON indicator is on, the fan works, but no mist comes out.	Some objects or water beneath the diffuser are blocking the air going into the vent underneath the diffuser.	Remove the object(s) beneath the diffuser or clean the water underneath the diffuser.
	Water drip is blocking the air vent inside the water tank.	Remove the object(s) beneath the diffuser or clean the water underneath the diffuser.

Specifications

- Model: M20
- Atomization mode: Ultrasonic
- Water tank capacity: 280 ml (9.46 fl. oz.)
- Power input: DC 24V, 12W
- Mist Mode: Continuous / Intermittent
- Product Size: 148*148*125 mm (5.8"x5.8"x4.9")
- Light Mode: Dimmerable / Sleep Timer
- Timer Mode: 1H / 3H / 8H / ON
- Working Time: up to 12 hours - continuous mode
up to 24 hours - intermittent mode
- Accessories: Adaptor / Manual
- Made in China
- Patented Product

