## WARRANTY

Jackery Inc. warrants to the original consumer purchaser that the Jackery product will be free from defects in workmanship and material under normal consumer use during the applicable warranty period identified in the 'Warranty Period' section below, subject to the exclusions set forth below. This warranty statement sets forth Jackery's total and exclusive warranty obligation. We will not assume, nor authorize any person to assume for us, any other liability in connection with the sale of our products.

The warranty period is 24 months. In each case, the warranty period is measured starting on the date of purchase by the original consumer purchaser. The sales receipt from the first consumer purchase, or other reasonable documentary proof, is required in order to establish the start date of the warranty period.

### Remedy

Jackery will repair or replace (at Jackery's option) any Jackery product that fails to operate during the applicable warranty period due to defect in workmanship or material. If a valid claim is made during the applicable period, Jackery, at its option, will either (1) replace the product, or (2) exchange the product with a product that is of equal value. A replacement product assumes the remaining warranty of the original product or 180 days from the date of replacement, whichever is greater. Customer is responsible for the return shipping costs.

### **Limited to Original Consumer Buyer**

The warranty on Jackery's product is limited to the original consumer purchaser and to any subsequent owner.

Jackery's warranty does not apply to (i) any product that is misused, abused, modified, damaged by accident, or used for anything other than normal consumer use as authorized in Jackery's current product literature, or (ii) any product purchased through an online auction house. Jackery's warranty does not apply to the battery cell unless the battery cell is fully charged by you within seven days after you purchase the product and at least every 6 months thereafter.


### **How to Receive Service**

To obtain warranty service, contact our customer service team at hello@jackery.com

© Copyright 2012-2020 Jackery Inc. All trademarks cited herein are the property of their respective owners. The information contained herein is subject to change without notice. The only warranties for Jackery products and services are set forth in the warranty statements accompanying such products and services. Jackery shall not be liable for technical or editorial errors or omissions contained herein. First Edition: March 2020. Document Part Number: J550-UM-003. This user guide describes features that are common to most models.

### SPECIFICATIONS **DC Input** AC Output Car Port DC Output **USB Output** Capacity Weight Dimensions 2x 12V=7A 110V~4.54A, 60Hz. USB-A Output: 3 x 5V==2.4A 6.3kg / 13.8lbs 500W max continuous 25.5Ah/21.6V 11.8 x 7.6 x 9.5in (Support 12~30V) 1000W peak surge (2x DC Output+Car Port:Total 120W)

<b>A</b> Battery	 = LED Flashlight	Lifecycles	Operating Temperature	Recharging Temperature	Management System	MPPT	Warranty	Certifications	Technical Support
Lithium-ion	SOS LED	≥ 500	-10 ~ 40 °C (14 ~ 104 °F)	0 ~ 40°C (32 ~ 104 °F)	Under voltage Protection Over voltage Protection Over current in Charge (Pischarge Protection Short Circuit in Charge/ Discharge Protection Over temperature in Charge/Discharge Protection Over temperature in Charge/Discharge Protection Overcharging Voltage Protection	Support Solar Panel MPPT Charging	24 Months	FCC, RoHS UN38.3 <b>ⓒ</b> <b>▲</b> WARNING	Lifetime



## FAQs

### What type of battery is in an Explorer 550?

Explorer 550 contains a battery pack which consists of an array of cylindrical 2550 lithium-ion battery cells with high energy density.

## How do I know if my Explorer 550 is charged?

To check the charge level of the Explorer 550, refer to the LCD Battery Display.

## Can I charge the Explorer 550 while supplying power at the same time?

The Explorer 550 could power other devices while recharging itself.

### How do I know if my device will work with the Explorer 550?

You will need to check the amount of power your device requires. This may require some research on your end. An online search or examining the user guide for your device should suffice. To be compatible with the Explorer 550 you should use devices that require less than 500W.

## CONTACT US

Jackery





www.jackery.com hello@jackery.com 1-888-502-2236









iackeryusa





Jackery Inc.

Congratulations on your new Jackery Explorer 550

JACKETY

**Jackery Explorer 550** 

USER MANUAL

FEATURES • TECHNICAL SPECIFICATIONS • HOW TO CHARGE • FAQs • WHAT'S IN THE BOX



**CHARGE FIRST!** Before using your new Jackery Explorer, plug it into a suitable power outlet until it is fully charged. Then you can start your exciting journey with it.



## POWER U

## **LCD Screen Button**

Press the power button to check the remaining battery.

### AC Button / DC 12V Button / USB Button Turn off each output by pressing its power button as it does not turn off automatically or it will drain the battery out.

## LCD

## Power Level Percentage

### Check the battery level by pressing the display button before use. If battery is at a low level, charge first.

LCD screen flickers 10 times when battery capacity drains to

## Power of Input & Output (W)

If the Jackery Explorer's total output exceeds 500W, it will


Please ensure the power consumption is less than 500W, then press the power button.


## Low & High Temperature Alarm

The Explorer 550 can power your devices at temperatures ranging from -10 ~ 40°C (14 ~ 104°F). If your working temperature is outside this range, the Explorer 550 may stop working.

## LED FLASHLIGHT

Press button for LED flashlight, hold on button for 2-3 seconds for SOS function, press button one more time to turn off.





# possible. There are four ways to recharge your Jackery Explorer: Car Charger About 8 Hours 100W Solar Panels(Optional) About 14 Hours

## SAFETY INSTRUCTIONS

• Use and store the unit only in a clean and dry

environment. DO NOT use and store in dusty

## Read the following instructions to ensure safe usage:

## • DO NOT disassemble, repair or modify the

DO NOT place the unit close to or in a fire or expose it to heat. Keep out of direct sunlight

- Only use the output socket to power externa
- DO NOT touch the unit or the plug-in points
- if your hands are wet. DO NOT connect any metallic objects to the AC input or output.
- DO NOT rub your eyes if fluid from inside the unit should get in your eyes. DO NOT dispose the unit together with

• DO NOT use any inappropriate power cords.

DO NOT operate the unit above the specified

household waste.

 DO NOT use the unit if it is not functioning DO NOT move the unit if it is recharging or in use.

resulting in fire, explosion or risk of injury.

- DO NOT put fingers or hands into the product. DO NOT use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior
- DO NOT disassemble the power pack, take it to aqualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or electric shock.

Noncompliance may lead to serious

Noncompliance may ve., to serious injury\* or death Noncompliance may very likely lead

## unit or the battery.

- and wet environment. Check the unit prior to every use. DO NOT use DO NOT charge, use or store the unit in a the unit if it is damaged, broken. bathroom or in an area exposed to rain or DO NOT use the unit if the power cord is
- Keep the unit away from children. DO NOT devices. Never connect the output to mains let children use the power supply unit. Keep this product away from pets. DO NOT use or store the unit in an area or
  - environment with high temperature. Should fluid from inside of the unit come in contact with your skin or clothing, wash the
    - affected areas with tap water. · In a storm, unplug the power cord from the

damaged or broken.

injury\*\* or death

- DO NOT charge the unit via power supply systems that operate outside of 100~240V. DO NOT place the unit on its side or upside down while in use or storage.
- DO NOT use accessories for other usage. WARNING - RISK OF EXPLOSIVE GASES.

## Review cautionary marking on these products and on engine.

- 1) NEVER smoke or allow a spark or flame in vicinity of battery.
- \*\* Injuries include burns, electric shock, etc., which do not lead to hospitalization or permanent treatment.

## ATTENTION

Avoid dropping.

Do not disassemble.

## Not permitted on aircrafts. To preserve the battery lifespan, please use and recharge at least once every 6 months. Use original or certified charger and cables.

It's not waterproof, do not expose to liquids.

Please dispose of batteries and electronic

goods in accordance with local regulations.

- for transport of dangerous goods. Make sure that the unit is properly secured Avoid extreme temperature. when transporting it in a motor vehicle. • Only charge, use and store the unit within an ambient temperature of 0 to 40 °C (32
- Switch the unit off immediately if it has accidentally fallen, was dropped or was exposed to vibrations. Carefully read the instructions for the electric

Noncompliance may lead to injuries

and/or property damage\*\*\*

• If rust, peculiar odors, overheating or other

dealer or our customer service center.

abnormal circumstances are observed, stop

using the unit immediately and contact the

The unit complies with all legal requirement

- devices that you intend to connect to your power supply unit. Make sure that the device you are connecting is switched off before you connect it.
- To reduce risk of battery explosion, follow these instructions and those published by battery manufacturer and manufacturer of any equipment you intend to use in vicinity of the battery.

## PERSONAL PRECAUTIONS

### 2) Be extra cautious to reduce risk of dropping a metal tool onto battery. It might spark or short-circuit battery or other electrical part that may cause explosion. 3) DO NOT expose a power pack to fire or excessive temperature. Exposure to fire or temperature

Serious injuries include blindness, burns, electric shock, fractures, poisoning, etc., which can lead to complications, hospitalization or permanent treatment \*\*\* Property damage: includes buildings, belongings and pets, etc.

## DISCLAIMER

- Our company cannot be held liable for damages caused by fire, earthquake, use by a third party, other accidents, intentional misconduct on the part of the customer, abuse or other abnormal conditions.
- Do not repair any damage to the AC plug or power supply on
- The warranty covers all terms and conditions of the warranty. Contents that are not specified in the warranty terms and conditions are beyond our responsibility.
- Our company assumes no liability for damages caused by incorrect use or non-compliance with this instruction manual.

Intended use: The Jackery Explorer 550 portable power unit is intended as a power supply for electronic devices with a maximum power consumption of 500W. Our product is not suitable to be used with equipment that relates to one's own personal safety and relies heavily on electricity, such as medical devices, equipment for nuclear facilities, the manufacture of accidents involving personal safety, fires, or machine failures, caused by using our product with the aforementioned devices.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.