

CKS207 Quick Guide

TIME SETTING

Year → Day → 12/24H → Time

STEP 1



Press **CLOCK SET** for 2 seconds to entry time setting.



Press **◀** or **▶** to adjust the Year.



STEP 2




Press **CLOCK SET** to next, Month/ Date segment will blink.



Press **▲** or **▼** to adjust the Date.
Press **◀** or **▶** to adjust the Month.



STEP 3




Press **CLOCK SET** to next, 12H / 24H segment will blink.



Press **◀** or **▶** to adjust the time format.



STEP 4



Press **CLOCK SET** to next, Hour and Minute segment will blink.



Press **▲** or **▼** to adjust the Minute.
Press **◀** or **▶** to adjust the Hour.



STEP 5 Press **CLOCK SET** again to store the setting, or wait for 40 seconds.

ALARM SETTING

Time → Volume → Alarm working days

1/2 📢 Wake to Buzzer
1/2 🎵 Wake to Radio

STEP 1




Press **AL1 / AL2** for 2 seconds to entry alarm setting. The current wake-up time will blink.



Press **▲** or **▼** to adjust the Minute.
Press **◀** or **▶** to adjust the Hour.



STEP 2



Press **AL1/AL2** to next, the current volume level and the current day mode will blink.



Press **▲** or **▼** to adjust the Volume.



Press **WEEK/MODE** to choose alarm working days.



Single day



Work day



Weekend




Week




STEP 3

Press **AL1/AL2** again to store the alarm setting, or wait for 40 seconds.

SNOOZE/ STOP/ TURN OFF THE ALARM



1. **SNOOZE** : Alarm will pause 9 minutes for each press, 6 times at most.



2. **Stop the alarm** : Press **AL1 / AL2** when the alarm is ringing.



3. **Turn off the alarm completely** : Press **AL1 / AL2** repeatedly until all the alarm indicator OFF from the display.