

CKS507 Quick Guide

TIME SETTING

Time → Day → Year → 12/24H



STEP 1



Press **TIME SET** for 2 seconds to entry time setting.

Press ▲ or ▼ to adjust the Hour.
Press ◀ or ▶ to adjust the Minute.


STEP 2



Press **TIME SET** to next, Month / Date segment will blink.

Press ▲ or ▼ to adjust the Month.
Press ◀ or ▶ to adjust the Date.


STEP 3



Press **TIME SET** to next, Year segment will blink.

Press ◀ or ▶ to adjust the Year.

STEP 4



Press **TIME SET** to next, 12H / 24H segment will blink.

Press ◀ or ▶ to adjust the time format.

STEP 5

Press **TIME SET** again to store the time setting, or wait for 40 seconds.

ALARM SETTING

Time → Volume → Alarm working days

1/2 📢 Wake to Buzzer
1/2 📻 Wake to Radio


STEP 1



Press **AL1 / AL2** for 2 seconds to entry alarm setting.

Press ▲ or ▼ to adjust the Hour.
Press ◀ or ▶ to adjust the Minute.

STEP 2



Press **AL1 / AL2** to next, the current volume level will blink.

Press **▲** or **▼** to adjust the volume.

STEP 3



Press **AL1 / AL2** to next, the current day mode will blink.


Press **▲** or **▼** to choose alarm working days.




Single day



Work day



Weekend




Week




STEP 4

Press **AL1 / AL2** again to store the alarm setting, or wait for 40 seconds.



SNOOZE/ STOP/ TURN OFF THE ALARM



1. **SNOOZE** : Alarm will pause 9 minutes for each press, 6 times at most.



2. **Stop the alarm** : Press **AL1 / AL2** when the alarm is ringing.



3. **Turn off the alarm completely** : Press **AL1 / AL2** repeatedly until all the alarm indicator OFF from the display.