



MIMOSA AIRPLUSH 6-WAY HIPSEAT CARRIER

User Manual



Malaysia Importer/Distributor:
Global Product Solutions Sdn. Bhd. (705154-M)
Wisma Pang Cheng Yeap, Lot 5205C,
Jalan Perindustrian Balakong Jaya 1/3,
Taman Perindustrian Balakong Jaya,
43300 Seri Kembangan, Selangor Darul Ehsan, Malaysia
Tel: (60) 03 8940 6638
my.support@globaloutsourcenasia.com | mysales@globaloutsourcenasia.com

Hong Kong Importer/Distributor:
Trade Solutions Ltd
Unit D, 13A/F, Gemstar Tower, 23 Man Lok Street,
Hunghom, Kowloon, Hong Kong

Singapore Importer/Distributor:
Global Outsource Solutions Pte Ltd
601 Sims Drive, Pan-I Complex, Singapore 387382
Tel: (65) 6831 5020
info@globaloutsourcenasia.com



1. SAFETY INFORMATION.....	2
2. HIPSEAT CARRIER SPECIFICATIONS.....	5
3. HIPSEAT CARRIER PARTS.....	6
4. SECURING THE REMOVABLE FRONT PANEL.....	7
5. USING THE MESH VENTILATION WINDOW.....	8
6. PUTTING ON HIPSEAT (ALL OPTIONS).....	9
7. FRONT INWARD CARRY INSTRUCTIONS	10
8. FRONT OUTWARD CARRY INSTRUCTIONS.....	13
9. BACK CARRY INSTRUCTIONS.....	17
10. FRONT INWARD/OUTWARD CARRY INSTRUCTIONS.....	21
11. USING THE HOOD.....	22
12. CARE INSTRUCTIONS.....	22

Important! Please read all instructions before assembling and using the Hipseat Carrier. Please keep all instructions for future reference.

- Only use this hipseat carrier for children between 15lbs (6.8kg) and 45lbs (20kg) (minimum 7.7lbs (3.5kg) with infant insert). Minimum weight of 15lbs (6.8kg) with removable panel and minimum weight of 17.2lbs (7.8kg) without removable panel.
- Do not use this hipseat carrier for baby weighing less than 7.7lbs (3.5kg) or under 4 months of age, until your baby can support its own head.
- Always carry your baby facing towards your body in either the front or back carry position until your baby can hold his or her head upright. Always use the removable front panel until your baby can hold his or her head upright. Only use the front outward, back and hipseat-only carry positions when your baby has demonstrated strong and consistent head and neck control.
- Premature infants, infants with respiratory problems and infants under 4 months are at greatest risk of suffocation.
- Always monitor to ensure that your baby's mouth and nose are unobstructed.
- Check to assure all buckles, snaps, straps and adjustments are secure before each use. Regularly check while in use to ensure proper placement and tension. Ensure the shoulder straps and waist belt are not twisted or tangled when in use. Ensure the removable front panel is not obstructed or bundled up.
- Check for ripped seams, torn straps or fabric or damaged fasteners before each use. Do not use the hipseat carrier if it is damaged.
- Ensure proper placement of baby in hipseat carrier. Regularly check your baby's position to make sure that the baby is properly seated in the hipseat carrier, centred with legs extended, head upright and not slouching downwards or to the side.
- Never unbuckle the waist belt while your baby is in the hipseat carrier.
- For users with longer torso, you may want to wear the waist belt just above your hips. For users with shorter torso, you may want to wear the waist belt around your hips.
- Always support your baby with one arm when adjusting the hipseat carrier to your fit for the safety of your baby.

- Do not switch between positions with your baby in the hipseat carrier. Always take your baby out of the hipseat carrier before changing the position of the hipseat.
- The hipseat carrier is not suitable for use during sporting activities (e.g. running, cycling, swimming, skiing, etc) or while lying down.
- The hipseat carrier should only be used when walking, sitting or standing.
- Never leave your baby unattended in the hipseat carrier.
- Never use a hipseat carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Never wear a hipseat carrier while cooking and cleaning, holding hot drinks, etc. which involves exposure to a heat source or chemicals.
- Never wear a hipseat carrier while driving or when being a passenger in a motor vehicle.
- This hipseat carrier is not a substitution for a car seat.
- Keep this hipseat carrier out of reach from pets or children when not in use.
- This hipseat carrier is only intended to be used with one child at a time.

⚠ WARNING:

FALL AND SUFFOCATION HAZARD

Fall Hazard – Babies can fall through a wide leg opening or out of hipseat carrier.

- Adjust leg openings to fit your baby's legs snugly. Make sure your baby's legs are comfortably positioned and safely secure.
- Before each use, make sure all fasteners (e.g. buckles, snaps, straps and adjustments) are secure.
- Take special care when leaning or walking.
- Never bend at waist; always bend at knees.

- Only use this carrier for children between 15lbs (6.8kg) and 45lbs (20kg) (minimum weight of 7.7lbs (3.5kg) with infant insert). Minimum weight of 15lbs (6.8kg) with removable panel and minimum weight of 17.2lbs (7.8kg) without removable front panel.
- Always support your baby with one arm when using the hipseat carrier without the removable panel.
- Never unbuckle the waist belt while your baby is in the hipseat carrier.
- Do not leave your baby unsupported for risk of falling.
- Do not remove the removable front panel (by undoing the velcro tabs and zipper) while your baby is in the hipseat carrier.
- Stop use at first sign of damage.

Suffocation Hazard – Babies under 4 months may suffocate in this product if face is pressed tightly against your body.


- Do not strap your baby too tightly against your body.
- Allow room for head movement.
- Keep baby's face free from obstructions at all times.
- Do not leave the hipseat base open.

2. HIPSEAT CARRIER SPECIFICATIONS


Weight recommendation	15lbs – 45lbs (6.8kg-20kg, approx. 4-48 months)	
No. of carry positions	5 carry positions	
	(1) <u>Front inward carry</u> (hipseat + removable front panel) Min. 15lbs (6.8kg, approx. 4 months) (7.7lbs (3.5kg) with infant insert)	(2) <u>Front outward carry</u> (hipseat + removable front panel) Min. 15lbs (6.8kg, approx. 4 months)
	(3) <u>Back carry</u> (hipseat + removable front panel) Min. 17lbs (7.8kg, approx. 6 months)	(4) <u>Front inward carry</u> (hipseat only) Min. 17lbs (7.8kg, approx. 6 months)
	(5) <u>Front outward carry</u> (hipseat only) Min. 17lbs (7.8kg, approx. 6 months)	
Material	Polyester, mesh and 100% cotton	
Safety	This product meets European safety standards.	

3. HIPSEAT CARRIER PARTS

HIPSEAT CARRIER



HIPSEAT BASE





Features We Love:

- Can be used for 4 carrying positions
- Extra padding on shoulder straps for your comfort
- Thick waist belt for better weight distribution, reduces backaches
- Adjustable chest and waist straps to provide a perfect fit
- Honeycomb anti-slip on hipseat base for your baby's safety
- Removable front panel with mesh ventilation window keeps your baby cool
- Double safety locking device (zipper & velcro buckle) and big belt buckle to keep your baby secure at all times
- Ergonomically designed seat to encourage proper sitting posture
- Side pocket for tissues and mobile phone
- Removable sleeping hood to support your baby's head while he/she is sleeping



4. SECURING THE REMOVABLE FRONT PANEL

IMPORTANT! Do not attach or detach the removable front panel while your baby is in the hipseat carrier.



A) HOW TO ATTACH THE REMOVABLE FRONT PANEL TO HIPSEAT BASE

	<ol style="list-style-type: none">1. Connect the removable front panel to the hipseat base via the zipper.
	<ol style="list-style-type: none">2. Secure the removable front panel to the hipseat base by running both velcro tabs through the buckles and fastening them.




B) HOW TO DETACH THE REMOVABLE FRONT PANEL FROM HIPSEAT BASE

	<ol style="list-style-type: none">1. Unfasten both velcro tabs.
	<ol style="list-style-type: none">2. Undo the zipper to detach the removable front panel from the hipseat base.

5. USING THE MESH VENTILATION WINDOW





	<ol style="list-style-type: none">1. Unzip the front pocket to expose the mesh ventilation window
	<ol style="list-style-type: none">2. Roll up the front pocket and fasten the snap to secure it.





6. PUTTING ON HIPSEAT (ALL OPTIONS)

	<p>1. Wrap the waist belt around your hips. The weight should rest on your hips. Make sure the waist belt lies close to your body with no gaps.</p>
	<p>2. Fasten waist belt buckle until you hear a "click" and pull the waist belt strap to tighten.</p>
	<p>3. Make sure the waist belt is aligned and secured.</p>





7. FRONT INWARD CARRY INSTRUCTIONS (HIPSEAT + REMOVABLE FRONT PANEL)


A) HOW TO WEAR YOUR BABY IN FRONT INWARD CARRY POSITION

	<p>1. Ensure the hipseat base and removable front panel are connected correctly and securely via the zipper and velcro buckles (refer to section 4).</p>
	<p>2. Put on the hipseat (refer to section 5) and position the waist belt so that the removable front panel is centred in front of your body.</p>
	<p>3. Hold your baby and wrap his legs around your waist while placing your baby on the hipseat base.</p>
	<p>4. Support your baby with one arm and lift the removable front panel up behind the baby's back.</p>

	<p>5. While still supporting your baby with one arm, slip your other arm into the shoulder strap.</p>
	<p>6. Switch hands and slip your other arm into the other shoulder strap. Always use one hand to support your baby until both straps are securely over your shoulders.</p>
	<p>7. Buckle the chest strap behind your shoulders to secure your baby in the hipseat carrier.</p> <p>Note: Please have someone help you with this step if you are unable to reach for the buckles.</p>
	<p>8. Adjust the hipseat carrier by pulling the adjustable straps under your arms forward so that your baby is comfortable and close to your body. The hipseat carrier should fit snugly around the leg openings, supporting your baby's torso.</p>



B) HOW TO TAKE OFF HIPSEAT CARRIER IN FRONT INWARD CARRY POSITION




	<p>1. Loosen the straps under your arms.</p>
	<p>2. Lift shoulder strap to bring the chest strap buckle up towards the back of your neck.</p>
	<p>3. Unclip and remove the chest strap buckle with one hand. Ensure that you are still holding on to your baby with your other hand.</p>
	<p>4. Remove the shoulder straps one at a time while keeping one hand on your baby at all times.</p> <p>Remove your baby.</p>







8. FRONT OUTWARD CARRY INSTRUCTIONS (HIPSEAT + REMOVABLE FRONT PANEL)


A) HOW TO WEAR YOUR BABY IN FRONT OUTWARD CARRY POSITION



	<p>7. Switch hands and slip your other arm into the other shoulder strap. Always use one hand to support your baby until both straps are securely over your shoulders.</p>
	<p>8. Buckle the chest strap behind your shoulders to secure your baby in the hipseat carrier.</p> <p>Note: Please have someone help you with this step if you are unable to reach for the buckles.</p>
	<p>9. Adjust the hipseat carrier by pulling the adjustable straps under your arms forward so that your baby is comfortable and close to your body. The hipseat carrier should fit snugly around the leg openings, supporting your baby's torso.</p> <p>Note: Do not let your baby sleep in the front outward carry position.</p>







B) HOW TO TAKE OFF HIPSEAT CARRIER IN FRONT OUTWARD CARRY POSITION




	<p>1. Loosen the straps under your arms.</p>
	<p>2. Lift shoulder strap to bring the chest strap buckle up towards the back of your neck.</p>
	<p>3. Unclip and remove the chest strap buckle with one hand. Ensure that you are still holding on to your baby with your other hand.</p>
	<p>4. Remove the shoulder straps one at a time while keeping one hand on your baby at all times.</p> <p>Remove your baby.</p>







9. BACK CARRY INSTRUCTIONS (HIPSEAT + REMOVABLE FRONT PANEL)


A) HOW TO WEAR YOUR BABY IN BACK CARRY POSITION






	<p>7. Slip your free arm through the other shoulder strap. Maintain a slight forward lean to help control your baby's weight.</p> <p>Note: Always support your baby with one arm until both straps are securely over your shoulders.</p>
	<p>8. Buckle the chest strap behind your shoulders to secure your baby in the hipseat carrier.</p>
	<p>9. Adjust the hipseat carrier by pulling the adjustable straps under your arms forward so that your baby is comfortable and close to your body. The hipseat carrier should fit snugly around the leg openings, supporting your baby's torso.</p>

B) HOW TO TAKE OFF HIPSEAT CARRIER IN BACK CARRY POSITION


	<p>1. Lean slightly forward, loosen the straps under your arms and unclip the chest strap while securing the baby with your other hand.</p>
	<p>2. Support your baby with one hand while removing a shoulder strap from one arm.</p>
	<p>3. Gently turn your baby and the hipseat base from your back to the side of your hip.</p> <p>Note: Please have someone help you until you feel comfortable doing this step on your own.</p>
	<p>4. While supporting your baby with one arm, remove the shoulder strap from your other arm. Always keep one hand on your baby at all times.</p> <p>Remove your baby.</p>



10. FRONT INWARD/OUTWARD CARRY INSTRUCTIONS (HIPSEAT ONLY)



11. USING THE HOOD



12. CARE INSTRUCTIONS

IMPORTANT: Before washing the hipseat carrier, separate the hipseat base from the removable front panel, remove inner foam seat base, fasten all buckles, velcro and close all zippers.



Machine wash cold.
Gentle cycle.



Do not bleach.



Do not tumble dry.



Do not iron.



Do not dry clean.

- Spot clean with gentle soap and water.
- Machine wash using a laundry bag; when necessary (use cold water) and air dry.
- Avoid drying in direct sunlight.
- Do not use detergents with bleach, perfumes, dyes, chlorine or optical brightener.