


2 IN 1 PLASTIC GATE & PET PEN





- READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF GATE.
- KEEP INSTRUCTIONS FOR FUTURE USE.

www.carlsonpetproducts.com

Carlson Pet Products, Inc. 3200 Corporate Center Drive, Suite 105 | Burnsville, MN 55306, USA

952.435.1084

Before Using Product

Read and follow all instructions carefully to ensure that your gate is properly installed. Improper installation could result in the gate becoming unstable or dislodged from the doorway. The safety of your pet and/or child is your responsibility. Please keep these instructions for your reference.

IMPORTANT


- The four mounting brackets must be used in securing the gate to the wall. These brackets prevent the gate from dislodging from its opening and becoming unstable.
- If hardware mounting to a surface other than drywall or wood, please consult with a professional about installation.
- The maximum width of this gate is 192 inches.



WARNING

- To prevent serious injury or death, securely install gate and use according to manufacturer's instructions.
- This product is safe for use with children from 6 to 24 months of age.
- Children have died or been seriously injured when gates are not securely installed. ALWAYS install and use gate as directed using all required parts.
- STOP using when a child can climb over or dislodge the gate.
- STOP using when a pet can climb over or dislodge the gate.
- Use only with the locking/latching mechanism securely engaged.
- To prevent falls, never use at the top of stairs.
- NEVER use to keep child away from pool.
- Always ensure the gate is resting against the floor before beginning installation.
- Strangulation hazard: pets can force themselves into very small openings; use this gate with pets whose heads will not fit into openings in the gate, between the gate and floor, or between the gate and wall.
- Never leave pet or child unattended. This product may not prevent all accidents.
- Check the gate regularly to see if all the hardware and mountings are tightened.
- Do not use if any components are missing or damaged.

Before Assembly



PLEASE CHECK TO MAKE SURE YOU HAVE THE FOLLOWING PARTS:

- **A** Play Yard Gate Frame (6 Panels)
- **B** Wall Mounting Bracket (4)
- **G** Gate Connector (4)
- **1" Wall Mounting Screws** (8) (requires a Phillips/cross-head screwdriver)
- **E** Small Threaded Gate Cap (1)
- Tall Gate Cap (2)


Option A: Installing Your Gate Between Two Walls

STEP 1

Unfold the *gate frame* at each pivoting joint by loosening each cap.

STEP 2

Determine the size of your opening. If you need to remove panels from your gate simply unhook the upper and lower knobs between the panels. If you are adding panels, hook together opposite panel ends; one panel with the male side and one panel with the female side. Check to make sure all the panels are securely locked.




STEP 3

Attach two gate connectors to one of the free ends of your gate at the specified mounting locations shown below. The placement of the gate connectors will determine where your gate is attached to the wall. Repeat step for the other free end of the gate. MOUNTING LOCATIONS MOUNTING . LOCATIONS


STEP 4

With the *gate connectors* attached to the gate, attach the *wall mounting brackets* to the *gate connectors*.

Repeat step for opposite end of gate.




STEP 5



STEP 6

Rotate *wall mounting bracket* to the locked position.

Repeat step for remaining wall mounting brackets.




STEP 7

Arrange the panels to your desired configuration.


NOTE: When putting your gate away you can remove the gate panels without removing the *wall mounting brackets*.

STEP 8


To remove your gate, rotate all wall mounting brackets to the unlocked position. You are now able to detach the gate connectors from the wall mounting brackets.




NOTE: This gate is designed to fit minimum width openings 36 inches wide to maximum width openings 192 inches wide.



Option B: Installing Your Gate as a Freestanding Enclosure






ENGLISH

STEP 3

Tighten the *locking knobs* to secure your pet pen into your desired configuration.



NOTE: When adding or removing additional panel units to the configuration, panels must be added or subtracted in sets of two for the freestanding enclosure to function properly.

TO FOLD YOUR PLAY GATE

STEP 1: Detach two of the gate panels by unhooking the upper and lower knobs.

STEP 2: You will now be able to pull the pet pen apart.

STEP 3: Fold and put away.


CARE AND MAINTENANCE

Periodically check the gate for signs of damage, wear, or missing components. Do not use if any part is missing, worn or damaged. Check the gate regularly to ensure all the hardware and mountings are tightened. Do not use abrasive cleaners or bleach. Clean by sponging with warm water and a mild detergent.

90 DAYS LIMITED WARRANTY

If, during the first 90 days after consumer purchase of the item, under reasonable and non-commercial use and conditions of maintenance, it fails while owned by the original purchaser because of the quality of materials or workmanship of finish and assembly, Carlson Pet Products, Inc. will replace or repair it at Carlson's option. PROOF OF PURCHASE REQUIRED.

Replacement Parts







- **B** 1" Wall Mounting Screws #8 round head wood screw
- Small Threaded Gate Cap Gray = #100360-001



Tall Gate CapGray = #300742-001



Gate Connector Gray = #100012-001





www.carlsonpetproducts.com



Carlson Pet Products, Inc. 3200 Corporate Center Drive, Suite 105 Burnsville, MN 55306, USA



952.435.1084