

Instructions for use with Hollywood No-Wobble System:

Slide Adapter onto the Hollywood "No-Wobble" hitch tube forward. The top plate on the hitch tube should be in contact with the adapter per Fig. 4.

Tighten the set screws on the adapter.

Slide the bike rack into your 2.5" hitch. The welded steel plate on the bottom of the adapter should press against the trailer hitch tube. Insert the locking hitch pin (be sure the hitch pin is passing through the loop in the No-wobble hitch tube).

Install the locking head onto the hitch pin and tighten the lever on the no-wobble hitch tube until the wobble in the rack is eliminated.




Fig. 1: Hollywood Sport Rider No Wobble Hitch tube




Fig. 2: Hitch Adapter




Fig. 3: Slide Adapter onto hitch tube




Fig. 4: Adapter should be fully forward, then tighten set screws.

Instructions for use with bike rack threaded hitch pin tightening system:

Slide adapter onto bike rack's hitch tube centering the hitch tube's hole within the slot on the side of the adapter. The back of the adapter should be flush with the back of the hitch tube. Snug up the set screws but do not fully tighten yet.

Slide the bike rack into your 2.5" trailer hitch. Both the hitch tube and adapter should make contact with the back plate of the trailer hitch. Adjust if necessary, and tighten set screws securely.

Insert and tighten threaded hitch pin bolt per your bike rack's instructions.




Fig. 1: Typical threaded hitch pin




Fig. 2: Hitch Adapter




Fig. 3: Slide Adapter onto hitch tube




Fig. 4: Hitch pin hole should be located within the slot.

Warning: This product is intended for use with bike racks only, for use with 2.5" Class V hitches only
(Warranty information available at hollywoodracks.com)