



# ELBA

## 4 IN 1 JUICER BLENDER MODEL: EJK-K1188A(SS)

### Owner's Manual

Please read this manual carefully before operating your set.

Retain it for future reference.

Record model number and serial number of the set.


See the label attached on the set and quote this information to your dealer when you require service.

**For The Warranty Terms & Conditions, Please Refer To Warranty Certificate.**

## IMPORTANT SAFEGUARDS

1. Read all instructions before use.
2. Do not use the appliance if the stainless-steel grater and filter assembly is damaged.
3. Do not contact the plug or power cord with wet hands.
4. Do not let plug remains plugged when not in use.
5. Do not immerse the power cord, plug or motor base into water or any other liquids.
6. Do not use this appliance when the plug or power cord is damaged or the plug is not properly inserted.
7. Never bend or bind the power cord or apply by excessive force, otherwise it may cause damaged. If the power cord is damaged, return the appliance to the nearest authorized dealer or after-sales service center for examination, repair, electrical or mechanical adjustment.
8. Keep the power cord out of reach of children. Do not let the power cord hang over the edge of the table or worktop on which the appliance stands.
9. Always use the appliance on a flat, stable and heat resistant surface.
10. Do not carry the appliance during operation.
11. Do not operate the appliance continuously for more than 3 minutes. Let the appliance to cool down for 10 minutes before continuing the next juicing.
12. Never put any fruits and vegetables inside the pulp chute until the appliance is power on.
13. Only use the food pusher as supplied. Never put your fingers or any other sharp object into the pulp chute.
14. Beware when handling the stainless-steel grater and filter.
15. Always make sure the appliance is properly and completely assembled before operating. The unit will not turn on unless it is properly assembled.
16. Before disassembling the appliance, switch off the power and wait for the filter to stop operating.
17. Before cleaning the appliance, make sure the control switch has turned to "0" position. Switch off the power and unplug from wall outlet then slowly remove the parts.
18. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
19. Children should be supervised to ensure that they do not play with the appliance.
20. Do not use the appliance outdoors.
21. Use this appliance for its intended use only.
22. This product has been designed for domestic and household use only. Any commercial use, inappropriate use or failure to comply with the instructions, the manufacturer accept no responsibility and the warranty will not apply.
23. Save this instruction for future reference.

## DESCRIPTION OF PARTS



Juicer

Blender

Chopper

Grinder

- 1. Food pusher
- 2. Juicer cover
- 3. Stainless steel grater and filter
- 4. Spout cover
- 5. Locking handle

- 6. Pulp container
- 7. Rotor
- 8. Motor base
- 9. Measuring cup
- 10. Jar cover

- 11. Glass Jug
- 12. Sealing ring
- 13. Blade nut
- 14. Scraper
- 15. Chopper cup cover


- 16. Chopper cup
- 17. Chopper unit
- 18. Grinder cup
- 19. Grinder unit

## PREPARATION OF FRUITS AND VEGETABLES

1. Wash the fruits and vegetables that need to be extracted.
2. Peel fruits that have inedible skins such as citrus fruits, pineapples, melons, papayas, etc.
3. Pit all fruits with seeds such as peaches, nectarines, cherries and etc.
4. Fruits and vegetables such as apples, carrots and cucumbers will not need to be cut into small pieces. Unless the fruits or vegetables are too big to be fit into the feeder tube, slice it before starting to extract.


## OPERATING THE APPLIANCE

### A. Juicing




1. Before using, please make sure the button switch of the motor base in stop state. In case assembly is not completed, starting the appliance accidentally can be avoided to prevent unnecessary injury to persons or damage to property.
2. Before juicing, make sure stainless-steel grater and filter and rotor clutched in position, and no hard contact between stainless steel grater and filter and juicer cover. Secure the locking handle into the cover slot.
3. Turn on power supply, press switch to let the appliance run no-load for 5 sec. Put prepared vegetable or fruit into feeder tube and press with the food pusher with evenly, hard and slowly. To extract the maximum amount of juice always push the food pusher down slowly.
4. When pressing food with the food pusher, force shall be applied evenly. Do not apply sudden force, otherwise juicing effect will be reduced.

## B. Blender



1. Make sure the position of the switch is in stop state (the switch shall be in “0” position)
2. Put sealing ring into blade unit, secure and fasten glass jug into blade unit (clockwise for fastening, and counter clockwise for loosening), put the jar cover and the measuring cup on it.
3. Secure the blade unit clockwise into the motor base with your hand (counter clockwise for loosening), do not holding the glass jug handle as per above photo for disassembling. Otherwise, the glass jug will leave blade unit and make food in the glass jug leak out.


## C. Chopper



1. Secure chopper cup into chopper unit (clockwise).
2. For meat to be processed, remove tendon, bones and skin and wash cleanly. Cut into small piece of 2-centimetre squares, every time put 200g into the chopper. Put the chopper cup cover on the chopper, mount them on the motor base according to the position shown in the diagram, turn clockwise, and press the chopper cup tightly with your hand. Turn on the button switch for chopping.
3. Before chopping, pouring some edible oil or flavouring into the meat will produce better results.

**Note: If rotating speed slows down abruptly due to too much meat quantity or tendon entangling blade. Please turn off the appliance, cut off the power supply and adjust the meat quantity or remove the tendon from the meat.**

## D. Grinder



1. Grinder cup is applicable for dried food to be ground into powder. During using, every time put 150g into the grinder cup, cover with the grinder unit. Fasten tightly by turning clockwise; mount them on the motor base according to the position shown in the “Description of Parts”. Press tight the grinder cup with your hand, turn on the button switch for grinding.
2. When grinding sesame, walnut and other oily food adding a spoon of granulated sugar into the grinder cup for grinding will produce better results.

**Note: In case of idling during grinding. i.e, when the cutter does not contact with the food. Appliance should immediately turn off and unplug from supply. Mix the food evenly softly, then turn on for grinding again.**

### **Note:**

This appliance is designed with button switches of ‘O’ grading, ‘I’ grading, ‘II’ grading and ‘P’ pulse (‘O’ for stop, ‘I’ for weak grading, ‘II’ for strong grading and ‘P’ for pulse). For chopping, cutting up and grinding, select pulse and strong grading. For operating time, take the principle of running for 10s and stopping for 5s. After using for 1 min, stop for 1 min, then use again.

For juicing, select strong grading and after using for 1 min, stop for 1 min, then use again. After the above operation is performed for three time, stop for 15 min and do not operate until the motor is cool down. In this way, the lifespan of this appliance will be prolonged.

## **DISASSEMBLE THE APPLIANCE**

**IMPORTANT:** Before disassembling the appliance, make sure that the control switch is in the '0' position. The plug has been unplugged from the wall outlet and the motor has completely stopped operating.

1. Remove the food pusher from the feeder tube.
2. Remove the pulp container by holding onto the feeder tube and tilting the juicer slightly and take out the pulp container.
3. Remove the juice jug.
4. Hold the juice cover and lift up the safety locking handle from the grooves on the side of the pulp chute / juice cover.
5. Lift up to remove the juice cover.
6. Remove the spout cover (together with stainless steel grater) by placing one hand under the spout and another hand holding under the spout cover edge (opposite the spout) and lift it upwards.

Note: Be careful when handling the grater and filter assembly as the as the cutting blades are very sharp.

## **CLEANING AND MAINTENANCE**

1. Turn the control switch to the speed '0' and wait for motor to stop operating.
2. Unplug the plug from the wall outlet.
3. Disassemble the juicer (refer to disassemble the appliance).
4. Clean the following parts with soapy water. A mild detergent is recommended to clean the parts. Rinse the parts well and dry thoroughly.
5. Rinse the stainless-steel grater and filter assembly/ cutting blade with clean water. Use cleaning brush gently clean away pulp from the filter and cutting blade. If the holes of the filter are blocked with pulp, soak the filter assembly into hot water to remove the pulp and clean with the nylon brush again. Allow to dry on a cloth or paper towel before reassembling the juicer.
6. Wipe the motor base and safety locking handle with a soft dry cloth.

## **HELPFUL HINTS**

1. A small amount of lemon juice can be added into the apple juice to prevent juice from turning into brown color.
2. Do not use dry fruits as they do not contain juice and will clog the juicer.
3. Allow the juicer to run for one minute before turning '0' speed to allow any excess juice to be extract from the pulp.
4. Plastic bag can be put in the pulp container for easy clean-up.

**ELBA**