
WEßKhu

START GUIDE



SMART WI-FI CAMERA

Scan code for the latest manual online



Thank you for purchasing your MERKURY smart home product.

Contents

■ Start Guide	
Download & Register	01
Plug in	02
Add Device (QR Code)	04
Add & Customize Tiles	07
Settings	80
Rules	10
Questions, Troubleshooting, Notices	11
■ Voice Control Guide	
Google Assistant	14
Amazon Alexa	16

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Support:

If you encounter any issues, please contact us at support.mygeeni.com for help.

To explore our full selection of products, visit us at: mygeeni.com (888)

232-3143 Toll-free

© 2022 Merkury Innovations • 45 Broadway 3rd FL, New York NY 10006. The illustrated product and specifications may differ slightly from those supplied. Geeni is a registered trademark of Merkury Innovations LLC. iPhone, Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google, Google Play, and related marks and logos are trademarks of Google LLC. iOS is a registered trademark of Cisco in the U.S. and other countries and is used under license. Amazon, Alexa and all related logos are trademarks of Amazon. com, Inc. or its affiliates. All other trademarks and trade names are those of their respective owners.

Made in China

START GUIDE

What's in the Box







USB Cable



Power Adapter



 Screws and Anchors



User Manual

Get Ready



 Know your Wi-Fi network and password



2.4GHz

 Make sure you're connecting to a 2.4GHz Wi-Fi network (Camera can't connect to 5GHz networks)





iOS 14 Android 11

 Make sure your mobile device is running iOS[®] 14 or higher or Android™ 11 or higher

STEP 1

 Download the "Merkury Cam by Geeni" App from App Store or Google Play.





Register an account on the App.

01.

Enter your email address.

02.

Enter the verification code and create a password.

03.

Log in to the App.



Plug in Plug in

Resetting Device

Reset the Camera by pressing the reset button for 3-4 seconds.









Solid Blue Starting Up

Ready to connect


Solid Blue Connected

STEP 1

Setup Camera

01.

If you would like to use the included installation mount kit, you can screw in the base of the camera using the included screws and anchors. Refer to the drawing.



NOTE: Before installing, be sure the desired location is accessible to a power source.

■ Plug In

02.

Once installed, plug in the power cable. The light will begin flashing to indicate it is ready for the setup steps.

NOTE: If you unplug the camera, you do not need to repeat the setup steps—the camera will automatically reconnect to your Wi-Fi network.

HD Camera






■ (Optional) SD Card Installation

03.

Insert microSD card as shown.
Will enable video recording and playback from your phone.

NOTE: The Smart Camera can stand on its own and be angled for any vantage point.




Add Device (QR Code)

Add Device (QR Code)

STEP 2

Add device:



01.

Be sure to reset camera by pressing the reset button for 3-4 seconds.

02

In the app, tap the "Devices" tab on the bottom and tap "+" in the top corner of the

0.3

Choose "Wi-Fi Camera" and enter your Wi-Fi details

04.

Scan the QR code with the camera. When you hear the camera beep, select 'I heard the sound' and it will add your camera.

■ Connect Wi-Fi & QR scan:





05.

The indicator light will turn solid blue when the device has connected successfully! NOTE: This camera can't connect to 5GHz networks.



Add Device (QR Code)

Add & Customize Tiles

Pairing Device



Adding device to account...

This make take a few minutes.

06.

The app will attempt to connect. This may take a few moments.



STEP 3

Add tiles:





01.

Upon successful pairing, a tile for the camera will automatically be added to the dashboard. You can add tiles with the "+" on the Home page or resize, organize, and remove tiles by tapping "Edit".

02.

Press the camera tile to view a live stream from the camera.


SETTINGS

Access Camera Settings:

From your main device list, click the camera you want to edit, then click Device Settings.

Device Name:

Device Name to rename your camera to something like "Family room" or "Back hallway", then click Save.



Motion Zones:


Click Motion Zones and then click on each square to deactivate or activate that zone from detecting motion, then click Save.

Rotate image:

If you mount your camera upside down, toggling this switch will rotate the image so that it's right side up.


Remove Device:

Delete the camera from your account. Until it's deleted, it will always be linked to your account.



RULES





Create Motion & Sound Detection Rules

01.

Select the "Rules" tab on the bottom navigation bar and tap the "+" at the top corner of the screen 02.

You can use a recommended rule, like "Record video and get notifications when motion is detected", or create your own.

Frequently Asked Questions

How can I share videos with family and friends?

Select the "Activity" tab on the bottom navigation bar and view an activity to share with others. Use the "Share" button to choose how you want to share the activity event.

How do I customize my dashboard?

Select the "Edit" option on the top of "Home" page. Create additional pages on your dashboard by dragging tiles to the right and organize devices to fit how you use them.

■ How Many Devices Can I Control?

The app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.

- My Merkury device has a funny name. How do I rename it? From your main device list, click on the device you want to rename, then click "Device Settings", then click on "Device Name". Rename your device to a more familiar name like "Bedroom" or "Living Room" and then click Save.
- The device appears offline or unreachable, what should I do? Make sure your Wi-Fi router is online and in range. Make sure you have the latest functionality by clicking "Check for firmware update" in your device settings.
- What's the Wireless Range?

The range of your home \widetilde{W} i-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.

If my Wi-Fi/Internet goes down, will it still work?
 Merkury products need to be connected to Wi-Fi in order to use them remotely.

Troubleshooting

Cannot connect to your Wi-Fi network.

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any Internet connection problems. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

Reset the device

Reset the LED strip by pressing
 6 holding reset button until the LEDs blink slowly every 3 seconds. (If it's blinking quickly or solid, reset it again)

System Requirements

- Mobile device running iOS® 14 or higher or Android™ 11 or higher
- Existing Wi-Fi Network

Technical Specifications

- Camera: up to 1080p (1920 x 1080) @15fps
- Field of View: 135°
- Audio: Insternal Speaker and Microphone
- Storage: supports up to 128 GB microSD card (not included)
- Power: Micro USB 5V, 1A
- Operating Temperature: 14° 140°F (-10° 60°C)
- Wi-Fi: IEEE 802.11n, 2.4GHz (not compatible with 5GHz Wi-Fi networks)

VOICE CONTROL GUIDE

Thank you for purchasing your Merkury smart home product. Make sure your devices are already set up using the Geeni app, then follow these steps.

Name and Control Each Device by Voice



Voice Control Guide



Contents

Google Assistant	14

Amazon Alexa ----- 16



To control your Merkury smart home products, just say "OK Google," or "Hey Google," and ask. Make sure your devices are already set up using the Geeni app.

Things you can say*: Stream to:




Google Home Hub, Google Assistant Smart Displays, Google Nest Hub, and any Google Chromecast-enabled TV, screen, or PC



*Some commands require compatible devices.

01

 Open the Google Home app and go to Home Control in the menu



Latest news & features

02

■ Tap the "+" button.




03

 Choose "Geeni" from the list of Home Control partners.



04

 Authorize your account with Google Assistant using the username and password from your Geeni app.



Now your Google Home app and devices are linked!

You're now able to say "Hey Google" and control your Merkury devices.

At any time, go into the "Home Control" section of the Google Home app to set nicknames and rooms for your devices. You can rename your devices in the Geeni app, and Google Assistant will refer to them by the same name.

So if you rename a camera to 'Living Room Camera' or 'Baby's Room," then Google Assistant will use that same name later on. You can always give it a nickname using the Google Home app as well.

Google Assistant will be able to control devices by room.



To control your Merkury smart home products, just ask Alexa. Make sure your devices are already set up using the Geeni app.

Things you can say*: Stream to:



Amazon Echo Show, Amazon Fire TV, and any Alexa-enabled TV or screen.



*Some commands require compatible devices.

01

 Open the Alexa app and go to Skills in the menu.



02

Search for Geeni then tap Enable.





03

 Authorize your account with Smart Home Skills using the username and password from your Geeni app.



04

 Choose "Discover Devices." After a few seconds your Merkury devices will be displayed under Smart Home in the Alexa app.



You can rename your devices in the Geeni app, and Alexa will refer to them by the same name.

So if you rename a smart bulb to "Living Room" or a nickname like a smart camera to "Living Room Camera" or "Baby's Room,"

Alternatively, you can create an Alexa group, like "Bedroom" or "Downstairs," and add the device to the group.

Alexa will recognize the group name in the Alexa app, or the device name in the Geeni app.

More information is available at:

http://tinyurl.com/alexa-smart-home-groups

Can't connect? Need help?

WE CAN HELP

DO NOT RETURN THIS PRODUCT TO THE STORE

support.mygeeni.com (888)232-3143 Toll-free or tap 'support' for help in the Geeni app.