

CARE AND USAGE GUIDE

- Perfect for storing, microwave reheating and quick cooking
- Open vent to microwave, close vent to store (with Rice cooker, microwave with lid off)
- Fridge, freezer, microwave & dishwasher safe (top shelf only)
- Easy grab safe hold handles



TO REHEAT AND QUICK COOK

Place lid on the base and click the steam release vent to the open position. After removing from microwave, leave vent open while food is hot. Close vent for storage after cooling

AFTER FREEZING:

Let the storer rest for a few minutes or run water over it before removing the lid, as freezing makes the lid stiff and difficult to remove.

TO STEAM WITH EASY STEAM RACKS

Add ½ cup of water to the steamer and place rack inside. Add vegetables, put lid on and open vent. Microwave, regularly stopping to check cooking and water levels. Top up with water as required.

EASY STEAM SUGGESTED MICROWAVE COOKING TIMES*

PEAS	BEANS	CARROTS	ZUCCHINI
4 minutes	4 minutes	4 minutes	5 minutes
BROCCOLI	CORN	CAULIFLOWER	POTATOES
5 minutes	6 minutes	7 minutes	8 minutes

*Cooking guidelines based on a 1000W microwave oven

RICE COOKER

If cooking rice in Rice Cooker, microwave with lid off. Follow our Microsafe Rice Cooker instructions for fluffy rice every time. <https://tinyurl.com/2p99wneb>

SOUP, NOODLE AND OAT BOWL

If using the Soup, Noodle and Oat Bowl refer to food packet instructions. Microwave with lid on and open vent. Regularly stop to check cooking and water levels. Top up with water as required. Freezer and dishwasher safe (top shelf only).

CARE GUIDELINES:

Before use, remove labels and wash the product. Do not use abrasive materials when washing applying a paste of baking soda and water then rinsing thoroughly can reduce food stains and discolouration. Steam vents can be removed for easy cleaning.

WARNINGS

- After microwaving, contents and storer may be very hot.
- Always use oven mitts to prevent risk of burn injury



DO NOT USE DECOR MICROSAFE™ PRODUCTS

- In conventional ovens or toaster ovens
- In combination microwave ovens (unless in microwave only mode)
- On hot plates, stove tops or under a grill Overheating foods, particularly foods high in oil, fat or sugar, may cause the product to melt. If the product melts, it may cause a burn injury if handled.

- If cooking with oil, or if cooking foods high in oil, fat or sugar, Decor recommends checking food regularly during microwaving, e.g. every 30 seconds. If melting fat, do not microwave past the point of melting. Never cook popcorn in Microsafe™ products (aside from the Microsafe™ Popcorn Maker), as doing so may melt the product
- Not suitable for children under 48 months old.
- If product is damaged, discontinue use.