



MAKES 1-4 SERVES

microsafe™

Rice Cooker

You can make up to 4 cups of cooked rice in the Decor Microsafe™ 2.75 litre Rice cooker. The rice cooker comes with a handy measuring cup and rice paddle. Other features include the steam release vent and safe-hold handles that stay cool to the touch for easy lifting in and out of the microwave.



Steps for white long grain rice

Cook all kinds of rice and grains. Stop and check cooking progress at regular 5 minute intervals

Overheating of foods high in oil, fats or sugar may cause the product to melt. Heating of any such substances must be carefully monitored (check every 30 seconds) and such substances should not be further heated once melted.

WARNING Container and it's contents may become very hot. Take extra care when draining hot water.



1

Measure 2 cups of rice & add to cooker. Add 4 cups of cold water and stir. *Makes 4 serves.



2

Microwave on high for 17 minutes without the lid.



3

Remove from microwave and put lid on with vent open. Rest for 5 minutes. Loosen grains with rice paddle and serve.

*Cooking guidelines and recipes are based on 1000W microwave. It is recommended that you monitor and check water level during cooking and top up as required.



CLICK THROUGH TO RECIPES

