



M100V USER MANUAL

USER MANUAL




M100V


Quick Start




Correct Wearing







Principle




1. Power On/Off






Power On
 Ⓜ Long Press 4ss  Blue Light Flashes Twice  Power on



Power Off
 Ⓜ Long Press 4ss  Red Light Flashes Twice  Power off

2. Connect with Mobile Phone




a. After powered on, the headset will go into pairing mode
 Blue and red light flashes alternately
 Pairing




b. Turn on the Bluetooth function on mobile phone search M100V
 Blue breath light flashes once every 10 seconds
 Connected

3. Connect with Two Mobile Phones


a. Turn off the Bluetooth function of the first mobile phone which was paired with "M100V" already.




b. Turn on the second mobile's Bluetooth function and search "M100V" for pairing.



c. Turn on the first mobile's Bluetooth function. Search and connect the "M100V" paired before.




4. Playing/ Pause




Short press once to pause
 Short press once again to play
 When playing music blue breath light flashes every 10 seconds

5. Next/ Last Song & Volume Adjustment /Mic Mute




Press for 2s for next song
 Short press once for volume up




Press for 2s for last song
 Short press once for volume down



Long press the "volume -" button 2ss to mute microphone during call. "Toot" tone will be heard every 10ss during microphone muted.
 Long press the same button 2ss again to un-mute microphone

 Toot


6. Call Management



- *1 **Answer/End call**
Short press once
- *1 **Reject call**
Long press 2ss
- *2 **Dial the last call**
Short press twice
- *1 Short press to end current call and meanwhile answer the new call
- *2 **Answer the second call**
Short press twice
- *2 **Switch from the current call to the first call**
Short press twice


 When call is coming, red light flashes every 3 seconds
 During call, blue light flashes every 10 seconds

7. Voice Assistant





Available to wake up voice assistant by touch the multi-function button for 4ss when connected with cell phone (not in music mode).
 Pause music to wake up voice assistant if in music mode.


8. Factory Reset






Long press "+" and "-" together for 3ss

 Blue and red light flashes alternately
 toot toot

9. Charging



Charge Port

-  Red light falshes when battery low
-  Prompt tone "didid" every 10 seconds
-  Solid red light when charging, solid blue light when fully charged

Accessories

- Headset ----- 1
- Charge Cable ----- 1
- User Manual ----- 1
- Silicone Earplugs ----- 2
- Velvet Bag ----- 1

Specifications

Model No.: M100V
 Bluetooth Version: 5.2
 Bluetooth Protocol: A DP, AVRCP, HFP, AAC, etc.
 Transmission Distance: 30m(without obstacle)
 Weight: 40g
 Audio Channel: Stereo
 Speaker Frequency: 50HZ-20KHZ
 Sound Quality: APTX-HD/no distortion
 Microphone: Ai dual mic noise reduction technology
 Standby: 200H
 Music Time: 8H(70% volume)
 Charge Time: 1.5H
 Charge Votage: 5VDC(≤24V)
 Charge Port: Type-C USB
 Battery Capacity: 180mAh
 Working Temperature: -10 C ~60 C
 Battery Charge Time: >1000
 Waterproof Level: IP65

Note:

- The correct wearing position of the bone conduction speaker of this headset is the cheek bone in front of the ear. Please do not put speaker into ears.
- Listening to high volume music for long time may cause hearing loss. Please try to listen at moderate level volume.
- Avoid dropping from high which causes damage to sound quality. Keep away from fire and high voltage equipments.
- Please store the headset in a dry and ventilated place. When the headset is not used for a long time, charge it every two months
- If the headset is stained with water or sweat after exercising, please use a clean cloth to wipe it for long-term use.
- Please reset the headset if it cannot work well.
- Please check the charging port before charging to make sure there are no water stains or foreign matters.

Warranty Card

Customer Name	Phone No.
Product Name	Product No.
Customer Address	Date of Purchase
Dealer Name	Phone No.
Date of Repair	Defective Status
Repair Result	

Warranty Coverage

Button failure, no sound from speaker or microphone, call not work, unable to charge normally

Out of Warranty service

Damage caused by negligence.
 Damage caused by unauthorized disassemble and modification.
 Damage caused by charging with high voltage or manual abuse.

CHECK OUT CARD Checker: 