



M100 USER MANUAL

USER MANUAL




M100


Quick Start




Correct Wearing







Principle




1. Power On/Off






Power On
① Long Press 4ss  Blue Light Flashes Twice  Power on



Power Off
① Long Press 4ss  Red Light Flashes Twice  Power off

2. Connect with Mobile Phone




a. After powered on, the headset will go into pairing mode
 Blue and red light flashes alternately
 Pairing




b. Turn on the Bluetooth function on mobile phone search M100.
 Blue breath light flashes once every 10 seconds
 Connected

3. Connect with Two Mobile Phones


a. Turn off the Bluetooth function of the first mobile phone which paired with M100 already




b. Turn on the second mobile's Bluetooth function and search M100 for pairing




c. Turn on the first mobile's Bluetooth function and search the M100 paired before




4. Playing/ Pause



Short press once to pause
Short press once again to play

 When playing music blue breath light flashes every 10 seconds


5. Next/ Last Song & Volume Adjustment





Long press 2ss for next song
Short press once for volume up


Long press 2ss for last song
Short press once for volume down


6. Call Management





 *1 **Answer/End call**
Short press once



 *1 **Reject call**
Long press 2ss

 *2 **Dial the last call**
Short press twice


 *1 Short press to end current call and meanwhile answer the new call


 *2 **Answer the second call**
Short press twice



 *2 **Switch from the current call to the first call**
Short press twice

 When call is coming, red light flashes every 3 seconds
 During call, blue light flashes every 10 seconds




7. Factory Reset



Long press "+" and "-" together for 3ss  Charge Port

 Blue and red light flashes alternately
 toot toot

8. Charging

 Red light flashes when battery low
 Prompt tone "didi" every 10 seconds
 Solid red light when charging, solid blue light when fully charged

Accessories

Headset	-----	1
Charge Cable	-----	1
User Manual	-----	1
Silicone Earplugs	-----	2
Velvet Bag	-----	1

Specifications

Model No.: M100
Bluetooth Version: 5.2
Bluetooth Protocol: A2DP, AVRCP, HFP, AAC, etc.
Transmission Distance: 30m(without obstacle)
Weight: 38g
Audio Channel: Stereo
Speaker Frequency: 50HZ-20KHZ
Sound Quality: APTX-HD/no distortion
Microphone: AI dual mic noise reduction technology
Standby: 200H
Music Time: 8H(70% volume)
Charge Time: 1.5H
Charge Voltage: 5VDC(≤24V)
Charge Port: Type-C USB
Battery Capacity: 180mAh
Working Temperature: -10 C~60 C
Battery Charge Time: >1000
Waterproof Level: IP67

Note:

- The correct wearing position of the bone conduction speaker of this headset is the cheek bone in front of the ear. Please do not put speaker into ears.
- Listening to high volume music for long time may cause hearing loss. Please try to listen at moderate level volume.
- Avoid dropping from high which causes damage to sound quality. Keep away from fire and high voltage equipments.
- Please store the headset in a dry and ventilated place. When the headset is not used for a long time, charge it every two months
- If the headset is stained with water or sweat after exercising, please use a clean cloth to wipe it for long-term use.
- Please reset the headset if it cannot work well.
- Please check the charging port before charging to make sure there are no water stains or foreign matters.

Warranty Card

Customer Name		Phone No.	
Product Name		Product No.	
Customer Address		Date of Purchase	
Dealer Name		Phone No.	
Date of Repair		Defective Status	
Repair Result			

Warranty Coverage	
Button failure, no sound from speaker or microphone, call not work, unable to charge normally	
Out of Warranty service	
Damage caused by negligence. Damage caused by unauthorized disassemble and modification. Damage caused by charging with high voltage or manual abuse.	
CHECK OUT CARD	Checker: 