

# DECT Cordless Senior Phone Model # FC-0914 Future Call Instruction Manual



1


## BEFORE USE

### Connecting your phone:

- Connect plugs in corresponding sockets in the base station. Plug the telephone line into telephone socket and insert power plug in an electrical outlet.
- Insert batteries in Handset.
- After first time power up (base unit is connected to AC mains), welcome mode (country) will appear on the screen (Fig.1).

- Before you start to use your telephone, charge batteries continuously for 15 hours.
- Use only plug adapter and rechargeable batteries supplied with your phone.

### Handset / Base Station Keys



2

1	OK / Menu key
2	Back / Intercom key
3 & 4	Navigation key
5	Hang-up / Exit key
6	# key - Press to insert #; In idle mode: Press and hold to access the call list.
7	0 key - During a call: Press and hold to insert a flash for call waiting.
8	* key - Press to insert *; In idle mode: press and hold to access the redial list
9	M1, M2 key - In idle mode/during a call: Press to dial pre-recorded number stored in direct mem.
10	911 Quick Dial Key One press to dial out 911 emergency number.
11	Talk key/Loudspeaker
12	Paging key - To locate handset/to start registration procedure.

\*Subject to subscription and availability of the service from the fixed line operator.

### Display icons:

	Indicates battery is fully charged.
	Indicates battery is fully discharged.
	Indicates that an external call is connected or held. Icon blinks when receiving an incoming call.
	Indicates you have a new voice mail message*.
	Indicates you have new missed calls*.
	Displays when the alarm clock is activated.

3

	Displays when handsfree is activated.
	Displays when ringer volume is turned off.
	Indicates that the handset is registered and within range of the base station. Icon blinks when the handset is out of range or is searching for a base.

### USING THE PHONE Received and end a call

1. Make a call
  - 1.1 Make a Call
    - Press to get the line, then press phone number to dial out the call;
    - Press phone number then press to dial out the call.
  - 1.2 From Redial List
    - Press and hold to access the call log list;
    - Press or to access the redial list record;
    - Select the phone number in the redial list;
    - Press to dial out the call

- 1.3 From Call Log List
  - Press and hold # to access the call log list;

4

- Press or to access the call log list;
  - Select the phone number in the call log list;
  - Press to dial out the call
- ### 1.4 From Direct Memories
- Long press on **KEY 1** or **KEY 2** or **KEY 3** or **M1** or **M2** or **911** in idle mode to dial out.
- ### 1.5 From Phonebook
- Press to access the phonebook;
  - Press or to select the phonebook record;
  - Press to dial out the call
- ### 1.6 To make an Internal Call
- If only 2 registered handsets, press to start Intercom;
  - If more than 2 registered handsets, press to start Intercom;
  - Press or to select handset number;
  - Press to start the Intercom of selected handsets.
- ### 1.7. To make a Three-Party Conference Call
- During call:
- Press to enter menu then select INTERCOM;
  - Press to confirm;
  - Press or to select handset number;

5

- Press to confirm the selected handset;
  - Press on the called handset to answer;
  - Long press \* on the calling handset to establish conference call.
- ## 2. EARPIECE MODE/SPEAKERPHONE MODE/MUTE CALL/BLOCK CALL
- ### 2.1. EARPIECE MODE
- During a call:
- During a call, press or to select earpiece volume from volume 1~5.
- ### 2.2. Speakerphone mode
- During a call:
- Press to activate or deactivate handsfree model with 5 volume levels;
  - Press or to select volume 1~5. The current setting is show;
  - When you end the call, the setting will remain at the last selected level.
- ### 2.3. Mute Call
- During a call:
- Mute a call is a function when you talk to someone nearby without letting the caller hear you during a call.
  - Press to mute the microphone and "SECURITY ON" will display on LCD; then your microphone is muted and your caller cannot hear you;
  - Press again to unmuted.
- ### 2.4. Block Call
- Block call is a function to block unwanted call from a phone number.
- Press to enter menu then select **CALL BLOCK**;
  - Press to confirm;

6

- Press or to select **BLOCK SET./BLOCKLIST/BLOCK ANOYM.**
  - then press to confirm;
  - **BLOCK SET.** set ON/OFF for the CALL BLOCK function;
  - **BLOCKLIST** is to view the phone number of all the blocked call;
  - **BLOCK ANOYM** set ON/OFF for blocking calls not in the PHONEBOOK.
- ### PHONEBOOK SETTING: 100 ENTRIES
- #### 1. To register in phonebook
- Press to enter the menu;
  - Press or to select **PHONEBOOK** function in menu;
  - Press to enter to **PHONEBOOK** function;
  - Press then select **ADD**;
  - Enter name of contact, then press to confirm the enter;
  - Enter phone number of contact, then press to confirm the enter;
  - Select melody for the contact, then press to confirm.
- #### 2. To register the direct memories n keys M1, M2, 1, 1 & 3
- Press to enter the menu;
  - Press or to select **HS SETTING** function in menu;
  - Press to enter to **HS SETTINGS** function;
  - Press or to select **DIRECT MEM**;
  - Press to confirm;

7

- Press or to select **M1** or **M2**, **KEY 1** or **KEY 2** or **KEY 3**;
  - Press to confirm;
  - Then edit or enter the number;
  - Press to confirm.
- ### PHONE SETTING
- This phone can be customized according to your preference, to access the different possibilities press to enter into menu to select the settings.
- #### 1. Date and Time Settings
- To set the correct time and date on the phone
- Press to enter menu;
  - Press or to select **HS SETTINGS**, then press to confirm;
  - Press or to select **DATE FORMAT/TIME FORMAT/SET TIME**.
- ##### 1.1. Change Date/Time Format
- Select **DATE FORMAT** to set desired date format between **MM-DD-YY** or **DD-MM-YY**. Use or to select the selected format, then press to confirm;
  - Select **TIME FORMAT** to set desired time format between **12 HR** or **24HR**. Use or to select the selected format, then press to confirm.
- ##### 1.2. Set the Time
- Select **SET TIME** to set the correct time and date;

8

- Press to enter menu;
  - Press to set;
  - After setting time, display shows **SET DATE**. Input correct date, press to set.
- ### 2. Alarm Settings
- Set an alarm clock on this phone. When an alarm is set, shows on display. When the alarm time is reached, the phone rings with the alarm melody for 45 seconds, and the and "ALARM ON" on display flash. Press any keys on handset to disable the alarm. If SNOOZE is ON, the alarm will alert again at then end of snooze period of 7 minutes. Press and hold to stop the SNOOZE.
- Press to enter menu;
  - Press to select **HS SETTINGS**, then press to confirm;
  - Press or to select **ALARM**, press to confirm;
  - Press or to select ON/OFF for alarm function;
  - Select ON, then press to confirm.
- Display shows SET TIME, input alarm time then press to set;
- Display shows SNOOZE, use or to select ON/OFF for snooze function.
- ### HANDSET SETTING
- Handset can be customized according to your preference by accessing **HS**

9

- SETTINGS** to select the settings.
- Press to enter menu;
  - Press or to select **HS SETTINGS**, then press to confirm;
  - Press or to select **RING SETUP/TONE SETUP/LANGUAGE/RENAME HS/AUTO ANSWER**, then press to confirm the selection.
- #### 1. Set the Ringer Melody and Volume
- Ringer melody and Ringer volume can be set in different scenarios, **INTERNAL RING** and **EXTERNAL RING**.
- Note:** Total 5 different melodies and 5 different Tones for selection.
- ##### 1.1. Set Ringer Melody for Internal Call
- Select **RING SETUP** press or to select INT. RING, then press to confirm;
- ##### 1.2. Set Ringer Melody for External Call
- Select **RING SETUP** press or to select **EXT. RING**, then press to confirm;
  - Press or to select the desired ringer, then press to confirm.
- ##### 1.3. Set Ringer Volume
- Select **RING SETUP** press or to select **RING VOLUME**, then press to confirm;
  - Press or to select the desired volume from Level 1~5, then press to confirm.

10

- #### 2. Set Alert Tones
- Alert tone can be set ON or OFF when:
- Press a key <KEY TONE>;
  - Battery is low and needs charge for handset <BATTERY TONE>;
  - Handset and Base is out of range <OUT OF RANGE>.
- To set Alert Tones ON/OFF:
- Select **TONE SETUP**, press or to select **KEY TONE/BATTERY TONE/OUT OF RANGE** to set alert tone, then press to confirm selection;
  - Select ON to turn on the alert tone, or, OFF to turn off.
- #### 3. Set Language on Handset
- Select **LANGUAGE**, press or to select the language, then press to confirm.
- Note:** Total 7 different languages for selection.
- #### 4. Rename the Handset
- RENAME HS**, input name of the handset, then press to confirm.
- #### 5. Set the Auto Answer
- When Auto Answer is on, call answers automatically when you pickup the handset from cradle.
- Select **AUTO ANSWER**, press or to select ON or OFF;
  - Select **ON**, press to turn on **Auto Answer**;
  - Select **OFF**, press to turn off **Auto Answer**.
- ### BASE SETTING
- Handset can be customized according to your preference by accessing **HS SETTINGS** to select the settings.

11

- Press to enter the menu;
  - Press or to select **BS SETTINGS**, then press to confirm;
  - Press or to select **DELETE HS/DIAL MODE/FLASH TIME/CHANGE PIN/ECO MODE**, then press to confirm the selection.
- ### 3. De-register a Handset
- To de-registered a handset from the Base, 4-digit PIN need to be input. The on the de-registered handset will blink.
- Select **DELETE HS**, then input 4-digit system PIN, press enter;
  - Press or to select one of the handset when need to be de-registered, then press to confirm.
- Note:** If PIN correct, handset will go to next step. If PIN incorrect, handset will go back to previous level.
- ### 4. Change the dial mode
- Select **DIAL MODE**, press or to select **TONE** or **PULSE**, then press to confirm.
- ### 5. Change the Flash Time
- The flash time settings is country dependent and needs to contact Local Service Provider for the correct settings.
- Select **FLASH TIME**, press or to select **SHORT** or **MEDIUM** or **LONG**, then press to confirm.
- ### 6. Change the system PIN Code
- A 4-digit system PIN code needs for changing the system settings of the base station. The default system PIN code is 0000.
- Select **CHANGE PIN**, then needs to input the existing 4-digit system PIN,

12

- then press to confirm;
  - Enter new system PIN code, then press to confirm.
  - Re-enter the new system PIN code, then press to confirm.
- Note:** If PIN correct, handset will go to next step. If PIN incorrect, handset will go back to previous level.
- ### 7. Change the ECO Mode
- The phone can be set in ECO mode for power saving.
- Select **ECO MODE**, press or to select ON, then press to turn on ECO mode;
  - Select OFF, then press to turn off ECO mode.
- ### REGISTRATION
- The phone can be registered up to FOUR handsets to a single base station.
- The handset is not registered to the base station, the on display.
- To register new handset:
- Press and hold on the base station for about 5 seconds, the base station is entered into registration mode;
  - Press to enter menu, then press or to select .
  - **REGISTRATION**, then press and 4-digit system PIN code need to input, then press to confirm.
- If the handset registration is successful, a confirmation tone will be heard and on the registered handset will stop blinking.
- The handset will be assigned automatically to the next available handset number. Handset number shows in the handset display during standby mode.

13

- If the on the handset keep blinking, this means the handset registration is unsuccessful.
- ### RESET THE PHONE
- The phone can be reset to the factory settings. After reset, all the settings and call list entries inside the phone will be deleted, except **PHONEBOOK** remains unchanged.
- Press to enter the menu; then press or to select **DEFAULT**, then press to confirm.
  - 4-digit system PIN code need to input, then press to enter;
  - Display shows **CONFIRM?**, press to confirm.
- ### TROUBLESHOOTING
- As a general rule, if a problem occurs, remove the batteries from all handsets for about 1 minute, then disconnect and reconnect the power supply to the base and reinstall the handset batteries. For more information, you can download full user guide or get on-line assistance [www.brondi.it](http://www.brondi.it)
- ### SAFETY
- This telephone is not designed for Emergency calls when the main power fails.
- Do not use your telephone to notify a gas leak or other potential explosion hazard.
  - Do not open your device or its power supply to avoid risk of electric shock.
  - Do not attempt to open the batteries, as they contain hazardous chemical substances.
- Your telephone must be located in a dry place away from hot, humid and direct sunlight condition. To avoid radio signal interference, place the phone at least 1 meter away from other electrical appliances or other phones

14

- Technical informations: DECT(Base & Handset) frequency: 1822-1897MHz Maximum transmission power: 24dBm.
- NOTICE** :If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this equipment FC-0914 does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
- WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- ### SERVICE
- According to FCC regulation. This equipment which has been certified and registered by the FCC, may only be repaired by authorized person, the FCC certification may be voided. Should you encounter any problems, please call the **FUTURE CALL LLC**.
- Toll-free Customer Hotline for assistance:  
1-888-934-CALL, Monday - Friday between the hours of 9:00 am - 6:00 pm PST For general inquires, you can E-Mail to [help@future-call.com](mailto:help@future-call.com) or visit our website at [www.future-call.com](http://www.future-call.com) FOR WARRANTY AND OUT-OF WARRANTY SERVICE:
- You may call our toll-free hot line on 1-888-934-CALL (1-888-934-2255)9AM-6PM PST or E-mail to [help@future-call.com](mailto:help@future-call.com) QUESTIONS?
- STOP**...doesn't take unit back to the store.  
**LOOK**...for the toll-free "help" telephone number.  
**LISTEN**... as our experts talk you through the problem.

15

- For immediate answers to your questions regarding operation, missing parts or installation call:  
**FUTURE CALL LLC**  
HOTLINE & E-MAIL AT:  
1-888-934-CALL & [help@future-call.com](mailto:help@future-call.com)  
**LIMITED WARRANTY AND SERVICE**  
**FUTURE CALL LLC**. Warrants this product to be free from defective materials or factory workmanship and will replace or repair this unit or any part thereof, except batteries, if it proves to be defective in normal use or service within 90 days from date of original purchase. Our obligation under this warranty is the repair or replacement of the defective instrument or any part thereof, except batteries. This warranty will be considered void if unit is tampered with, improperly serviced, or subjected to misuse, negligence or accidental damage. There are no other express warranties other than those stated herein.
- This warranty gives you specific legal rights, and you may also have other rights which varies from state to state.
- TO OBTAIN SERVICE PLEASE E-MAIL US ON**  
[help@future-call.com](mailto:help@future-call.com) OR CALL US TOLL FREE  
1-888-934-CALL 9AM-6PM PST (1-888-934-2255). IF THE UNIT IS UNDER WARRANTY PROOF OF PURCHASE MUST BE PROVEN.

16