


### PV-ezRack<sup>®</sup> ezShade™

Code-Compliant Planning and Installation V2.3 Complying with AS/NZS1170.2:2011 AMDT 2-2012



# Introduction



### **1. Introduction**

Clenergy PV-ezRack<sup>®</sup>ezShade<sup>™</sup> is a preassembled ground mount system suitable for large scale commercial and utility scale installations. PV-ezRack<sup>®</sup>ezShade<sup>™</sup> has been developed to fit any PV module. The innovative and patented T-Rails simplify and improve the accuracy of the installation. Using high quality engineered components PVezRack<sup>®</sup>ezShade<sup>™</sup> saves developers and installers, time and money when delivering large scale projects.

Please review this manual thoroughly before installing your PV-ezRack<sup>®</sup>ezShade<sup>™</sup>system. This manual provides

 Simple introduction of the installation relating to PV-ezRack<sup>®</sup>ezShade<sup>™</sup> Mounting systems.
Planning and installation instructions for PVezRack<sup>®</sup>ezShade<sup>™</sup>.

PV-ezRack<sup>®</sup>ezShade<sup>™</sup>parts, when installed in accordance with this guide, will be structurally sound and meet the AS/ NZS 1170.2:2011 (R2016) standards. During installation and especially when working on the roof, please comply with the appropriate safety regulations, and please also comply with the relevant regulations of your local region.

### List of Contents

Introduction	01
Planning	02
Tools &Components	08
System Overview	10
Installation Instruction	13
Certification Letter with Concrete	30
Footing Options for ezShade	

Please check that you are using the current version of the Installation Manual by contacting Clenergy Australia by email on tech@ clenergy. com.au, or your local representative.

#### The installer is solely responsible for:

- Complying with all applicable local or national building codes, including any that may supersede this manual;
- Ensuring that PV-ezRack and other products are appropriate for the particular installation and the installation environment;
- Using only PV-ezRack parts and installer supplied parts as specified by PV-ezRack (substitution of parts may void the warranty and invalidate the letter of certification on page 2);
- Recycling: Recycle according to the local relative statute.
- Removal: Reverse installation process.
- Ensure that there are no less than two professionals working on panel installation.
- Ensure the installation of all electrical equipment is performed by licensed electricians.
- Ensuring safe installation of all electrical aspects of the PV array. This includes providing adequate earth bonding of the PV array and PV-ezRack<sup>®</sup>ezShade<sup>™</sup> components as required in AS/NZS 5033-2014 AMDT 2 2-20.

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)


I/10 Duerdin Street, Clayton VIC 3168 Australia Fel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.a page 01 of 30




### 2. Planning

#### - Side View

Below are the side view drawings of support for 60 cell panels (up to  $1700 \times 1050$  mm) and 72 cell panels (up to  $2108 \times 1050$  mm) at 5° tilt angle.






#### **Location Plan of Anchors**

Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.ar




#### - Front View

Below are the front view drawings of support for 60 cell panels (up to  $1700 \times 1050$  mm) and 72 cell panels (up to  $2108 \times 1050$  mm)



### Front view drawings of single bay for 60 cell panels (up to 1700x1050 mm)




Front view drawing of double bay with <u>5500 mm</u> <u>span</u> for 60 cell panels (up to 1700 x 1050 mm)


Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.a






#### Front view drawing of double bay with <u>6000 mm</u> <u>span</u> for 60 cell panels (up to 1700 x 1050 mm)




### Front view drawings of single bay for 72 cell panels (up to 2108x1050 mm)

Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clene<u>rgy.com.au www.clenergy.com.a</u>





#### Front view drawing of double bay with <u>5500 mm</u> <u>span</u> for 72 cell panels (up to 2108 x 1050 mm)



Front view drawing of double bay with <u>6000 mm</u> <u>span</u> for 72 cell panels (up to 2108 x 1050 mm)

NOTE:

1. Double bay ezShade with <u>5500 mm span</u> is not for car packing facility;

2. 20 mm gaps between panels are for dry bars. If not using dry bars, it is not necessary to leave 20 mm gaps.

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.a



### **Cutting the Dry-bars**

This part is only relevant if using the ezShade watertight kits.

Clenergy ezShade Watertight Kit is designed based on the dimension of  $1700 \times 1050$  mm for 60 cell panels and  $2108 \times 1050$  mm for 72 cell panels. The top range dimension is to make the watertight kit more universal for different panels. For the panels having smaller length or width, three components need to be cut to be suitable for the panel dimensions.

#### 1. Dry Bar-Portrait (ER-B-P)

The length of Dry Bar-Portrait in Watertight Kit is 5405mm. The required length is calculated as, n\*W + (n-1)\*22 + 67 (mm); in which, n is the number of rows of panels; W is the panel width;

In case of 5 rows (standard configuration), the required length of Dry Bar-Portrait is 5\*W+155 (mm).

For example, the length of Dry Bar-Portrait is 5\*992 + 155 =5115 mm for 992mm wide panel with the length of 290 mm cut.


# Note: please cut the Dry Bar-Portrait and its attached rubber together, and make sure the cut is straight.

#### 2. Dry Bar – Landscape (ER-B-L)

The length of Dry Bar – landscape in Watertight Kit is 1687mm for 60 cell panel kit and 2095 mm for 72 cell panel kit. The required length is calculated as,

L-13 (mm); L is the panel length;

Using 1650 mm long panels as an example, the length of Dry Bar – landscape is 1650-13=1637 mm with the length of 50 mm cut. It is recommended to cut at both ends of dry bar to keep T bolts symmetrical distribution on the bar.




When the PV panel is between 1700 and 1800 mm long, it needs to use 72 cell panel kit with 2095 mm long dry bar – landscape. The dry bar needs to be cut at one end only and one of T bolts will be cut off with dry bar. The remaining  $4 \times T$  bolts still can maintain sound watertight function.

Note: please cut the Dry Bar – landscape and its attached rubber and make sure the cut is straight.

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.au






#### 3. Top Cover for Landscape Dry Bar (ER-CAP-B/L)


The length of Top Cover for Landscape Dry Bar in Watertight Kit is 1687mm for 60 cell panel kit and 2095 mm for 72 cell panel kit. The required length is calculated as,

L-13 (mm) L is the panel length;

Using 1960 mm long panels as an example, the length of Dry Bar – landscape is 1960-13 = 1947 mm with the length of 148 mm cut.



Note: Two wings of the Top Cover for Landscape Dry Bar need to cut 15 mm more at both ends (see the image below).



#### **Concrete Footing Options**


Please refer to the Certification Letter with Concrete Footing Options for ezShade. If a project specific Certification Letter has been provided, please refer to the footing info. in this letter.

Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.au

# Tools & Components



#### 3. Tools and Components 3.1 Installation Tools



Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

10 Duerdin Street, Clayton VIC 3168 Australia l: +61 3 9239 8088 Fax: +61 3 9239 8024 mail: sales@clenergy.com au www.clenergy.com a page 08 of 30

# Tools & Components



#### **3.2 Components**

**ER-R-T150** T-Rail 150



RT-100/90

Rectangular Tube



U-AP/TR

Plate 300/380

ER-B-150 Main Support Beam



ER-MC-40

40 mm

ER-B-P

Module Clamp

ER-SP-B150 Splice for Main Support Beam



ER-B-L/A Dry Bar-Landscape ER-RC-T/G Rail Clamp for T Rail with Grounding



ER-B-L Dry Bar-Landscape (with Bushing)



ER-CAP-B/L Top Cover for Landscape Dry Bar ER-CC-B/L

Trapezoidal U-anchor

Cross Connection for Dry Bar-Landscape



Dry Bar-Portrait

ER-B-T6/L T bolt kit M6\*L



ER-CAP-B/P End Cap for Portrait Dry Bar



ER-CAP-B/L End Cap for landscape Dry Bar



ER-CAP-T150/PA Cap for T-150 Rail

Rail Cap for Beam

ER-CAP-B150/PA Cap for Composite Beam

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 09 of 30


1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.ai

# System Overview



### 4. System Overview

#### 4.1 Overview of PV-ezRack ezShade



① Main Support Beam, 150\*L

- ② Splice for Main Support Beam
- ③ T-Rail 150\*L
- ④ Splice for T-150 Rail
- 5 Rail Clamp for T Rail
- 6 Rectangular Tube 100\*90\*L
- ⑦ Corrugated U-anchor Plate 300
- 8 Corrugated U-anchor Plate 380
- 9 Top Cover for Landscape Dry Bar
- ① Dry Bar-Landscape(with Bushing)

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 10 of 30

1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.a

# System Overview



End Cap for Portrait Dry Bar
T-bolt kit M6\*L
Dry Bar-Portrait
Cross Connection for Dry Bar
Dry Bar-Landscape
End Cap for Dry bar-landscape
Cap for T-150 Rail (PA6)
Cap for Composite Beam (PA6)
Module Clamp 40 mm (in use when Dry bars are not used)

#### 4.2 Precautions during Stainless Steel Fastener Installation

Improper operation may lead to deadlock of Nuts and Bolts. Follow the steps below to reduce this risk.

- 4.2.1 Reduce the friction coefficient:
- ① Ensure that the thread surface is clean (no dirt or contaminants)

(2) Apply lubricant (grease or 40# engine oil) to fasteners prior to tightening to avoid galling or seizing in the threads;


4.2.2 General installation instructions:

- ① Apply force to fasteners in the direction of thread;
- (2) Apply force uniformly, to maintain the required torque;
- ③ Professional tools and tool belts are recommended;
- ④ Avoid using electric tools for final tightening;
- (5) Avoid working at high temperatures;
- 4.2.3 Safe Torques

Please refer to safe torques as shown below. In case power tools are required, Clenergy recommends the use of low speed only. High speed and impact drivers increase the risk of bolt galling (deadlock). If deadlock occurs and you need to cut fasteners, please make sure that there is no load on the fastener before you cut it. Avoid damaging the anodized or galvanized surfaces.

# System Overview





4.2.4 These steps should be applied for every stainless steel nut and bolt assembly.

#### **4.3 Installation Dimensions**

All drawings and dimensions in this installation guide are for a generic reference. PV-ezRack<sup>®</sup> ezShade<sup>™</sup> is to be optimized to suit specific conditions for each project and documented in a construction drawing. As a result, major components of PV-ezRack<sup>®</sup>ezShade<sup>™</sup> may be provided in section sizes and lengths that vary from those shown in this guide. The installation process detailed in this instruction guide remains the same regardless of the component size. In case you need to do any on-site modification or alteration of the system in a way that would be different from the construction drawing please provide marked up drawings/sketches for Clenergy's review prior to modification for comment and approval.

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)



### 5. Installation Instruction

#### 5.1 Post and Main Beam Installation


#### 5.1.1 Embed 2 pcs of M20 bolt

Mark out the positions for bolts and embed 2 pcs of M20 bolt in each position as shown in Fig 1.

Make sure all M20 bolts are aligned in both horizontal and vertical direction as shown in Fig 2. Make sure all M20 bolts are aligned in both horizontal and vertical direction.


The distance between two bolts for Trapezoidal U-anchor Plate 300 and 380 is 200mm and 280mm respectively. All embedded bolts will be revealed 60mm~80mm above the ground as shown in Fig 1.

Note: The M20 bolts and matching nuts, washers and spring washers are provided by installer.



#### 5.1.2 Fix the Rectangular Tubes into the Trapezoidal U-anchor Plate

Place the Rectangular Tube into the Trapezoidal U-anchor Plate 300, align the holes and place bushing in one hand and put on M16 bolts in the other hand, then put on flat washers, spring washers, nuts and lock manually. Place the other two Rectangular Tube into the Trapezoidal U-anchor Plate 380 one by one, align the holes and place bushing in one hand and put on M16 bolts in the other hand, then put on flat washers, spring washers, nuts and lock manually as shown in Fig 3. Please refer to the engineering drawings for the size of the Rectangular Tube. Recommended Torgue: M16: 100~105 N




Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 13 of 30



#### 5.1.3 Fix the Main Support Beam

Slide 6 sets of M8 Cup head square neck bolts along the half slot of each Main Support Beam. Fasten each Splice for Main Support Beam with two sets of M8 bolt assembly slightly by Socket Spanner 13mm. Take the other Main Support Beam and fix it with Splices by the above steps. Do not fasten the M8 bolts tightly before the end faces of Main Support Beams aligned as shown in Fig 4.




#### 5.1.4 Fix the assembled Main Beam into Rectangular Tube

Insert the assembled Main Beam into Rectangular Tube, align the holes and fasten with M16 Bolts assembly by Socket Spanner 24mm as shown in Fig 5. Double-check all bolts are fastened tightly.

Note: Laying down the Main Beam and Rectangular Tube on ground will be easier to assemble. Please note that grease must be applied and tool speed must be controlled while fastening the bolts.





Recommended Torque: M16: 100~105N·m



Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 14 of 30

## Installation Instruction




#### 5.1.5 Fix the assembled Main Beam & Rectangular Tube onto Ground/Concrete

Insert the assembled Rectangular Tubes with Main Beams into embedded bolts. Adjust the Trapezoidal U-anchor Plate to make the lower end faces of all Main Beams aligned in one array as shown in Fig 6, 7 and 8. Now fasten the Trapezoidal U-anchor Plate with M20 Bolts assembly tightly.

Please note that grease must be applied and tool speed must be controlled while fastening the bolts.

Recommended Torque: M20: 200~220 Nm

The up-down adjustable range of the Front/Rear leg is  $\pm 24$ mm.The north-south adjustable range of the Front/Rear leg is  $\pm 8$ mm.






Fig. 6




Fig. 8

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 15 of 30

1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.ai


# Installation Instruction



#### **5.2 Rail Installation**


#### 5.2.1 Fix the Rail splice into T Rail

In order to form a longer section, Splices may be used to join two T Rails. Insert Splice halfway into end of first T Rail, apply Corrugated Shim on outside and fasten using self-drilling screws. Slide second T Rail over splice, apply Corrugated Shim on outside and fasten using self-drilling screws as shown in Fig 9. Note: Make sure the Corrugated Shim can match well with the corrugated face of T Rail.



#### 5.2.2 Fix the T Rail onto Main Beam

Place the T Rail on the assembled Main Beam as shown in Fig 10. Apply Rail Clamp to fix the T Rail on the assembled Main Beam and fasten Rail Clamps by Allen Key 6mm as shown in Fig 11.






Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)


page 16 of 30

Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.a





#### Note: the installation positions of T-Rail as shown in Fig 13.



Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 17 of 30




#### 5.2.3 PV Module Installation

Place the first row of PV Module on the T-rail as shown in Fig 14.

Make sure that the long side of the PV Module is parallel to the T-rail. Install the next module which aligns to the first one.

Repeat this step until the last panel is finished and make sure the end face of PV modules are aligned as shown in Fig 15.






Fig. 15



#### 5.2.4 Fix the Dry Bar-Landscape

After PV Module installation, place the Dry Bar-Landscape & Dry Bar-Landscape (with Bushing) into T-rail as shown in Fig16.

Note: Cut off the extra Rubber for Dry Bar by scissor. The Dry Bar-Landscape with Bushing should be placed on the first and last row as shown in Fig 16.




Fig. 16

Click the Dry Bar-Landscape or Dry Bar-Landscape (with Bushing) into the U slot of T-rail. Make sure the T head bolt slide into the groove of T-rail as shown in Fig 17.




Fig. 17

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 19 of 30



Maintain 6mm gap between the PV Module and Dry Bar-Landscape/ Dry Bar-Landscape (with Bushing) as shown in Fig 18.




Fig. 18

Turn the T head bolt clockwise with Straight-slot Screwdriver until the T head bolt can't move anymore as shown in Fig 19.


Fasten M6 Nuts and T head bolts with Socket Spanner 10mm tightly.


Note: Please note that grease must be applied and tool speed must be controlled while fastening the bolts.


Recommended Torque: M6 Bolts: 7~8 N·m

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)











Repeat the above operations to install the second row of PV Modules as shown in Fig 20.

#### Note:

Maintain 20mm gap between the first row and the second row. And ensure the end faces of PV Modules are aligned.





Fig. 19(the first and last row)



page 21 of 30

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)



Repeat the above operations to fix the Dry Bar-Landscape or Dry Bar-Landscape (with Bushing) as shown in Fig 21.

#### Note:

Maintain 6mm gap between the PV Module and Dry Bar-Landscape/ Dry Bar-Landscape (with Bushing). Maintain 32mm gap between two Dry Bar-Landscape as shown in Fig 21.




Fig. 21

#### 5.2.5 Fix the Cross Connection for Dry Bar

Place the Cross Connection for Dry Bar between the two adjacent Dry Bar-Landscape as shown in Fig 22.




Fig. 22

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 22 of 30



#### 5.2.6 Fix the Dry Bar-Portrait

Place the Dry Bar-Portrait between two adjacent rows of PV modules as shown in Fig 23.

Note:

Cut off the extra Rubber for Dry Bar by scissor.

Slide the T-bolt kit into groove of Dry Bar-Portrait, and turn the kit clockwise until it can't move anymore as shown in Fig 23.

Fasten M6 Nuts and T head bolts with Socket Spanner 10mm tightly as shown in Fig 23.





Fig. 23

Note: Please note that grease must be applied and tool speed must be controlled while fastening the bolts.

Apply 4 sets T bolt kit between Two PV Modules as shown in Fig 24.

Recommended torque: M6 bolts is 5-6 N·m


Repeat the above steps until the whole array installation is completed as shown in Fig 25.



Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)


page 23 of 30





#### 5.2.7 Accessory Installation

Click the Top Cover for Landscape Dry Bar into the U slot of the Dry Bar-Landscape as shown in Fig 26.






Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

page 24 of 30



Click the End Cap for Portrait Dry Bar into the groove of Dry Bar-Portrait as shown in Fig 27.



#### 5.2.8 Seal the space between the Dry Bar

Seal the space between the Dry Bar-Landscape and Dry Bar-Portrait with Weatherproof Neutral Silicone Sealant as shown in Fig 28.





Fig. 28




Seal the space between the T-Rail and Dry Bar-landscape with weatherproof Neutral Silicone Sealant as shown in Fig 29.

Direction to be glued: Along the T-Rail.






Distance to be glued: From the left end face to the right end face of T-Rail 150 as shown in Fig 30.





Install End Cap into Dry Bar-landscape as shown in Fig 31.





Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)



#### 5.3 PV Module Installation (without Dry Bars)


#### 5.3.1 Same with step

#### 5.3.2 Fix Module Clamp 40 to PV frame

After all PV Modules are placed properly, use the Module Clamp 40 to fix the back frame of PV Module on T-Rail, and fasten with 6mm Allen Key as shown on the Fig 32.

#### Note:

- 1. Apply 4 x Module Clamps 40 for each PV Module.
- 2. Please refer to the PV module installation instruction to confirm the clamping zones. It is recommended that the installation position of Module Clamp 40 from the PV module end to the clamps is 20% of module length (if not conflicted with the clamping zone of panels) as shown in Fig 33.
- 3. Recommended torque: M8 bolts is 18-20 N·m



#### Fig. 32




Fig. 33

# Installation Instruction



#### 5.3.3 Notes for Module Clamp 40 installation

Module Clamp 40 is only applicable for the panels whose underside frame width A is not less than 23mm and B is equal or less than 11mm (as shown in the figures below). Please consult the PV panel manufacturer to have this info. before the ezshade system order and installation.




Fig. 34

#### 5.4 How to Achieve Earthing for ezShade System

#### 5.4.1 Module Clamp 40

When using ezShade without Dry-bar solution, Module Clamps 40 not only provide the fixing function for the panels, but also create earthing continuity between the PV panels and the T-Rail 150.

For ezShade with Dry-bar solution, Module Clamps 40 are also needed to create the earthing continuity between the PV panels and the T-Rail 150. It is recommended that 2 x Module Clamps 40 per panel are used (one for each long side of panel as shown in the Fig 35).




Fig. 35

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

I/10 Duerdin Street, Clayton VIC 3168 Australia ēl: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenerov.com.au www.clenerov.com.au



5.4.2 Rail clamp with grounding pins and earthed z module (as shown in the figure below) is used for creating earthing continuity between the T-Rail 150 and the Main Support Beams.

Rail clamp with earthed z module is used for creating earthing path between the T-Rail 150 and the Main Support Beam. The red circles in below figure emphasize the pins on Rail clamp and Z-Module.





Fig.36

#### 5.4.3 Set Screws

Set screws of M8 on the Main Support Beam are needed to be fastened (recommended torque: 4.5-5.5N·m) to achieve the grounding function from the Main Support Beams to the Rectangular Tubes (see the figure below).





Now the ezshade system has achieved the earthing continuity from the PV panels to the support tubes. The installer is responsible for the earthing connection from the ezShade to the ground.

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)



# Certification Letter with Concrete Footing Options for ezShade

Installation Guide\_PV-ezRack\_ezShade\_AU\_V2.3 (September 2020)

I/10 Duerdin Street, Clayton VIC 3168 Australia [el: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.ar page 30 of 30



info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

2 December 2019

Clenergy Australia 1/10 Duerdin Street Clayton, VIC 3168

### **CERTIFICATION LETTER**

Clenergy PV-ezRack ezShade Certification – TC 2.5, 3 – Wind Region A, B and C. Internal REF: 00150.

MW Engineering Melbourne, being Structural Engineers within the meaning of Australian regulations, have calculated the maximum spacings for the PV ez-Rack rail system for the following conditions:

- Wind Loads to AS 1170.2-2011 AMDT 4-2016
  - Wind Terrain Category 2.5 and 3
  - Wind average recurrence of 200 years
  - Wind Region A, B and C
- Solar panel length up to 2108 mm for 72 cell panels
- Solar panel length up to 1700 mm for 60 cell panels
- Solar panel width up to 1050 mm for 72 cell panels and 60 cell panels

Attached are the tables showing the spacings and footing configuration according to Wind Region and Terrain Category.

The values shown on these tables will be valid unless an amendment is issued on any of the following codes:

- AS/NZS 1170.0- 2002 AMDT 4-2016
- AS/NZS 1170.1- 2002 AMDT 4-2016
- AS/NZS 1170.2- 2011 AMDT 4-2016
- AS/NZS 1664.1- 1997 AMDT 1:1999
- AS 4100- 1998
- AS/NZS 1252.2-2016

General Principles Imposed Loadings Wind Loadings Aluminium Code Steel Structures Bolting

Should you have any queries, do not hesitate to contact us.

Best Regards,

A

Alberto Escobar Civil/Structural Engineer **BEng MIEAust NER** BRP EC 46542 RPEQ 18759 info@mwengineering.melbourne



ezShade Engineering Certificate CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

### STRUCTURAL DESIGN DOCUMENTATION

### PV-ezRack ezShade Design Tables According to AS/NZS 1170.2:2011 Amdt 4-2016 Within Australia Terrain Category 2.5 and 3

Client : Clenergy Australia

REF: CL-360-MW

Date: 29/11/2019

Copyright: The concepts and information contained in this document are the property of MW Engineering Melbourne. Use or copying of this document in whole or in part without the written permission of MW Engineering Melbourne constitutes an infringement in copyright.

Limitation: This report has been prepared for the exclusive use of Clenergy Australia, and is subject to and issued in connection with the provisions of the agreement between MW Engineering Melbourne and Clenergy Australia. MW Engineering Melbourne accepts no liability or responsibility whatsoever for any use of or reliance upon this report by any third party other than Clenergy's clients.



ezShade Engineering Certificate CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

Internal REF: 00254

Client: Clenergy Australia

Project: PV-ezRack ezShade Certificate

Australian Standards

AS/NZS 1170.0:2002 (R2016) AS/NZS 1170.1:2002 (R2016) AS/NZS 1170.2:2011 (R2016) AS/NZS 1252.2:2016 AS/NZS 1664.1:1997-Amdt General Principles Imposed loadings Wind Loadings Bolting Aluminium

Wind Terrain Category 2.5 and 3

Designed: AE

Date: Nov-19

Disclaimer: From the date of publication onwards, any amendment made to any of the above mentioned Standards will make this report outdated and a new one will have to be released, unless the amendment has no implications on this certificate.



CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

### ezShade Engineering Certificate

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

#### PV-ezRack ezShade Type: 5°, Single-Bay for 60-Cell Panels (15 panels)

		SLAB OPTION						
		JLAD	OPTION	Fron	t Leg	Back	c Leg	
Wind Region	Terrain Category	Minimum Slab Thickness required (mm) (T)	Minimum Slab Reinforcement	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum Hold- down Bolt Rating (kN)
А	3	100	SL72 Top	600	400	400	400	2
А	2.5	100	SL72 Top	600	400	400	400	3
В	3	100	SL72 Top	600	400	400	400	7
В	2.5	100	SL72 Top	600	400	400	400	9
С	3	100	SL72 Top	600	500	400	400	14

\* According to drawing PZ27-0-022-10 from Clenergy (Xiamen) Technology Co. ,Ltd.

PV-ezRack ezShade Type: 5°, Double-Bay for 60-Cell Panels (25 panels)

		SLAB OPTION		Front Leg		Back Leg		
Wind Region	Terrain Category	Minimum Slab Thickness required (mm) (T)	Minimum Slab Reinforcement	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum Hold- down Bolt Rating (kN)
А	3	150	SL92 Top	1000	400	400	400	3
А	2.5	150	SL92 Top	1000	400	400	400	5
В	3	150	SL92 Top	1000	500	400	400	12
В	2.5	150	SL92 Top	1000	500	400	400	14

\* According to drawing PZ27-0-023-10 from Clenergy (Xiamen) Technology Co. ,Ltd.



CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

ezShade Engineering Certificate info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

PV-ezRack ezShade Type: 5°, Single-Bay for 72-Cell Panels (15 panels)

		SLAB OPTION		Front Leg		Back Leg		
Wind Region	Terrain Category	Minimum Slab Thickness required (mm) (T)	Minimum Slab Reinforcement	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum Hold- down Bolt Rating (kN)
А	3	125	SL82 Top	600	400	400	400	2
А	2.5	125	SL82 Top	600	400	400	400	3
В	3	125	SL82 Top	600	400	400	400	9
В	2.5	125	SL82 Top	600	400	400	400	11

\* According to drawing PZ27-0-024-10 from Clenergy (Xiamen) Technology Co. ,Ltd.

PV-ezRack ezShade Type: 5°, Double-Bay for 72-Cell Panels (20 panels)

		SLAB OPTION						
		SLAD (	DETION	Fron	t Leg	Back	c Leg	
Wind Region	Terrain Category	Minimum Slab Thickness required (mm) (T)	Minimum Slab Reinforcement	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum depth for a 450mm diameter Pad (mm) (H)	Minimum depth for a 600mm diameter Pad (mm) (H)	Minimum Hold- down Bolt Rating (kN)
А	3	150	SL92 Top	1000	400	400	400	3
А	2.5	150	SL92 Top	1000	400	400	400	5
В	3	150	SL92 Top	1000	500	400	400	12
В	2.5	150	SL92 Top	1000	500	400	400	14

\* According to drawing PZ27-0-025-10 from Clenergy (Xiamen) Technology Co. ,Ltd.



Note

Project: CL-Client: Clenergy Australia

ezShade Engineering Certificate CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

### **General Notes**

Note 1 Minimum Soil capacity for Slabs and Piers to be 100kPa. Installer must verify capacity or contact a Geotechnical Engineer for the assessment

Note 2 This Engineering Document was designed to cater for most common installation scenarios however, it does not cater for all of them. Contact Clenergy if you are unable to comply with any of the installation specifications listed on this document.

Component	Part No.	Description		
T150 rail	ER-R-T150	T150 rail		
T 150 rail splice	ER-SP-T150	T150 rail splice		
Support	RT-100/90	Rectangular tube support		
Beam	ER-B-150	Main support beam		
Beam splice	SPIII-B150	Beam splice		
U anchor plate	U-AP/TR/380	U anchor plate		
U anchor plate	U-AP/TR/300	U anchor plate		
Rail clamp	ER-RC-T	Rail clamp		
Module clamp	EX-GC-MC40	Module clamp		
Dry bar	ER-B-L	Dry bar-landscape		

- Note 4 For Terrain Category (TC) definition, please refer to clause 4.2.1 of AS/NZS 1170.2:2011 (R2016).
- Note 5 Maximum permitted rail overhang of 40% for the T150 rails.
- Note 6 The tables in this certificate are for a single or double bay ezShade. For multiple bay installation, please contact Clenergy.
- Note 7 From the date of publication onwards, any amendment made to any of the above mentioned Standards will make this report outdated and a new one will have to be released, unless the amendment has no implications on this certificate.
- Note 8 All components from Clenergy must be installed according to manufacturer's specification and the instructions shown in the relevant installation manual. Please check the Clenergy Australia website or contact them for access to the most recent installation manuals.
- Note 9 No consideration has been taken on the effect of snow loads. In case the roof is located in a snow prone area, a special design must be made.
- Note 10 Minimum spacing between supporting frames to be 3500mm.



ezShade Engineering Certificate CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

### **General Notes (Continued)**

- Note 11 Minimum Soil capacity for Slabs and Pads to be 100kPa. Installer must verify capacity or contact a Geotechnical Engineer for the assessment
- Note 12 Frames must be protected against impact loadings according to AS 1170.1, by using bollards or any other protective system
- Note 13 If the footing is raised the elevation above ground for individual pier footings must not exceed 400 mm (h in figure 3). Refer to Clenergy for reinforcement details.
- Note 14 Maximum hole size for cable management on girder/rail to be 40mm. To be located at the third of the girder/rail span between support points as per image below



- Note 15 If significant Sway displacement is noticed after the installation. Contact Clenergy to verify that the installation procedure has been followed correctly
- Note 16 This structure was not designed for Earthquake considerations. If installing this in a seismicprone area, please contact Clenergy for further provisions on bracing installation
- Note 17 Concrete footings/slab must have a minimum capacity of 25MPa
- Note 18 Reinforcement for the footings/slab (if required, figures 1 and 3) must have a minimum yield strength of 420MPa
- Note 19 Maximum spacing for saw cuts in new slabs to be 5000mm on both directions
- Note 20 Ratings for the hold-down bolts are for a single bolt. Consult manufacturer for bolt capacitites.

#### Note 21 Maximum spacing between two legs as per the below table:

PV-ezRack ezShade Type: 5°, Single-Bay for 60-Cell Panels (15 panels)	PV-ezRack ezShade Type: 5°, Double-Bay for 60- Cell Panels (25 panels)	PV-ezRack ezShade Type: 5°, Single-Bay for 72- Cell Panels (15 panels)	PV-ezRack ezShade Type: 5°, Double-Bay for 72- Cell Panels (20 panels)
3500 mm	6000 mm	4200 mm	6000 mm



### ezShade Engineering Certificate

CIVIL & STRUCTURAL ENGINEERS RESIDENTIAL - INDUSTRIAL - COMMERCIAL - PRODUCT DEVELOPMENT

info@mwengineering.melbourne Phone: 1300 MWENG-0 (1300 69364-0) www.mwengineering.melbourne ABN 37 605 815 585

Note 22 The length (L) and Width (W) of the concrete slab to be as per the below table. Refer to concrete relevant standards to specify the minimum expansion joints needed in the slab.

Type: 5°, for 60-Cell	k ezShade Single-Bay Panels (15 iels)	5°, Double	zShade Type: e-Bay for 60- (25 panels)	5°, Single	zShade Type: -Bay for 72- (15 panels)	5°, Double	zShade Type: e-Bay for 72- (20 panels)
L (mm)	W (mm)	L (mm)	W (mm)	L (mm)	W (mm)	L (mm)	W (mm)
5200	5592	8700	5592	6400	5592	8700	5592





Figure 1. Slab foundation







Figure 2. Individual pier foundation






Figure 3. Elevated above ground individual pier foundation



#### **Clenergy Australia**

1/10 Duerdin Street, Clayton VIC 3168 Australia Tel: +61 3 9239 8088 Fax: +61 3 9239 8024 E-mail: sales@clenergy.com.au www.clenergy.com.au

#### **Clenergy China**

999-1009 Min'an Rd, Huoju Hi-tech Ind. Dev. Zone Xiang'an District 361101, Xiamen, Fujian, China Tel: +86 592 311 0088 Fax: +86 592 599 5028 E-mail: sales@clenergy.com.cn www.clenergy.com.cn

#### **Clenergy EMEA**

Esplanade 41, 20354 Hamburg, Germany Tel: +49 (0) 40 3562 389 00 E-mail: sales.emea@clenergy.com

#### **Clenergy Japan**

Nittochi Yamashita Building 5th Floor 23 Yamashita-cho, Yokohama, 231-0023 Japan Tel: +81 45 228 8226 Fax: +81 45 228 8316 E-mail: sales@clenergy.co.jp www.clenergy.jp

#### **Clenergy Philippines**

145 Yakal St., San Antonio village, Makati City, Philippines Tel: +63 977 8407240 E-mail: sales\_ph@clenergy.com www.clenergy.ph



Clenergy Installation Guide PV-ezRack<sup>®</sup> ezShade<sup>™</sup> AU\_V2.3 (September 2020)

#### **Clenergy Thailand**

9/2, 5th Floor, Vorasin Building, Soi Yasoob 2, Viphavadee-Rungsit Road, Chomphon Sub-district, Chatuchak District, Bangkok 10900 Tel: +66 (0) 2 277 5201, +66 (0) 6 3228-0200 E-mail: sales\_th@clenergy.com, support\_th@clenergy.com www.clenergythailand.com

#### **Clenergy Singapore**

24 Raffles Place #28-01 Clifford Centre Singapore 048621 Tel: +65 9743 1425 E-mail: vincent.chan@clenergy.com

#### **Clenergy Malaysia**

Tel: +86 18750231005 E-mail: sales\_em@clenergy.com

#### **Clenergy Vietnam**

Tel: +86 592 3110095 E-mail: sales\_vietnam@clenergy.com; susie.chen@clenergy.com

### **Worldwide Network**

