


Simple Start Guide


kozii SafeHeat Pro

Do not operate Kozii Pro without water. This can cause permanent damage.

1. Set Kozii Pro on flat, stable surface, then plug in



2. Place basket into Kozii Pro




3. Place bottle or bag into basket



4. Pour in water (using the included filler, if desired) until bottle or bag starts to float, or until water level is 1/2 inch (13mm) below top edge of warming chamber, whichever happens first



5. Set timer (for estimated time, use warming time chart provided)



6. When time is up, remove bottle or bag by lifting basket from warming chamber

7. Always test temperature of bottle/bag contents on yourself before giving to child



Important to know, for best results

- The water in the warming chamber will become hot during use. Do not touch the water in the warming chamber during use, or for 30 minutes after use.
- It is **very important** to clean and de-scale Kozii Pro regularly!
- See the instruction manual for complete use, care, and cleaning instructions for Kozii Pro.
- If you have any issues or questions, email us at support@kiinde.com; we are quick to respond!

WARMING TIME CHART

Many factors affect the exact warming time for your child's meal. Please use this chart as a convenient starting point for determining the appropriate warming time for your specific meal type, container, and starting temperature. After only a couple of uses, you will learn exactly what the best warming times are for you. Always test the meal temperature yourself before offering it to your child.

IMPORTANT: If Kozii Pro feels warm around the base (from recent use), decrease warming time by 30 seconds. The timer may continue to tick for up to 30 seconds after Kozii has shut off. It is ok to remove the bottle or bag during this time.

Approximate Warming Time (in minutes)

Bottle type	Plastic bottle		Glass bottle		Bottle with liner		Breastmilk storage bag			Food jar**		Silicone bottle	
	Room	Fridge	Room	Fridge	Room	Fridge	Room	Fridge	Freezer*	Room	Fridge	Room	Fridge
2oz (60ml)	3	4.5	2	4	0.5	1	1	1.5	6*	5	6	3	6
4oz (120ml)	3.5	5	2.5	4.5	1	1.5	1.5	2	7*	6	7	4	7
5oz (150ml)	4	5.5	3	5	1.5	2	2	2.5	8*	7	8	5	8
6oz (180ml)	4.5	6	3.5	5.5	2	2.5	2.5	3	9.5*	8.5	9	6	8.5
8oz (240ml)	5	6.5	4	6	2.5	3	3	3.5	10.5*	9	10	7	9
9oz (270ml)	5.5	7	4.5	6.5	3	na	na	na	na	na	na	8	9.5

* When warming frozen milk, gently swirl the milk midway through the warming cycle to push down any frozen milk that may be trapped near the top of the bag or bottle. Massaging the top of the bag will also help push the ice down.

** When warming food jars, it is helpful to stir after half of the suggested warming time, then warm for the remainder of the time.

⚠ WARNING! NEVER LEAVE CHILD UNATTENDED WHILE FEEDING. ALWAYS USE WITH ADULT SUPERVISION. DO NOT MICROWAVE TWIST POUCHES.

Dear proud parents,

We hope you love your Kozii Pro!

Your feedback is important to us, so please email support@kiinde.com and let us know what you think. Also visit us at www.kiinde.com for more innovative, life-simplifying products for your little one and you.

Thank you!

The Kiinde team

kozii
SafeHeat Pro
Simple Start Guide