

How to use your Echo Mechanism



Echo Mechanism

Simple & unique button controls make this mechanism easy to use and ergonomic. This mechanism has been built with sustainability and ease of use in mind. Control your Seat height, seat depth and back angle adjustment all from the touch of the suited underside trigger buttons.

1) Adjustable Lumbar Panel

To increase the lumbar height; Reach around the mesh back to the rear of the chair and firmly grip the lumbar panel stem. Slide the lumbar panel upwards until the lumbar support reaches the desired position. To decrease the lumbar height; Reach around the mesh back to the rear of the chair and firmly grip the lumbar panel stem. Slide the lumbar panel downwards until the lumbar support reaches the desired position.

2) Seat Height Adjustment

To increase the seat height; Pull the underside trigger on the right side of the chair when seated and hold, whilst lifting your weight off the seat, allowing the seat height to increase. Release the lever to lock in place when the seat reaches your desired height. To decrease the seat height; Pull the underside trigger on the right side of the chair when seated and hold, whilst putting your weight on the seat, allowing the seat height to decrease. Release the lever to lock in place when the seat reaches your desired height.

3) Seat Depth Adjustment

To increase the seat depth; Pull the underside trigger on the back left side of the chair when seated and hold, whilst sliding your body forwards, allowing the seat depth to increase. Release the lever to lock in place when the seat reaches your desired position. To decrease the seat depth; Pull the underside trigger on the back left side of the chair when seated and hold, whilst sliding your body backwards, allowing the seat depth to decrease. Release the lever to lock in place when the seat reaches your desired position.

4) Back Angle Adjustment

To work in free-float mode; Pull the underside trigger on the front left side of the chair when seated and then release. The lever will automatically retract into its starting position, but the back will be unlocked, allowing you to work in freefloat mode. To lock the back in position; Pull the underside trigger on the front left side of the chair when seated and then release. Apply pressure to the back until you reach your desired position. Pull the lever outwards and release again to lock in that position. Please note that the back locks in 5 positions (including upright).

*** Please note that this product carries a maximum weight limit of 150kg ***