

Comfort Camp Pad


74in x 23in x 4.7in


INFLATE


1. Unroll camp pad and lay it flat on a clean surface with CORE logo face-up.



2. Locate and open valve to the "INFLATE" position (fig. 1).








6. Repeat steps 4 and 5 as needed until camp pad reaches preferred level of firmness. Once inflated fully, close valve.

TIP: If the camp pad feels too firm you can use the "Micro-Adjust" feature on the inflate valve to release small bursts of air from camp pad. To do this, open inflate valve to micro-adjust position and press down on the green trampoline for 1-2 seconds at a time until you find that just right level of comfort.



(fig. 1)

(fig. 3)

We've got you COVERED.

Our products feature a 1-year warranty. If you have any questions or product concerns, please contact us.



1-Year Limited Warranty VISIT:

coreequipment.com/pages/warranty

Need some help?


1-888-775-5628


 ✓ help@coreequipment.com coreequipment.com


> Scan to learn more and see detailed instructions




DEFLATE










3. Starting at the foot of the pad, opposite of the valve, begin tightly rolling the pad pressing the air out as you go (fig. 8).



- 4. Once rolled up, place camp pad into carry bag and cinch closed.
- 5. To pack pump sack, simply stuff back into designated compartment and cinch closed.



Flevate LLC Overland Park, KS 66223

Made in China