



Instructions for the Original Cougar Saddle and the Cougar Saddle with Batten Seat

Front View - Original Cougar Saddle



- a- Leg Straps
- b- Batten Seat
- c- Accessory Elastic Strap
- d- Ladder Lock
- e- Rope Bridge Adjustment Strap Buckle

Rear View - Cougar Saddle with Batten Seat



- f- Rope Bridge Adjustment Strap
- g- Side Dee
- h- Nylon Loop
- i- Elastic Loop
- j- Ring

- k- Rope Bridge
- l- Rubber Bumpers
- m- Leg Strap Buckle
- n- Leg Strap or Batten Seat Connector
- o- Rope Bridge Loop

To Replace the Rope Bridge or Rubber Bumpers: Disassembling the Cougar Saddle

1. Unlatch the Velcro® on the leg strap (a) or batten seat (b) and unbuckle the strap completely. Remove the slide that's on the quick-link buckle. Pull the leg strap through the leg strap connector (n), as shown in figure A. If completely removing to change from the leg straps (a) to the batten seat (b) or vice versa, flip the saddle over, remove the saddle's leg straps (a) or batten seat (b). First, undo the accessory elastic strap (c) by running it back through the ladder lock (d) on the saddle's back.
2. Repeat the same procedure with the other leg strap (a) or batten seat (b).
3. Unbuckle the buckle on the waist back for the rope bridge adjustment strap (e), as shown in figure B1. Pull the adjustment strap (f) through the side dee (g), through the nylon loop (h), through the elastic loop (i) and through the ring (j) on the rope bridge, as shown in figure B2.

figure A



figure B1



figure B2



- Repeat the same procedure with the other side of the rope bridge adjustment strap **(f)**.
- Now it's time to take apart the rope bridge **(k)**. Pull the rope bridge **(k)** through one end of the loop rope bridge section of the rope bridge (see figure C1) and through the ring **(j)** (see figure C2). Then, do the same with the other side. Now the rubber bumpers **(l)** will slide off.

figure C1



figure C2



Reassembling the Cougar Saddle

- Slide the rope bridge loop **(o)** through the ring **(j)**, then slide the opposite rope bridge loop **(o)** through the first rope bridge loop **(o)**, as shown in figure D, and pull tight.
- Slide the four rubber bumpers **(l)** on the rope bridge **(k)**.
- Now, slide the rope bridge loop **(o)** through the other ring **(j)**, then pull the opposite leg strap connector **(n)** with attached ring **(j)** through the rope bridge loop **(o)**. Please note: It is important when attaching the rope bridge **(k)** back to the saddle that the looped parts on each side of the rope bridge **(k)** are facing outward.
- Take the rope bridge adjustment strap **(f)** and run it back through the ring **(j)**, through the elastic loop **(i)**, through the nylon loop **(h)**, through the side dee **(g)** and through the buckle **(e)** on the waist back, as shown in figure E.
- Repeat the same procedure for the other side.
- Run leg strap or batten seat through the leg strap or batten seat connectors **(n)**, through the slide (that was removed) on the leg strap buckles or batten seat buckles and attach Velcro®. Make sure the elastic straps on the leg straps or batten seat are towards the saddle back and the buckle is on the outside.
- Repeat procedure on the other side.
- If leg straps or batten seat was completely removed, flip saddle over. Run the accessory elastic strap **(c)** back through the ladder lock **(d)** on the saddle's waist back. You'll run it through the first slot and back through the second slot.
- Repeat the procedure on the other side

figure D



figure E



Order Toll Free in the U.S. and Canada
 Phone: 800-932-8371
 Fax: 800-693-2837

Local and International
 Phone: 330-674-1782
 Fax: 330-674-0330

www.weaverleather.com