




Portable Reclining/Bleachers back Chair Instructions

- Enjoy your Reclining Chair at the beach, park, sporting events, camping, bleachers and more.
- Reclines in different positions, integrated arm rest for maximum comfort.
- Fold flat for minimal storage and easy transport. Adjustable backpack style shoulder straps.
- Can be used with or without armrest to create a larger seat.
- An Anti-slip water resistant bottom helps the seat stay in place.

Folding Chair with Armrest



1. Place chair horizontally facing up (straps facing upwards) and apply pressure on armrests with both hands.




2. Flip Chair over (straps facing down)




3. Hold bottom seat down, with one hand push chair's backseat forward to the desire angle.

Folding Chair without Armrest for more sitting surface




1. Place chair horizontally facing up (straps facing down) and apply pressure on armrests with both hands.




2. Hold bottom seat down, with one hand push chair's backseat forward to desire angle.

Straightening Chair Back or Lowering Reclining Position



1. Hold bottom seat down, with one hand. Push chair's backseat forward with other hand until reclining position is released.



2. Keep holding bottom seat down, with one hand. Push backseat down to a horizontal position or lower reclining position, with other hand.

