




See Everything, Miss Nothing

BM6



See Everthing, Miss Nothing

We hope you never have the need,
but if you do our service is friendly and hassle-free.

✉ support@czeview.net

Baby Monitor User Manual

CONTENTS

EN

MONITOR FUNCTION	P01
SET UP THE CAMERA ON THE APP	P07
• METHOD 2 SCAN QR CODE	P07
INSTALL THE CAMERA	P10
CONTROL THE CAMERA WITH ALEXA	P10
APP FUNCTIONS	P12
TROUBLESHOOTING	P28



MONITOR FUNCTION

• ROTATE THE CAMERA

Turn the camera horizontally or vertically using the direction button on the monitor once the camera is on.



• BRIGHTNESS ADJUSTMENT

On the monitor, press the 'Menu' button , then select  and press 'OK' to enter.

Use the 'Direction' button  to adjust the brightness level.



• PHOTO & VIDEO CAPTURE



Photos

Press Menu , select the camera icon , and press OK to snap a photo.

Videos

Press Menu , choose the camcorder icon , and press OK to start recording.


Viewing

1. Press Menu , select the file icon , and press OK.
2. Pick the camera and date, then select a photo or video and press OK to preview.

EN



•PLAY LULLABY

Press the Menu button (MENU) on the monitor, choose the musical note icon , and press OK to access the playback interface. Here, you can choose from three lullabies and white noise, switch the cycle mode, or adjust the music volume.



! Note:

Your baby can enjoy up to 14 lullabies via the APP. A micro SD card (up to 128GB) inserted into the camera slot is required for lullaby playback. For details, see 'PLAY LULLABY' under 'APP FUNCTIONS'.



•INDICATOR LIGHT ON/OFF

Press 'Menu' (MENU) on the monitor, select  and 'OK' to enter.


Use 'Direction' (DIRECTION) to toggle baby camera's indicator and night light.



•FEEDING REMINDER

On the monitor, press 'Menu' (MENU), and choose  > 'Feeding Reminder' .

Set up to 10 feeding times as needed. An alarm will display on the monitor when it's time to feed.




•TEMPERATURE AND HUMIDITY

Set a range to receive alerts and take action when temperature and humidity levels are outside your specified range.

On the monitor, press 'Menu' (MENU), and choose  < 'Temperature and Humidity' .

Define the temperature and humidity range, and activate the reminder as required. If levels fall outside the set range, an alarm will be shown on the monitor.




• SMART CARE



Receive alerts when motion or sound is detected, ensuring better care for your baby.

On the monitor, press 'Menu' (MENU), select 'Settings'  > 'Smart Care' .

There are three sensitivity levels available for both motion and sound detection. Each detection type has an individual alarm on/off function. When enabled, a corresponding alarm icon will appear in the center of the monitor screen, accompanied by an alarm sound. The volume of the alarm can be adjusted directly from the monitor screen.





• SLEEP MODE

Press 'Menu' (MENU) on the monitor and choose  > 'Sleep Mode' .

Configure the duration for screen and audio activity. Toggle the audio on or off. Specify a separate duration for the screen before it transitions to a restful screen state.



• CAMERA LIGHT

Press 'Menu' (MENU) on the monitor and select  > 'Camera Light' .



Toggle the indicator light on or off; choose from three different night light modes to soothe babies.




! Note:

For energy saving and environmental protection, the night light will automatically turn off after 30 minutes.



•SD CARD

Press 'Menu' (MENU) on the monitor and select  > 'SD Card' .

Check the SD card's capacity. Use a Micro SD card with a maximum capacity of up to 128GB. Format the SD card in the monitor before its first use to ensure smooth video storage.



•DEVICE INFORMATION

Press 'Menu' (MENU) on the monitor and select  > 'Device Information' .

Check for upgrades.




SET UP THE CAMERA ON THE APP

•Before starting, please note:


1. Ensure the camera is on and press the 'RESET' button for 5 seconds until the indicator light flashes red, signaling it's ready for WiFi connection.
2. When connecting to the app, the camera will temporarily disconnect from the monitor for approximately 2 minutes. Once the connection to the app is successful, the camera will automatically reconnect to the monitor.
3. Please ensure that the indicator light continues flashing red throughout the camera setup process in the app. If the connection attempt fails and the indicator light turns solid blue, Method II outlined below may not function properly. Ensure that the entire setup process is conducted while the indicator light is flashing red.

•II. METHOD 2 SCAN QR CODE

1. On the 'Home' page, tap 'Add' or  in the upper right corner to add a device.
2. Choose the correct type and model for your device from the list.




3. Follow the on-screen instructions, and tap 'Next'.
4. Select the same WiFi network your phone is connected to and enter the correct password.




5. Remove the film from the lens and ensure it is clean and free of dirt. After confirming the lens is clear, tap 'Next' to generate a QR code.



6. Hold the QR code 5-8 inches from the lens, directly in front of it, and scan. Listen for a 'cuckoo' sound, which indicates the connection process has begun. After this, tap 'Next'.



7. Confirm that the indicator light turns to a steady blue, indicating a successful setup. Following this, press 'Next' to assign a name to your camera.



INSTALL THE CAMERA

Use the included mounting bracket, screw pack, and the adhesive to position the camera in your desired location

! Note:


- To remove it from the mounting bracket, turn the camera counterclockwise.
- If your camera is mounted upside down, its picture shall also be rotated. Please go to 'Device Settings' > 'Image Settings' and turn on 'Screen Flip' to adjust the image(Only supports in-app changes).

CONTROL THE CAMERA WITH ALEXA


•Before starting, please note:

- Ensure the camera is powered on.
- Connect the camera to the CZView app.
- Install the Alexa app on your mobile device.
- Ensure a stable WiFi connection is established.


1. Log in to Alexa APP with your Amazon account, tap "More" in the bottom navigation bar and select "Skills & Games"
2. Tap the search bar and enter "CZView".




3. Choose 'ENABLE TO USE'.
4. Enter your CZView app email address and password.
5. Grant authorization when prompted.



6. Once the CZView app is successfully linked, tap 'Next'.
7. The app will then automatically navigate to a device-search interface. Wait for your device to connect.



8. Follow the on-screen instructions to complete the setup process.



! Note:

If you have an Echo device (compatible with all models of Echo Show), you can enable voice commands by following these steps:


- Log into your Echo device using the same Amazon account that is linked to your Alexa app.
- In the Alexa app, tap 'Devices' at the bottom and ensure your Echo Show is online.
- You can now use voice commands. For instance, say 'Alexa, show me BM2' (or the custom name you've assigned to your camera). Your Echo Show will respond to the command and display the camera's feed.


APP FUNCTIONS

• STORAGE AND RECORDING OPTIONS I. FOR USERS WITH SD CARD STORAGE:


! Note:


We recommend using a Micro SD card with a capacity between 8-128GB. For smooth video storage, please format the SD card in the app upon first use.

- Confirm that the SD card is properly inserted.
- On the Home page, locate your device and tap  located in the lower right corner of the window.
- Tap 'Recording Management'.
- Verify whether the app is correctly reading the SD card's capacity. If not, format the SD card within the app.
- Choose your preferred recording type from the available options.




• II. FOR USERS WITH A CLOUD STORAGE SERVICE:

1. On the Home page, locate your device and tap  located in the lower right corner of the window.
2. Tap 'Cloud Storage Service'.
3. Select a paid cloud storage plan (Event Cloud Storage or 24-hour Continuous Cloud Storage), or opt for the basic cloud storage as a trial.




• ADJUST VIDEO DEFINITION

1. In the video preview window on the home page, click ► to enter the live view.
2. Click the drop-down option in the lower right corner of the video window.
3. Select from the different definition levels available.




• ADJUST LENS ORIENTATION

1. In the live video window, locate the 'PTZ' button.
2. Use this feature to monitor in various directions.



• IMAGE SETTINGS

1. On the Home page, locate your device and tap ⚙️ located in the lower right corner of the window.
2. Tap 'Image Settings'.
3. Select your preferred Screen Orientation and Night Vision Mode.



•MANAGE ALARMS

! Note:

Before configuring "Alarm Management," please confirm whether you are using SD card storage, a paid cloud storage service, or a free basic cloud storage service. The type of storage you use will affect the format of the records displayed in the Alarm Messages (some records may be videos, while others may be images), and the availability of videos may vary:


1. For users with SD card storage:

- For the 24-hour continuous recording package, alarm recordings are provided as uninterrupted video streams, with alarm points clearly marked on the timeline in the Alarm Messages section. (The recording duration is fixed and cannot be modified.)


For the event recording package, alarm recordings are limited to 1-minute video clips, displayed in the Alarm Messages section. (The recording duration can be adjusted in Alarm Management.)

2. For users subscribed to a paid cloud storage service, alarm recordings vary depending on the selected package:

- For the 24-hour continuous recording package, alarm recordings are provided as uninterrupted video streams, with alarm points clearly marked on the timeline in the Alarm Messages section. (The recording duration is fixed and cannot be modified.)
 - For the event recording package, alarm recordings are limited to video clips of up to 30 seconds in the Alarm Messages section. (The recording duration is fixed and cannot be adjusted in Alarm Management.)
3. For users with free cloud storage, alarm recordings are 6-second videos in the Alarm Messages section. (The recording duration is fixed and cannot be adjusted in Alarm Management.)
4. For users without cloud storage or SD card storage, alarm records will be displayed as images in the Alarm Messages section.

- On the Home page, locate your device and tap  located in the lower right corner of the window.
- Access 'Alarm Management' settings.

- Motion Detection:** Enable motion detection to receive notifications based on your preferences, including detection sensitivity, record and alarm intervals, and custom alarm areas.





Noise Detection: Activate noise detection to receive alerts. Set the sensitivity of detection as needed.

! Note:


- Noise detection measures ambient sound in decibels (dB) and cannot detect specific areas.


• MOTION TRACKING

1. On the Home page, locate your device and tap  located in the lower right corner of the window.
2. Enable 'Motion Tracking' to allow the camera to follow your movement.





• PRIVACY MODE: DISABLE THE LIVE STREAMING

1. On the Home page, locate your device and tap  located in the lower right corner of the window.
2. Tap 'Privacy Protection'.
3. Turn off the lens or set a specific interval to disable live streaming and recording, ensuring your privacy and undisturbed moments.




• SHARING THE CAMERA WITH FAMILY

1. On the Home page, find the device you wish to share and tap  in the lower right corner of the window.
2. Select 'Device Share'.
3. For a quick setup, watch the video guide and then click 'Add'.
4. Use 'Scan QR Code' or 'Enter Account' to send an invitation.





5. If using QR code:


- Open the app on the invitee's phone.
- Tap 'Me' in the bottom navigation bar.
- Click on the avatar and select 'My QR Code'.






6. After scanning the QR code or entering the email address, set the permissions for the invitee in your app.
7. The invitee will receive a confirmation notification in their app.
8. After the invitee accepts the invitation for device sharing, their information will appear in the 'Device Share' section of your app.
9. The shared device will show up in the invitee's app home page.




• HOW TO DELETE THE INVITEE


1. On the Home page, find the shared device and tap  in the lower right corner.
2. Select 'Device Share'.



3. Click  in the upper right corner, then tap the DELETE icon . A confirmation prompt will appear.




4. The invitee will receive a notification in their app indicating they have been removed from the shared device list.




•HOW TO SET TEMPERATURE AND HUMIDITY ALARMS

- 1. Adjacent to the left side of the video definition dropdown menu, the temperature and humidity values are displayed. These are specifically designed to monitor and track the temperature and humidity conditions in your baby's room.
- 2. In the live video window, locate the 'Temperature & Humidity'.
- 3. Activate the alarm and establish the maximum and minimum thresholds for both temperature and humidity. This will enable you to receive alerts whenever the temperature or humidity levels in your baby's room, as detected by the baby unit, deviate from your preset ranges. For added convenience, you have the option to display the temperature on APP in either Fahrenheit (°F) or Celsius (°C).




•INTERCOM

- 1. In the live video window, locate the 'Original Sound'.
- 2. There are two additional sounds for interacting and playing with your baby.



3. Find the 'Intercom' and tap it to start talking to your baby.




•PLAY LULLABY

Note:


Before using the 'Play Lullaby' feature, please ensure that a Micro SD card is inserted (we recommend using an 8-128GB SD card, and please format it within the APP upon first use) to facilitate the download of lullabies to the card and ensure smooth music playback.

- 1. In the live video window, locate the 'Music'.
- 2. There are 10 lullabies available. To comfort your baby, tap the corresponding to the song you wish to play.



•NIGHT LIGHT

- 1. In the live video window, locate the 'Light Switch'.
- 2. Activate the light switch to access three distinct lighting modes: choose a steady, customizable color; enjoy the dynamic motion of a marquee effect; or unwind with the gentle rhythm of a breathing light display, where you can also customize the color.



EN

TROUBLESHOOTING

Q1. Why is the screen white and blurry at night?

- When the camera lens is obstructed or there are obstructions near the lens, it can cause the night vision image to be blurry and whitened. Please use the pan/tilt function to adjust the direction of the camera until the quality of the night vision image returns to normal.
- If the problem persists, our support team at support@czeview.net is here to help.

Q2. Why can't the camera connect to the APP


- Verify the camera is powered on, indicated by a slow red flashing light.
- Ensure the 'CZView' app is installed on your device.
- Select the correct device type and model when adding a new device in the app.
- Check for a stable network connection and keep both the camera and mobile device close to the router during setup.
- Enter the correct password as outlined in the instruction manual.
- Avoid using emojis, special characters, or symbols in your WiFi name and password.
- If the above steps don't resolve the issue, press and hold the 'RESET' button on the camera until you hear a 'cuckoo' sound. This initiates recalibration. Afterwards, reconnect the camera in the app.
- Should these solutions not resolve your issue, please don't hesitate to contact our support team at support@czeview.net.

Q3. Why is the camera unable to scan the QR code when connected to the APP?


- If the camera's indicator light is rapidly flashing red:
 - a. Check that the router is operational and emitting signals.
 - b. Verify the network's stability.
 - c. Ensure the device is not in an area with no network coverage.
- d. If issues persist, press and hold the 'RESET' button until you hear a 'cuckoo' sound. This initiates the recalibration process. Once the recalibration is complete and the light flashes red slowly, attempt to reconnect.

- If the camera's indicator light is slowly flashing red:
 - a. Clean the lens if it's dirty.
 - b. Relocate the camera to a less brightly lit area if necessary.
- Should these steps not resolve the issue, feel free to reach out to our support team at support@czeview.net for additional assistance.

Q4. Why didn't I get the alarm messages?

- On the Home page, find your device and tap  in the lower right corner of the window. Then select 'Alarm Management' and make sure that 'Motion Detection', 'Noise Detection', or 'Temperature and Humidity Alarm' is enabled.
- In the same settings area within the APP, confirm that 'Receive Alert Notifications' is turned on.
- In your phone's system settings, check that the app is permitted to send push notifications for detections.
- If these solutions do not resolve your issue, please contact our support team at support@czeview.net for further assistance.


Q5. The Pan/Tilt is not working via the APP.

- Avoid manually adjusting the lens by hand, as this can interfere with the camera's functionality.
- On the Home page, find your device and tap  in the bottom right corner of the window. Select 'PTZ Correction' to initiate the camera lens calibration.
- If these solutions do not resolve your issue, please contact our support team at support@czeview.net for further assistance.


Q6. Why does the camera display a noticeable red or green tint?

This issue is typically caused by the camera's infrared filter failing to switch automatically, resulting in a red or green tint in the image. To resolve this, please try the following steps:


- While observing the live preview in the app, gently tap the camera until the image returns to its normal clarity and color.

- On the Home page, locate your device and tap  located in the lower right corner of the window. Navigate to 'Image Settings' and find 'Night Vision Mode'. In a night or dark environment, alternate between 'Day Mode' and 'Night Mode' to see if the image clarity and color return to normal.
- If these solutions do not resolve your issue, please contact our support team at support@czeview.net for further assistance.

Q7. How to reconnect the device in a new WiFi area?

- On the Home page, find your device and tap  in the lower right corner of the window. Scroll to the bottom and select 'Delete Device'.
- Press and hold the 'RESET' button until you hear a 'cuckoo' sound. This initiates the recalibration process.
- After recalibration, when the indicator light begins to flash red slowly, attempt to reconnect the device with the APP using the new WiFi signal.

Q8. Why can't the SD Card be recognized by the camera?

- Tap  located in the lower right corner of the window.
- Navigate to 'Recording Management'. If the SD card's memory information is not displayed, follow these troubleshooting steps:
 - a. Power off the camera, remove and then reinsert the SD card with the label side up and the pins facing down, and power the camera back on. Check if the app can now read the SD card's memory information.
 - b. Verify if the SD card's information can be read by a computer. If not, replace the SD card. If it can, please contact us at support@czeview.net for further assistance.
 - c. If these solutions do not resolve your issue, please don't hesitate to reach out to our support team at support@czeview.net.

Q9. How to seek seller support for assistance?

- Open the APP, and go to 'me' at the bottom of the navigation bar. Tap 'Help' > 'Feedback' > 'Send us feedback'. Here, you can request assistance and provide the necessary information.
- Alternatively, you can directly email us at support@czeview.net with your concerns.