

Step 1: To turn on the vaporizer, press and hold down both the up and down arrow buttons for a few seconds. Your Air will begin heating to the standby temperature, close to the first heat level.

Step 2: Use the arrow buttons to raise or lower your Air's temperature. The numbers represent the following temperatures:

Level One - 50 C / 122 F

Level Two - 185 C / 365 F

Level Three - 190 C / 374 F

Level Four - 195 C / 383 F

Level Five - 200 C / 392 F

Level Six - 205 C / 401 F

Level Seven - 210 C / 410 F

Note: 360 F / 185 C is the recommended level to begin experiencing vaporization, and then you can adjust according to personal preference.

Step 3: Pack your herbs into the bowl end of the glass draw stem. Coarsely ground material is less likely to slip through the holes in the draw stem. Be sure to not over pack the stem, as this will prevent the proper airflow necessary for vaporization. Hold the Air with the heating element facing downward and connect to the packed draw stem. Now flip the whole unit right side up.

Step 4: Wait 10 to 15 seconds prior to taking slow and steady inhalations from the Air. Draw lightly to prevent any material from being pulled through.

Step 5: When you have finished vaporizing, turn the unit upside down and remove the draw stem. Be sure to clean out any excess material that may have fallen onto the heating element. Use the attached cap to cover the heating element when not in use.