



## hanging instructions

- 1 IF HANGING THE SWING INDOORS, ATTACH TO A BEAM OR CEILING JOIST (USE A STUD FINDER TO LOCATE). TO AVOID DRILLING INTO THE CEILING, USE A STAND-ALONE HAMMOCK STAND.
- 2 SCREW THE EYE MOUNT INTO THE BEAM. THIS WILL TAKE A BIT OF ELBOW GREASE. MAKE SURE IT IS SCREWED IN SECURELY.
- 3 ATTACH THE CARABINER TO THE EYE MOUNT. DO NOT USE S HOOKS.
- 4 ADD A CHAIN FOR DESIRED LENGTH. PUT THE CHAIN THROUGH THE EYE OF THE SWING AND ATTACH THE ENDS TO THE CARABINER.

THIS SWING DOES NOT INCLUDE HANGING HARDWARE

## warnings

TEST THAT THE SWING IS HUNG SECURELY BEFORE EACH USE.

ALWAYS USE THE RESTRAINT SYSTEM IN THE SWING.

THIS SWING IS FOR CHILDREN UNDER 40 LBS ONLY.

TO USE THE SWING, YOUR CHILD MUST BE ABLE TO HOLD THEIR OWN HEAD UP WHILE IN A SEATED POSITION.

NEVER LEAVE YOUR CHILD ALONE WHEN ON THE SWING.

THE SWING IS NOT A SAFE PLACE FOR YOUR CHILD TO SLEEP.

STOP USING THIS SWING WHEN YOUR CHILD IS ABLE TO CLIMB OUT OF IT ON THEIR OWN.

## care instructions

TO KEEP THE SWING IN ITS BEST STATE, KEEP OUT OF RAIN OR DIRECT SUNLIGHT WHEN NOT IN USE. STORE IN A DRY PLACE. SPOT CLEAN ONLY. AIR DRY ONLY. DO NOT PUT IN THE DRYER.