





TS-912 Shade Sail Spacing Guide for Turnbuckles

DISCLAIMER: These instructions are provided as a courtesy to Tenshon® customers and are to be used only as general guidelines. Tenshon accepts no responsibility for installations. If you are unsure about your installation, please consult a qualified builder or engineer.

The space required to hang a sail needs to be larger than the dimensions of the finished sail. This accounts for the attachment hardware used as well as the stretch of the sail. Turnbuckle hardware sold by Tenshon is 7-5/16" closed and 9-0" when half open. The bow shackle at each corner adds 1-3/16".




Dimensions of a relaxed sail



Minimum dimensions between anchor points for a tensioned sail with hardware


Tips:

- ▶ Each pole or anchor point should be placed on a line that bisects the corner angle of the sail. This will evenly apply tension to all edges of the sail to reduce sagging and bunching at the corners.



- ▶ Anchor points should be strong and secure. When anchoring into a building, avoid attaching into fascia or soffits. Instead, use structural elements like studs, roof trusses or concrete filled CMU.

- ▶ Height variation at the corners will not only create a pleasing aesthetic, it will also help the sail perform the way it is designed to. We recommend approximately one foot of height difference for every 5 feet between posts or anchor points.



- ▶ Use turnbuckles because they allow the sail to be tensioned after all the corners are attached to the anchor points.