



## WARNING! Safety Rules

- For ages 8 and up.
- Maximum user weight limit 250 lbs.
- One person at a time.
- Maximum distance from user feet to the ground is 18 inches.
- Read all instructions before assembly.
- Adult supervision required at all times.
- For use only on 2" (50mm) wide slacklines.
- Check for correct installation and for wear prior to each use. If worn or damaged parts are found, replace with Fofana replacement parts.
- Adult assembly required, including site selection and installation.
- Area under slackline must be free of all hazards, obstacles, obstructions, and other dangers nearby.
- Load stress test must be performed before use.
- All watchers should maintain a 10 foot distance.
- Use healthy strong trees at least 1 foot in diameter.
- Do not attach to unhealthy trees, injury may result.
- Follow all instructions and heed all warnings in slackline instruction manual and setup guide.
- Do not use with an obstacle span greater than 20 feet or on slacklines set up with slope. This may generate excessive speed which could cause injury. Be safe, go slow.
- Do not place fingers or hair inside of slider pulley or serious injury may result.
- Do not reach up to grab slackline webbing while riding or as a spectator to slow down rider or serious injury may result.
- ALWAYS MAKE SURE YOUR RIDERS KNOW AND FOLLOW THE RULES AND INSTRUCTIONS.
- Poor installation, poor sight selection, inadequate rider instruction, poor adult supervision or improper use can cause severe injury or death.

The buyer, installer, and user of this product assume all risk and accept all responsibility for any damage or injury, including death, that may arise from its use.

**Failure to follow these instructions could result in serious injury!**

If you have any questions or problems, please contact us, we are glad to help!

Visit [Fofana.co/Ninja](http://Fofana.co/Ninja) or email [support@fofana.co](mailto:support@fofana.co)

## User Manual and Setup Guide

### Set Contents

- 1 Ninja Slider Pulley
- 1 Triangle Carabiner



### Step 1. Properly set up Ninja Slackline

- Follow the User Manual and Setup Guide for your ninja slackline obstacle course.
- Leave up to 20 feet of length at the beginning of the course for the Slider Pulley obstacle.
- Slider Pulley should be placed near the beginning of the obstacle course so the user can slide down the webbing toward the middle when the line sags due to the user weight.
- Line should be set so that the shortest user's feet hang 12 inches from the ground while hanging from the obstacles at the middle of the webbing.

### Step 2. Mount Slider Pulley to Ninja Slackline

- Place Slider Pulley over the top of the slackline.
- Make sure the longer side of the Slider Pulley hangs below the webbing line. See picture below.
- Secure the Triangle Carabiner onto the Slider Pulley by threading it through the hole in each of the pulley side plates. Triangle Carabiner must pass through both side plate holes or it may fall off.
- Attach a hanging obstacle to the Triangle Carabiner and lock the securing nut closed. See picture.
- Make sure all connections are tight and perform the mandatory load stress test by using either a 250 lbs person or weight suspended from the line.

### Step 3. It's Ninja Time!

- Have fun, but make sure users do not get too much speed. Be safe, go slow.



# ACTIVATE YOUR FREE 1 YEAR EXTENDED WARRANTY

VISIT:

[FOFANA.CO/NINJA-REGISTER](http://FOFANA.CO/NINJA-REGISTER)

OR

SCAN:



**MUST REGISTER WITHIN 14 DAYS OF PURCHASE**

**DO YOU HAVE AN ISSUE NOW?**

**PLEASE REACH OUT TO US:**

**[SUPPORT@FOFANA.CO](mailto:SUPPORT@FOFANA.CO)**

**WE'LL BE GLAD TO HELP YOU ASAP.**

# FOFANA

# NINJA

# OBSTACLE COURSE