




TIMESQUARTZ®

SPORTS WATCH


12 Characters Electronic Watch Instruction Manual



A. Features:


- ◆ 12 Digits LCD Display , Display Hour ,Minute ,Second ,Month ,Day and Week.
- ◆ Daily Alarm and Chime hourly
- ◆ 12 / 24H format selectable, Auto Calendar
- ◆ 1/100 second Chronograph with split functions
- ◆ EL backlight

B. Operational Manual:



Normal time display

B key




Chronograph

B key



Alarm

B key



Time setting

- ◆ At any mode,press A key or E key,the ELback light on for 3 seconds.

C.Chronograph:

- ◆ Press B key twice into the chronograph
- ◆ Press C key to start/stop running
- ◆ When stop ,press D key to split count
- ◆ Press B key into the normal mode

D.Daily Alarm:

- ◆ Under the normal mode , press B key into the Alarm , then press C key to turn ON/OFF Alarm and Chime.
- ◆ Press B key into the alarm mode
- ◆ Press D key once ,hour displayer flashing ,press D key again minute displayer flashing
- ◆ Press C key can adjust the hour and minute each
- ◆ Press B key turn to normal mole

E.Time Setting:

- ◆ Under the normal mode ,press B key three times to setting the time with the "Second" flashig; Press key to select item as following sequence:Hour,Minute,Month,Day, Day of Week,second. Press C key can adjust the flashing item. Press B key go back to the normal mode

**You can wear the watch when bathing and washing car.
But never push button in the water.**