

55 mm

TR TekRepublic

LIMITED WARRANTY
 Tek Republic provides a one year limited warranty for all of its products against defects in material and workmanship. During this period, Tek Republic will repair or replace any product which proves to be defective. However, Tek Republic will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Tek Republic and products where the sealed assembly trace has been broken.

If you discover a defect, Tek Republic will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Tek Republic. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (No PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

[http:// tek-republic.com](http://tek-republic.com)

Support: <http://www.tek-republic.com/contact.html>


100 mm

P4

TR TekRepublic User Manual

TR-PCIE-U34S00

Tek Republic PCI-E to USB 4 Port Express Card with 5V 4-pin power connector




1. USB 3.0 Interface
2. 4-Pin Power Connector

Requirement

- An available PCI-E slot on your computer
- A 4-Pin DC cable to power supply
- Supports windows XP/Vista/7/8/8.1

P1

Installation



1. Power off your computer
2. Open the computer case
3. Connect the PCI-E Card to an available PCI-E interface, and connect the 4-pin DC power connector.
4. Turn on the computer and install the driver

Specifications

USB Type	USB 3.0
Data Transfer Rate	Up to 5.0 Gbps
Internal USB Ports	4 x USB 3.0
Power	4-Pin
Dimension	7.13 x 3.2 x 0.75 inches / 181 x 81 x 19 mm
Weight	1.6 Oz / 45.36 G

FAQ

Why is device connected to the PCI-E card keeps disconnecting from the computer or restarting while transfer data ?
 This is probably being caused by insufficient power supply. Ensure the 4-Pin connector is securely inserted.

What are different interface types for PCI-E card ?
 The interface types for PCI-E cards included: PCI-E X1/X2/X4/X8/X16. The most popular and command use types are PCI-E X1 and X16, which are supported by our products.

P2

P3