
Poly Flushmount Style Exhaust Fans

INSTALLATION INSTRUCTIONS




Rough-In Opening Dimensions

Fan Size	Dimen. A	Dimen. B
9"	14 ½"	13 3/4"
12"	16 ³¼"	15 ³/₄"
16"	20 1/2"	19 ½"
20"	24 ³ / ₄ "	23 1/2"

INSTALLATION PROCEDURES

- 1. After you have made the correct sized opening in the wall, the fan unit can now be placed into the opening and secured with lag bolts and washers (supplied) as in Figure 1.
- 2. There are two (2) shutter latches supplied with each fan which are used to hold the shutter in place. These latches should be positioned with one on the top and one on the bottom in the center hole of the fan panel. Note Be sure to use two (2) washers for each shutter latch (see Figure 1).
- 3. Once the fan unit has been securely fastened to the wall, the fan is now ready to be wired. Consult your local electrician. As shown in Figure 2, the electrical wire from the motor should be run through the wire harness on the top inside of the fan housing and then through the notch in the upper right of the shutter frame.
- 4. Flashing should be attached across the top of the fan on the outside of the building. Caulking can be used on the sides of the fan housing to assure a tight seal.



MAINTENANCE INSTRUCTIONS

Please Note - The fan unit you purchased is built with heavy duty components; designed to give you many years of performance. However, like anything mechanical, your fan unit will require a small amount of periodic maintenance to assure maximum efficient operation.

Our fans utilize motors that have sealed ball bearings which require no oiling. Periodically clean any dust and grime that has accumulated on the motor, fan blade and automatic shutter (pressure washing the unit will void the warranty). By doing so you will keep your fan unit running efficiently.



800-779-3267 · Fax: 320-251-2922

sales@schaeferfan.com • www.schaeferfan.com