84 x 84 mm





or set your own timer. The watch will remind you when the time

ALARM CLOCK You can set alarms from the NoiseFit Focus app.

CALENDAR Use this feature to view the calendar.

SET TIME

Tap on 'Set time' to set or adjust the time on your watch.

You can use this feature to do basic calculations.

FIND PHONE This feature helps you find your mobile device by making it ring.

Just tap on 'Find phone', and your phone will start to ring, even if it is on Silent mode.

You can use this feature to use the camera remotely from the

User Manual for NoiseFit Grace



Vibration intensity Language On Display screen. Tap on 'Battery' to view the current battery percenand to turn on the Power Saving Mode.

09 User Manual for NoiseFit Grace

Choose from four formats to view your watch feature

Tap on 'Display' to switch between watch faces and adjust the brightness, screen timeout duration, and Raise to wake duration. You can also choose the Always



You can use this feature to access the QR code to download the NoiseFit Focus app.

10 User Manual for NoiseFit Grace

You can use this feature to set and change your password on your watch. System

Tap on 'System' to access system info and to shut down and reset your watch.





DEVICE INFORMATION The NoiseFit Diva smartwatch contains the following:

AMOLED display

• 16mm strap

 Blood oxygen monitor • IP67 water resistance Heart rate monitor

The NoiseFit Grace smartwatch stores your activity data for up to 7 days in between the time you sync your watch to the NoiseFit Focus app. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.

How do I update my NoiseFit Grace?

You can update your NoiseFit Grace via the NoiseFit Focus app. In the app, select 'Me', go to 'Settings' & check for version updates.

How do I find my watch's current firmware version?

You can find the watch's current firmware on the watch. Go to 'Settings', tap on 'System' then 'System info' to view the current firmware version. On the NoiseFit Focus app, tap on 'Device' and choose 'Device Version' to know your current firmware version 11 User Manual for NoiseFit Grace 12 User Manual for NoiseFit Grace

How does the watch estimate how many calories have been burned?

NoiseFit Grace estimates how many calories you've burned based on the

How do I change my activity goals?

You can do it through the NoiseFit Focus app. In the app, select 'Me' and go to 'Exercise Goals' to change your goals.

How do I log my weight?

You can log in your weight the first time you set up your NoiseFit Focus app. However, you can update the weight later via the NoiseFit Focus app. Go to 'Me', and tap on the section with your name on it to update your weight. You can update your nickname, birthday, sex and height as well.

DISPOSAL AND RECYCLING INFORMATION

Electrical and electronic devices may not be disposed off with domestic vaste. Consumers are obliged by law to return the electrical and reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment

REGULATORY INFORMATION

13 User Manual for NoiseFit Grace

USA: Federal Communications Commission (FCC) Statement This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: • This device may cause harmful interference, and this device must

accept any interference received, including interference that may cause Warning: Changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment guarantee that interference will not occur in a particular installation. reception, which can be determined by turning the equipment off and on he user is encouraged to try to correct the interference by one or more of

Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for hel The NoiseFit Diva Watch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is

In some cases, prolonged use of products may cause skin irritation Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.

14 User Manual for NoiseFit Grace 15 User Manual for NoiseFit Grace

• Keep the device dry and clean regularly and especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin

lightly in contact with your skin and there is a gap of about one finger's width between the wrist strap and your wrist.

· For stains that are difficult to remove, it is recommended to scrub with

• The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in shallows. • Keep it away direct sunlight, high temperatures or humid conditions as it

SAFETY INSTRUCTIONS • Do not disassemble the battery on your own.

• Do not expose NoiseFit Grace to extremely high or low temperatures. The

excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.

• Charge the battery in a cool, ventilated room. • Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid

• Do not use household cleaners to clean the device. Use soap-free cleaners

• Use only the charging cable supplied to charge the battery. Do not charge for

positive and negative terminals of the battery.

Do not use your product in a sauna or steam room.

Do not place the batteries in the water.

• Do not attempt to repair or maintain the watch yourself, service and aintenance should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel. • To prevent device damage, accessory damage and device failure, always protect

can occur when a metallic object, such as a coin, causes the direct connection of

Keep the batteries out of children's reach and in a safe place to prevent danger.

• Do not dispose off batteries in the fire as that may cause an explosion. Dispose

off used batteries in accordance with your local regulations. Do not dispose it as

the device against strong impact or shock.

household waste.

16 User Manual for NoiseFit Grace

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support gonoise in

noise